

Setting The Timer - Sanyo KS2432 Instruction Manual

Split system air conditioner cool/fan model

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18
19
20
21
22
23
24



•

-

Troubleshooting

•

Bookmarks




ON I /OFF
NIGHT
OFF
ON
SETBACK
MODE
CLOCK
FLAP
HH

FAN SPEED
MM
A/C
ACL
TIME SET
SELECT
SENSOR
BATTERIES

1. How to set the present time

PM

2. How to set the



OFF time

OFF

PM


01-201-17EG

Setting the Timer

(Example) To set to 9:10 p.m.

Operation


1. Press the Program button (times)
2. Press the HH button displayed.
- Press the MM button until 10 is displayed.



(Example) When air conditioner is running, turning it off at 11:30 p.m.

1. Press the Program button (times)
2. Press the HH button until PM 11 is displayed.
- Press the MM button until 30 is displayed.
3. Press the TIMER SELECT button once to set OFF time.

OFF
ON
CLOCK
The time indication alone flashes.



ManualsLib.com


The until PM 9 is matically except for the ":" symbol after 10 sec.

OFF
ON
CLOCK
) once. The time indications flash.



The display will change automatically show the present time after 10 sec.

The



OFF

Indication

display

will

auto-

stop

flashing

timer

and

OFF

back

to


present

time

and

are displayed.

17



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
14
15
16
17
18
19
20
21

Quick Links:

[Features](#)

[Product Information](#)

[Electrical Requirements](#)

[Names of Parts](#)

[Operation with the Remote Control Unit](#)

[Care and Cleaning](#)

[Troubleshooting](#)

Related Manuals for Sanyo KS2432

[Air Conditioner Sanyo C2432A Installation Instructions Manual](#)

(50 pages)

[Air Conditioner Sanyo KS2432 Instruction Manual](#)

Split system air conditioner; wall-mounted type ceiling-mounted type recessed type cool/fan model (24 pages)

[Air Conditioner Sanyo XS4232 Technical Data And Service Manual](#)

(66 pages)

[Air Conditioner Sanyo C4232 Technical Data & Service Manual](#)

Split system air conditioner (66 pages)

[Air Conditioner Sanyo KS3032 Service Manual](#)

Split system air conditioner (56 pages)

[Air Conditioner Sanyo KS3032 Service Manual](#)

(54 pages)

[Air Conditioner Sanyo C3032 Service Manual](#)

Split system air conditioner (54 pages)

[Air Conditioner Sanyo XS3632 / C3632 Service Manual](#)

Split system air conditioner (51 pages)

[Air Conditioner Sanyo XS3632 Service Manual](#)

Split system air conditioner (50 pages)

[Air Conditioner Sanyo TS2432 Service Manual](#)

Split system air conditioner (48 pages)

[Air Conditioner Sanyo XS2432 Service Manual](#)

Split system air conditioner (48 pages)

[Air Conditioner Sanyo C1852 Service Manual](#)

Split system air conditioner (45 pages)

[Air Conditioner Sanyo 24XS32A Submittal Sheet](#)

Indoor/outdoor ceiling recessed (4-way) air conditioner (3 pages)

[Air Conditioner Sanyo 30KS32A Specifications](#)

Wall mounted air conditioner (3 pages)

[Air Conditioner Sanyo 36TS32A Datasheet](#)

Ceiling suspended air conditioner (3 pages)

[Air Conditioner Sanyo 36XLS32A Specifications](#)

Ceiling recessed (4-way) air conditioner (3 pages)

Related Content for Sanyo KS2432

[SPW-CR365GXH56 | Setting The Timer](#)

Sanyo SPW-CR365GXH56

[XS1271 Setting The Timer](#)

Sanyo XS1271

[COOL Setting The Timer](#)

Sanyo COOL

[SAP-KRV96EHDS Setting The Timer](#)

Sanyo SAP-KRV96EHDS

[SAP-KRV96EH Setting The Timer](#)

Sanyo SAP-KRV96EH

[SAP-CRV93EHN Setting The Timer](#)

Sanyo SAP-CRV93EHN

[SAP-KRV94EHDX Setting The Timer](#)

Sanyo SAP-KRV94EHDX

[KS1872 Setting The Timer](#)

Sanyo KS1872

This manual is also suitable for:

[Ts2432Xs1822Ks3032Xs1852Ts3632Xs2432](#) ... [Show all](#)