



Toshiba TDP-S3 Quick Start

Quick start guide

1
2

--


•

Bookmarks

--

Quick Links

[Download this manual](#) See also: [Service Manual](#), [User Manual](#)



TDP-T3/S3 Quick Start

T3 QS-eng.fm Page 1 Monday, February 4, 2002 2:31 PM

1

USB
mouse
computer cable

TDP-T3/S3 Quick Start

2

Power cord

3

Adjust the image position.

* Your computer may use a different key combination. Check your computer's user's guide for more information.

Present!

Lens cap

To obtain the best overall focus quality,
open the menu and focus on the text.
This will insure the best overall
image quality.

Height
adjustment

4

If necessary, press the activation
keys on your laptop to see the
image on the screen.*

Focus

Zoom

Leveling foot

connector panel

Signal from computer

S

S-video

Composite video

Sound




6

5

009-0599-00 *009-0599-00*

Laptop power
cord


T3 QS-eng.fm Page 1 Monday, February 4, 2002 2:31 PM



To obtain the best overall focus quality,
open the menu and focus on the text.
This will insure the best overall
image quality.


Adjust the image position.

4



Present!

If necessary, press the ac
keys on your laptop to s
image on the screen.*



[Next Page](#)

1
2

Related Manuals for Toshiba TDP-S3

[Projector Toshiba TDP-S3 Service Manual](#)

(108 pages)

[Projector Toshiba TDP-S3 User Manual](#)

Toshiba projector user guide (66 pages)

[Projector Toshiba TDP-S3 User Manual](#)

Toshiba tdp-s3 projector user manual (66 pages)

[Projector Toshiba TDP-T3 Quick Start](#)

(2 pages)

[Projector Toshiba TDP-S35 Owner's Manual](#)

Data projector (svga / with document camera) (25 pages)

[Projector Toshiba TDP-S35U Specifications](#)

Toshiba tdp-s35u: specifications (2 pages)

[Projector Toshiba TDP-S35U Specifications](#)

Mobile projector (2 pages)

[Projector Toshiba TDP-SC35 Specifications](#)

Brochure (2 pages)

[Projector Toshiba TDP-S35CC Service Manual](#)

Dlp projector (6 pages)

[Projector Toshiba Camileo TDP-S20 Owner's Manual](#)

Svga / with document camera (25 pages)

[Projector Toshiba DP-SW25T Owner's Manual](#)

Data projector (svga / with pc card slot) (37 pages)

[Projector Toshiba TDP-S25U Owner's Manual](#)

Tdp-s25u user's guide (25 pages)

[Projector Toshiba TDP TDP-S8 Owner's Manual](#)

Data projector (45 pages)

[Projector Toshiba TDP-S80U Owner's Manual](#)

Svga / with document camera (25 pages)

[Projector Toshiba TDP-SP1U Owner's Manual](#)

Tdp-sp1u user's guide (46 pages)

[Projector TOSHIBA TDP-S2 User Manual](#)

Multimedia projectors (62 pages)

Summary of Contents for Toshiba TDP-S3

[Page 1: Connector Panel](#)

connector panel TDP-T3/S3 Quick Start Signal from computer S-video Composite video Sound mouse computer cable Present! Power cord If necessary, press the activation keys on your laptop to see the Lens cap image on the screen.* Laptop power cord To obtain the best overall focus quality, Focus open the menu and focus on the text.

[Page 2](#) Need to talk to someone? Still need help? SAFETY INSTRUCTIONS Nothing appears on the screen. All I see is the startup screen. Safety Definitions Warning: Caution: Safety Symbols There's no computer image on the screen, just the message, Perfecting the Attention: Image, in the lower right corner.

This manual is also suitable for:

E4.1 ellipticalTdp-t3