



Whirlpool MVW18PDAXW0 Use And Care Manual

Top-loading

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28

• PAGE

1

OF 28 GO

•


-

Troubleshooting

•

Bookmarks

Available languages




Quick Links

- [1 Table of Contents](#)
- [2 Control Panel and Features](#)
- [3 Washer Maintenance](#)

4 Troubleshooting

[Download this manual](#)



Whir

TOP-LOADING
WASHER

USE AND CARE GUIDE

LAVADORA

DE CARGA

SUPERIOR
MANUAL

TOP-LOADING
WASHER

USE AND CARE GUIDE



LAVADOR
SUPERIOR
MANUAL

DE

USO Y CUIDADO

This manual contains useful information; read it before operating your washer.
Este manual contiene informaci6n 6til; por favor l6alo antes de operar su lavadora.



Table

of Contents

[WASHER SAFETY](#) 2

[CONTROL PANEL AND FEATURES](#) 3

[CYCLE GUIDE](#) 5

[USING YOUR WASHER](#) 6

[WASHER MAINTENANCE](#) 9

[TROUBLESHOOTING](#) 11

[INDEX](#) 15

[GLOSSARY](#) 16

[INDEX](#) 15

[GLOSSARY](#) 16

[INDEX](#) 15

[GLOSSARY](#) 16

[INDEX](#) 15

[GLOSSARY](#) 16

[INDEX](#) 15

[GLOSSARY](#) 16

TOP-LOADING WASHER

USE AND CARE GUIDE

LAVADOR SUPERIOR USO Y

In&ce

SEGURIDAD

[DE LA LAVADORA](#) 15

[PANEL DE CONTROL Y CARACTERÍSTICAS](#) 16

[GUIA DE CICLOS](#) 18

[USO DE SU LAVADORA](#) 19

[MANTENIMIENTO](#) 22

[SOLUCION DE PROBLEMAS](#) 24

[W1046297C](#) 24

This manual contains useful information; read it before operating your
Este manual contiene informaci6n 6til; por favor l6alo antes de operar su

Table of Contents

WASHER SAFETY	2
CONTROL PANEL AND FEATURES	3
CYCLE GUIDE	5

SEGURIDAD DE LA LAVA
PANEL DE CONTROL Y C
GUIA DE CICLOS

ManualsLib.com

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool MVW18PDAXW0

[Washer Whirlpool 3SWTW4800YQ Use And Care Manual](#)

(28 pages)

[Washer Whirlpool MTW6200V Installation Information](#)

Top load washer (1 page)

[Washer Whirlpool W10240438A Installation Instructions Manual](#)

Whirlpool washer installation instructions (20 pages)

[Washer Whirlpool MHW7000XR1 Use & Care Manual](#)

Front-loading automatic washer (48 pages)

[Washer Whirlpool WTW5700AC Installation Instructions Manual](#)

3.6 cu. ft. cabrio top load washer with see-through tempered glass lid. (20 pages)

[Washer Whirlpool WTW5500 Delivery & Installation Pointer](#)

Top load washers with dispenser drawer (4 pages)

[Washer Whirlpool WFW9050XQ Dimensions And Installation](#)

Whirlpool front-loading washer dimensions and installation (2 pages)

[Washer Whirlpool MVWC400XW Technical Education](#)

Vertical modular washer (84 pages)

[Washer Whirlpool WTW7000DW0 Use And Care Manual](#)

(36 pages)

[Washer Whirlpool W10200890B Installation Instructions Manual](#)

Whirlpool washer installation instructions (16 pages)

[Washer Whirlpool WASHER Installation Instructions Manual](#)

Washer (16 pages)

[Washer Whirlpool WTW9500E SERIES Service Manual](#)

6.2 cu ft direct drive top load washer (68 pages)

[Washer Whirlpool M 0512 Manual](#)

(2 pages)

[Washer Whirlpool CAE2745 Manual](#)

Commercial washers (40 pages)

[Washer Whirlpool MAT20CS Manual](#)

(20 pages)

[Washer Whirlpool Maytag Installation Instructions Manual](#)

(24 pages)

Summary of Contents for Whirlpool MVW18PDAXW0

[Page 1: Table Of Contents](#)

Whir TOP-LOADING LAVADORA DE CARGA WASHER SUPERIOR MANUAL USE AND CARE GUIDE
USO Y CUIDADO This manual contains useful information; read it before operating your washer.
Este manual contiene informaci6n Otil; por favor 16aloantes de operar su lavadora. • Table of
Contents In&ce WASHER SAFETY

[Page 2: Washer Safety](#)

WASHER SAFETY Your safety and the safety of others are very important. We have provided
many important safety messages in this manual and on your appliance. Always read and obey
all safety messages. This is the safety alert symbol. This symbol alerts you to potential hazards

that can kill or hurt you and others. All safety messages will follow the safety alert symbol and either the word "DANGER"...

[Page 3: Control Panel And Features](#)

CONTROL PANEL AND FEATURES Not all features and options are available on all models. DRAIN & SPIN TEMPERATURE LOAD SIZE allcold rinses Mode 3DWTW4740 OPTIONS (on some models) LOAD SIZE The following options may be added to most cycles. Select the setting most suitable for your load. Small will add a low amount of water for smaller loads and Super will add EXTRA RINSE the most amount of water for large or bulky loads.

[Page 4](#) LID LOCKED To allow for proper spin operation, the lid will lock and the Lid Lock light will turn on. This light indicates that the lid is locked and cannot be opened. Lid Locked If you need to open the lid, press START/Pause/Unlock.

[Page 5: Cycle Guide](#)

CYCLE GUIDE For best fabric care, choose the cycle that best fits the load being washed. Not all cycles and options are available on all models. Sturdy fabrics, Super High Provides maximum wash time and action for tough stains colorfast items, Warm Wash and soils.

[Page 6: Using Your Washer](#)

USING YOUR WASHER SUPER CAPACITY and SUPER PLUS CAPACITY WASHERS LOADING To these recommended loads of full volume, set the load size control in the largest load position. Heavy Work Clothes Mixed Load Towels Delicate 3 pairs of pants 3 double sheets 10 bath towels 3 camisoles 3 shirts...

[Page 7](#) Load laundry into washer Add fabric softener to dispenser (on some models) Load garments in loose heaps evenly around basket wall. For best results, do Pour a measured amount of liquid fabric not pack the load tightly. Do not wrap large items such as sheets around the agitator;...

[Page 8](#) Select LOAD SIZE Select options, if desired (on some models) LOAD SIZE EXTRA RINSE FABRIC SOFTENER Model 3DWTW4840 shown ADDED Model 3DWTW4840 shown Select the load size setting most suitable for your load. Small will add a low amount of water for smaller loads and Super will Select the desired cycle options.

[Page 9: Washer Maintenance](#)

WASHER MAINTENANCE WATER INLET HOSES WASHER CARE (cont.) " _ Replace inlet hoses after 5 years of use to reduce the risk of 2. Chlorine Bleach Procedure {Alternative}: hose failure. Periodically inspect and replace inlet hoses if no Open the washer lid and remove any clothing bulges, kinks, cuts, wear, or leaks are found.

[Page 10](#) REINSTALLING/USING WASHER AGAIN To reinstall washer after non-use, vacation, winter storage, Excessive Weight Hazard or moving: Use two or more people to move and install washer. 1. Refer to "installation Instructions" to locate, level, and connect washer. Failure to do so can result in back or other injury, 2.

[Page 11: Troubleshooting](#)

TROUBLESHOOTING First try the solutions suggested here to possibly avoid the cost of a service call. If you experience Possible Causes Solution Check the following for Feet may not be in contact with the Front and rear feet must be in firm contact with floor, and proper installation or floor and locked, washer must be level to operate properly.

[Page 12](#) TROUBLESHOOTING Electrical Shock Hazard Plug into a grounded 3 prong outlet. Do not remove ground prong. Do not use an adapter. Do not use an extension cord. Failure to follow these instructions can result in death, fire, or electrical shock. First try the solutions suggested here to possibly avoid the cost of a service call.

[Page 13](#) TROUBLESHOOTING First try the solutions suggested here to possibly avoid the cost of a service call. Possible causes Solution if you experience Dry spots on load High speed spins extract more The high spin speeds combined with air flow during the final after cycle moisture than traditional top-load spin can cause items near the top of the load to develop dry...

[Page 14](#) TROUBLESHOOTING First try the solutions suggested here to possibly avoid the cost of a service call. Possible Causes Solution if you experience Not cleaning or Using too much detergent. The suds from too much detergent can keep washer from removing stains (cont.) operating correctly.

[Page 15: Seguridad De La Lavadora](#)

SEGURIDAD DE LA LAVADORA Su seguridad y la seguridad de los demostros es muy importante, Hemos incluido muchos mensajes importantes de seguridad en este manual su electrodoméstico. Lea y obedezca siempre todos los mensajes de seguridad. Este es el símbolo de advertencia de seguridad.

[Page 16: Panel De Control Y Características](#)

PANEL DE CONTROL Y CARACTERÍSTICAS No todas las características y opciones están disponibles en todos los modelos. Modelo 3DWTW4840 Nermol Cycles REGULAR REGULAR TEMPERATURE allcold fin es LOAD SIZE Modelo 3DWTW4740 Tamaño de la carga (LOAD SIZE) Opciones (OPTIONS) (en algunos modelos) Seleccione el ajuste más adecuado para su carga.

[Page 17](#) Perilla de ciclos de lavado Llenado/Detección (FILL/SENSING) Cuando se presione el botón de START/PAUSE/Unlock Use la perilla de ciclos de lavado para seleccionar entre los ciclos disponibles en su lavadora. Gire la perilla de ciclos Lid (Inicio/Pausa/Desbloqueo de la tapa), la lavadora se de lavado para seleccionar un ciclo para su carga.

[Page 18](#) GUIA DE CICLOS Para lograr el mejor cuidado de las telas, elija el ciclo que sea el más adecuado para la carga que va a lavar. No todos los ciclos y opciones están disponibles en todos los modelos. Artículos a lavar: Ciclo: Temperatura Velocidad...

[Page 19](#) USO DE SU LAVADORA LAVADORAS DE CAPACIDAD SUPER y DE CAPACIDAD SUPER PLUS COMO Para estas cargas de volumen completo recomendadas, coloque el control de tamaño de carga en la posición de la carga más grande. Ropa de trabajo pesado Carga mixta Toallas Ropa delicada...

[Page 20](#) Agregue detergente Agregue blanqueador líquido con cloro al depósito Agregue una cantidad medida de detergente en el fondo No sobrellene, diluya ni utilice más de 1 taza (250 ml). No de la canasta de la lavadora antes de agregar las prendas. utilice blanqueador no decolorante ni productos Oxi en el Siva a usar un producto para realzar el lavado, como Oxi...

[Page 21](#) Temperatura de lavado Telas sugeridas Seleccione un ciclo Caliente (Hot) Normal Cycles REGULAR Ropa blanca y de color Se agrega un poco de agua fría LIGHT para ahorrar energía. El agua pastel estará más fría que la del ajuste Prendas durables SUPER de agua caliente de su calentador WASH...

[Page 22: De La Lavadora](#)

CUIDADO DE LA LAVADORA (cont.) " "10, Presione Inicio/Pausa/ Desbloqueo (START/PAUSE/ 3. Deje siempre la tapa de la lavadora abierta entre un uso y otro, para ayudar a que se termine de secar la lavadora Unlock) para comenzar el ciclo y evitar la acumulación de residuos causantes de olores.

[Page 23](#) TRANSPORTE DE LA LAVADORA CUIDADO DE LA LAVADORA (cont.) Cierre ambos grifos de agua. Desconecte y elimine el agua Limpieza de los depósitos de las mangueras de entrada de agua. Después de usar la lavadora durante cierto tiempo, es posible que encuentre acumulación de residuos en los depósitos de Si se va a trasladar la lavadora durante una temporada...

[Page 24: Uso De Su Lavadora](#)

SOLUCION DE PROBLEMAS Primero intentar las soluciones sugeridas y evitar posiblemente el costo de una visita de servicio técnico. Si experimenta lo siguiente Causas posibles Solución Verifique lo siguiente Es posible que las patas no estén Las patas frontales y posteriores deberán hacer contacto firme para la instalación haciendo contacto con el piso y con el piso y la lavadora deberá estar nivelada para funcionar...

[Page 25](#) SOLUCION DE PROBLEMAS Peligro de Choque Eléctrico Conecte a un contacto de pared de conexión a tierra de 3 terminales. No quite la terminal de conexión a tierra. No use un adaptador. No use un cable eléctrico de extensión. No seguir estas instrucciones puede

ocasionar la muerte, incendio o choque el_ctrico.

[Page 26](#) SOLUCION DE PROBLEMAS Primero intentar las soluciones sugeridas y evitar posiblemente el costo de una visita de servicio t6cnico. Causas posibles Solucibn Si experimenta lo siguiente I La lavadora no La lavadora puede estar cargada de El cargar apretadamente o las cargas desequilibradas desagua/exprime, manera apretada o desequilibrada.

[Page 27](#) SOLUCION DE PROBLEMAS Primero intentar las soluciones sugeridas y evitar posiblemente el costo de una visita de servicio t6cnico. Si experimenta lo siguiente Hay arena, pelo de La arena, pelo de mascotas, pelusa Agregue un Enjuague adicional (Extra Rinse) (en algunos mascotas, pelusa, etc.

[Page 28](#) Cuando llame, tenga a mano la fecha de compra y el nQmero completo del modelo y de la serie de su lavadora. La informaci6n nos ayudara a atender mejor a su pedido. W104629770 10/12 Printed in U.S.A. ©2012 Whirlpool. All rights reserved. Impreso en EE.UU. Todos los derechos reservados.

This manual is also suitable for:

[Mvw18pdaww03dwtw48403dwtw4740](#)