



Whirlpool GT4185SKQ2 Use & Care Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24

• PAGE

OF 24 GO

•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks

Quick Links

[1 Table of Contents](#)

[2 Installation Instructions](#)


[3 Getting to Know Your Microwave Oven](#)

[4 Built-In Kits](#)

[5 Questions and Answers](#)

[6 Troubleshooting](#)

[Download this manual](#)



MODEL
GT4185SK
3828W5A1889/8183906

Use E Care Microwave Ovens

A Note to You	2
Microwave Oven Safety	3
Installation Instructions	5



Use
G
Micr

Getting to Know Your Microwave Oven	7
How your microwave oven works	7
Radio interference	7
For the best cooking results	7
Testing your microwave oven	7
Testing your dinnerware or cookware	8
Operating tips	8
Electrical connection	10
Microwave oven features	10
Control panel features	10
Using OPTIONS	11
Built-in kits	11
Setting the clock	12
Using the minute timer	12
Using the cooking rack	12
Microwave Oven Use	13
Cooking at high cook power	13
Cooking at different cook powers	13
Cooking with more than one cook cycle	14
Using AUTO DEFROST	14
Defrosting tips	15
Using JET START™ Feature	15
Using WARM HOLD	16
Sensor Cooking	16
Using COOK	16
Cooking chart	17
Using REHEAT	17
Reheating chart	18
Using POPCORN	18
Popcorn chart	18
Cooking Guide	19
Microwave Oven Care	20
Questions and Answers	21
Troubleshooting	22
Assistance or Service	23
Warranty	24

1-800-253-1301

Call our Customer Interaction Center with questions or comments. www.whirlpool.com



ManualsLib.com



Use G Micro

A Note to You
Microwave C
Installation I
Getting to K
How your r
Radio inter
For the bes
Testing you
Testing you
Operating
Electrical c
Microwave
Contro p
Using OPT
Built-in kits
Setting the
Using the r
Using the c
Microwave C
Cooking at
Cooking at
Cooking w
one cook c

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool GT4185SKQ2

[Microwave Oven Whirlpool GT4185SK Use & Care Manual](#)

Whirlpool microwave oven use & care guide gt4185sk (24 pages)

[Microwave Oven Whirlpool GT4175 Use & Care Manual](#)

Whirlpool corporation microwave oven use & care guide (16 pages)

[Microwave Oven Whirlpool GT4175SPB Product Dimensions](#)

1.7 cu. ft. countertop microwave ovens (1 page)

[Microwave Oven Whirlpool W10170440A User Instructions](#)

Whirlpool corporation microwave hood user instructions (6 pages)

[Microwave Oven Whirlpool GT4175SPB0 Parts List](#)

Microwave oven 1.7 cubic foot (6 pages)

[Microwave Oven Whirlpool GT4175SP Use & Care Manual](#)

Whirlpool microwave oven use & care guide model gt4175sp (16 pages)

[Microwave Oven Whirlpool GT4175SP Use & Care Manual](#)

(16 pages)

[Microwave Oven Whirlpool GT4175SPT3 Use & Care Manual](#)

(16 pages)

[Microwave Oven Whirlpool GT4175SPB2 Parts List](#)

Microwave oven 1.7 cubic foot (6 pages)

[Microwave Oven Whirlpool GT1196SH Use & Care Manual](#)

Whirlpool microwave oven use and care guide gt1195sh, gt1196sh (26 pages)

[Microwave Oven Whirlpool GT1195SH Use & Care Manual](#)

(28 pages)

[Microwave Oven Whirlpool GT 285 BL Instructions For Use Manual](#)

Gusto black microwave oven with crisp function gt 285 bl (9 pages)

[Microwave Oven Whirlpool Jet Crisp GT 288 Instructions For Use Manual](#)

(21 pages)

[Microwave Oven Whirlpool GT 384 Quick Reference Manual](#)

(17 pages)

[Microwave Oven Whirlpool GT 385 Quick Reference Manual](#)

(15 pages)

[Microwave Oven Whirlpool GT 386 MIR Quick Reference Manual](#)

(15 pages)

Summary of Contents for Whirlpool GT4185SKQ2

[Page 1: Table Of Contents](#)

Popcorn chart18 Cooking Guide19 Microwave Oven Care20 Questions and Answers 21 Troubleshooting22 Assistance or Service23 Warranty24 1-800-253-1301 Call our Customer Interaction Center MODEL GT4185SK with questions or comments. www.whirlpool.com 3828W5A1889/8183906...

[Page 2: Anote To You](#)

NOTE TO You The Whirlpool ®Brand is committed to designing quality products that

consistently perform for you to make your life easier. To ensure that you enjoy years of trouble-free operation, we developed this Use and Care Guide. It is full of valuable information about how to operate and maintain your appliance properly. Please read it carefully.

[Page 3: Microwave Oven Safety](#)

MICROWAVE OVEN Your safety and the safety of others are very important. We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages. This is the safety alert symbol. This symbol alerts you to potential hazards that can kill or hurt you and others. All safety messages will follow the safety alert symbol and either the word "DANGER"...

[Page 4](#) **IMPORTANT SAFETY INSTRUCTIONS** • Do not operate any heating or cooking appliance - Remove wire twist-ties from paper or plastic beneath the microwave oven. bags before placing bag in oven. • Do not mount microwave oven over or Rear any - If materials inside the oven should ignite, keep portion of a heating or cooking appliance.

[Page 5: Installation Instructions](#)

INSTALLATION INSTRUCTIONS Before you begin operating the oven, carefully read the following instructions. 1. Empty the microwave oven and clean inside it with a soft, damp cloth. Check for damage such as a door that isn't lined up correctly, damage around the door, or dents inside the oven or on the ®...

[Page 6](#) **GROUNDING INSTRUCTIONS** • For all cord connected appliances: Do not use an extension cord. If the power supply The microwave oven must be grounded. In the cord is too short, have a qualified electrician or event of an electrical short circuit, grounding serviceman install an outlet near the microwave oven.

[Page 7: Getting To Know Your Microwave Oven](#)

GETTING TO KNOW YOUR MICROWAVE OVEN This section discusses the concepts behind microwave cooking. It also shows you the basics you need to know to operate your microwave oven. Please read this information before you use your oven. Using your microwave oven may cause interference to your radio, TV, or similar equipment.

[Page 8: Testing Your Dinnerware Or Cookware](#)

• Never cook or reheat a whole egg inside the shell. Steam buildup in whole eggs may cause them to burst, and possibly damage the oven. Slice hard-boiled eggs before heating.

[Page 9: Microwave Oven Features](#)

FEATURES MICROWAVE OVEN Your microwave oven is designed to make your 5, Removable Turntable Support (under turntable). cooking experience enjoyable and productive. To 6. Control Panel. Touch pads on this panel to help get you up and running quickly, the following perform all functions.

[Page 10: Control Panel Features](#)

Your microwave oven control panel lets you select a desired cooking function quickly and easily. The following is a list of all the Command pads located on the control panel.

[Page 11: Using Options](#)

You can select or change the following functions or displays by touching **OPTIONS**: You can stop the oven during a cycle by opening the door. The oven stops heating and the fan stops, but the light stays on. To restart cooking, close the door and Touch **START**. Weight Change to lbs or kgs. If you do not want to continue cooking: Language

[Page 12: Setting The Clock](#)

When you first plug in your microwave oven, the **The Cooking Rack** (Part No. 8172101) gives you extra display shows " : ". If the electric power ever goes space when cooking at more than one level in your microwave oven.

[Page 13: Microwave Oven Use](#)

MICROWAVE OVEN USE This section gives you instructions for operating each function. Please read these instructions carefully. 1. Put the food in the oven and close the door..... 1. Put your food in the oven and close the 2. Touch COOK TIME. door.

[Page 14: Cooking With More Than One Cook Cycle](#)

NAME WHEN TO USE IT P50 = 50% of full power Medium • Cooking ham, whole poultry, and pot roasts P40 = 40% of full power • Melting chocolate • Heating bread, rolls and pastries P30-DEF = 30% of full Medium-Low, •...

[Page 15: Defrosting Tips](#)

!i i',i iii,,!i:ijZiii iiiii: , • Use small pieces of aluminum foil to shield parts of food such as chicken wings, leg tips, fish tails, or You are probably used to food weights as being in areas that start to get warm. Make sure the foil does pounds and ounces that are fractions of a pound not touch the sides, top, or bottom of the oven.

[Page 16: Using Warm Hold](#)

SENSOR COOKING Your microwave oven has a sensor that detects the humidity released by the food. The amount of humidity detected tells the oven how long to cook or heat your food. The sensor is used by 3 special functions: COOK, REHEAT, and POPCORN.

[Page 17: Cooking Chart](#)

Baked 1to 4 medium, • Pierce eachpotatoseveral timeswitha forkandplace Potatoes about8 to 10oz onthe oventrayaround theedge,at least1 inch(2.5cm) Frozen 1to 4 cups • Remove f rompackage. Place vegetables i n a Vegetables (250mLto 1 L) microwavable container. Cover w ithplasticwrapandvent. •...

[Page 18: Reheating Chart](#)

2. Touch POPCORN. POPCORN lets you pop commercially packaged NOTE: The sensor will determine "popping time," microwave popcorn with just one touch, based on the size of the package, NOTES: • Pop only 1 package at a time, • If you are using a microwave popcorn popper, follow manufacturer's instructions.

[Page 19: Cooking Guide](#)

COOKING GUIDE i i ii ii iii / iiiiiil i,li, iii t iiiii:iiii • If you increase or decrease the amount of food • Several foods (for example: baked potatoes, you prepare, the time it takes to cook that food will sausages, egg yolks, and some fruits) are tightly also change.

[Page 20: Microwave Oven Care](#)

MICROWAVE OVEN CARE To make sure your microwave oven looks good and works well for a long time, should maintain it properly. For proper care, please follow these instructions carefully. Metalcontainers s houldnotbeusedina microwave oven. T here are,however, someexceptions. If you For interior surfaces: Wash often with warm, sudsy havepurchased f oodwhichis prepackaged in an...

[Page 21: Questions And Answers](#)

UESTIONS AND ANSWERS QUESTIONS ANSWERS Can I operate my microwave oven without the No. If you remove or turn over the turntable, you turntable or turn the turntable over to hold a will get poor cooking results. Dishes used in large dish? your oven must fit on the turntable.

[Page 22: Troubleshooting](#)

TROUBLESHOOTING Most cooking problems often are caused by little things you can find and fix without tools of any kind. Check the lists below before calling for assistance or service. If you still need help, see the "Requesting Assistance or Service" section.

[Page 23: Assistance Or Service](#)

United States. Our consultants provide assistance with: To locate the Whirlpool designated service company • Features and specifications on our full line in your area, you can also look in

your telephone or appliances directory Yellow Pages.

[Page 24: Warranty](#)

B. Repairs when your microwave oven is used in other than normal, single-family household use. C. In-home service. Your microwave oven must be taken to a Whirlpool designated service company. D. Damage to your microwave oven caused by accident, alteration, misuse, abuse, fire, flood, acts of God, or use of products not approved by Whirlpool Corporation.

This manual is also suitable for:

[Gt4185skt3Gt4185skq1Gt4185skb1Gt4185sks2Gt4185skt0Gt4185skq3](#) ... [Show all](#)