


Check The Components - Toshiba gigabeat U Series Startup Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40

Table Of Contents

41



•

[Table of Contents](#)

•

Bookmarks



6

Check the components

The following components are included in the gigabeat package.

1

2

About the Software and User's Guide

Under copyright law, the software provided on the CD-ROM and the User's Guide

may not be reproduced, either entirely or in part, in any form, without the prior written

permission of Toshiba.

The enclosed software and User's Guide may be used by the customer on a computer.

Toshiba accepts no liability whatsoever for any harm or damage to the customer or to

any third party arising from the use of the gigabeat with the enclosed software or

User's Guide.

Subject to Change

All product specifications, configurations, prices, system component/options

availability are all subject to change without notice. The gigabeat and computer

screens contained in this Start Up Guide are provided for reference purposes only.

Actual screens may differ from those shown here. Moreover, Toshiba accepts no

responsibility for any errors contained in these descriptions.

1 Earbuds

2 USB cable

3 Software CD-ROM

4 Start Up Guide (this manual)

4

3




Table of Contents

[Previous Page](#)
[Next Page](#)

1
...
3
4
5
6
7
8
9
10

Related Manuals for Toshiba gigabeat U Series

[MP3 Player Toshiba gigabeat Quick Start Manual](#)

Portable media center (140 pages)

[Portable Multimedia Player Toshiba gigabeat T Series User Manual](#)

(138 pages)

[Portable Multimedia Player Toshiba U202-BK User Manual](#)

U202-bk user's guide (135 pages)

[Portable Multimedia Player Toshiba S60 MES-G60 Specifications](#)

Portable media player (2 pages)

Related Products for Toshiba gigabeat U Series

[Toshiba Gigabeat F20](#)

[Toshiba Gigabeat F10](#)

[Toshiba Gigabeat F40](#)

[Toshiba Gigabeat F60](#)

[Toshiba Gigabeat P Series](#)

[Toshiba gigabeat T Series](#)

[Toshiba Gigabeat F Series](#)

[Toshiba Gigabeat F](#)

[Toshiba Gigabeat X](#)

[Toshiba gigabit U Series](#)

[Toshiba GIF200](#)

[Toshiba GSC-R60](#)

[Toshiba GD-1200](#)

[Toshiba Qosmio G20-114](#)

[Toshiba GA-1211-EX](#)

[Toshiba GR-HG615UDZ](#)