



Whirlpool 3389589 Installation Instructions Manual

Large capacity thin twin washer/dryer four-wire 240 volt

1
2
3
4
5
6
7
8
9

--

•

[Table of Contents](#)

•

Bookmarks

--

[Download this manual](#)

Quick Links



IMPORTANT

Installer:

Leave

Installation

Instructions

with the homeowner

Homeowner:

Keep Installation

Instructions

for future reference

Save Installation

Instructions

for local

electrical

inspector's

use.

Part No. 3389589 Rev. B

Large Capacity

Installation




Thin Twin
Washer

Dryer

Four-Wire 240 Volt

Installation



[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool 3389589

[Washer/Dryer Whirlpool 3395326 Installation Instructions Manual](#)

Gas large capacity thin twin washer-dryer - 120 volt (9 pages)

[Washer/Dryer Whirlpool 3396314 Use And Care Manual](#)

Whirlpool washer/dryer 3396314 use and care guide (34 pages)

[Washer/Dryer Whirlpool 3406876 Use & Care Manual](#)

Large capacity automatic gas and electric washer/dryer (18 pages)

[Washer/Dryer Whirlpool 3366869 Use And Care Manual](#)

Whirlpool washer/dryer pair useandcare guide (56 pages)

[Washer/Dryer Whirlpool 3396315 Use And Care Manual](#)

Thin twin automatic washer/dryer (78 pages)

[Washer/Dryer Whirlpool 50 Hz Installation Instructions Manual](#)

Whirlpool thin twin washer dryer 230 volt, 50 hz installation instructions (7 pages)

[Washer/Dryer Whirlpool 3397612 Installation Instructions Manual](#)

Thin twin washer/dryer - 240 volt (9 pages)

[Washer/Dryer Whirlpool 3953953 Use & Care Manual](#)

Two and three speed automatic washers (12 pages)

[Washer/Dryer Whirlpool 3389591 Installation Instructions Manual](#)

Large capacity thin twin washer/dryer four-wire 240 volt (9 pages)

[Washer/Dryer Whirlpool 3397512 Installation Instructions Manual](#)

Thin twin washer-dryer four-wire 240 volt (9 pages)

[Washer/Dryer Whirlpool W10150624A User Instructions](#)

(24 pages)

[Washer/Dryer Whirlpool 3401087 Use And Care Manual](#)

Thin twin automatic washer/dryer (89 pages)

[Washer/Dryer Whirlpool 3397616 Installation Instructions Manual](#)

(10 pages)

[Washer/Dryer Whirlpool 3LTE5243BW0 Use And Care Manual](#)

(78 pages)

[Washer/Dryer Whirlpool AWZ 475 Programme Chart](#)

(2 pages)

[Washer/Dryer Whirlpool FreshCare WFWDC96 User Manual](#)

9-6 kg washer dryer combo (23 pages)

Summary of Contents for Whirlpool 3389589

Page 1 Part No. 3389589 Rev. B Large Capacity Thin Twin Washer Dryer IMPORTANT Four-Wire 240 Volt Installer: Leave Installation Instructions with the homeowner Homeowner: Keep Installation Instructions for future reference. Save Installation Instructions for local electrical inspector's use.

[Page 2: Tools And Materials Needed For Installation](#)

Floor drain system :no h,gher lhon requires cz siphon mnches f'orr f,cor break, Part 285320 ova~lable from Whirlpool If u longer droln hose outhorized parts needed drain hose dlstrlbutor Port No 388423 hose extenslo" Port SEE RECESSED AREA...

[Page 3: Exhaust Requirements](#)

Instructions back cover of Installation A kit, Part No. 687104. IS available proper exhaust Instructions on the rear panel from your Whirlpool dealer. installation. the washer/dryer. NOTE: If local codes require permanently connected wiring, "Alternate electrical connection". Maximum...

[Page 4](#) Now start... with washer/dryer in laundry area Slide nozzle of drain hose through the small Personal Injury Hazard "loop" in the wire More than person is required form Wrap to lift, tilt or move the washer/dryer hook of the because of its weight size.

[Page 5](#) Place hose clamp over washer drain connector Insert corner posts or other type Push coupling of drain hose support 6 inches from left leg. to washer connector. Use pliers If you did not remove Do Not insert corner posts in the open clamp slide clamp...

[Page 6](#) Whirlpool COOL-LINE® Service ~111 answer questions about operating or maintaining your washer/dryer not covered In your Installation Instructions Whirlpool COOL-LINE® Service number is (800) 253-1301 Dial Just as normally dial long distance the call is free Check that have of your...

[Page 7: Alternate Electrical Connection](#)

Alternate electrical When local codes... To convert to a connection three-wire Do Not Permit the use of the flexible four-wire power supply cord that electrical system. comes equipped with washer/ dryer When local codes... Permit four-wire copper power supply Electrical Shock Hazard cable...

[Page 8](#) local codes... When local codes... When local codes... Do Not permit the use of three-wire. Do Not permit use of a flexible. Permit use of a flexible-type flexible power supply cord three-wire, power supply cord power supply cord (pigtail) Permit three-wire.

[Page 9: Recessed And Closet Installation Instructions](#)

24 sq. outdoors. Side View Front View CORPORATION Part No 3389589 Printed in U S A Prepared by Whirlpool Corporation. Benton Harbor, Michigan 49022 © 1990 Whirlpool Corporation...