



# Chapter 3: Using The Remote Control; Installing Batteries - Toshiba 39L2300U User Manual

Integrated high definition led television



1  
2  
3  
4  
5  
6  
7  
8  
9


Table Of Contents

10  
11  
12  
13  
14  
15  
16  
17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123



•

[Table of Contents](#)

•

Troubleshooting



•

## Bookmarks





# Chapter 3

## Using the Remote Control

# Installing batteries

To install batteries :

**1**

Remove the battery cover from the back of the remote control.

Squeeze tab  
and lift cover

*(Sample Illustration) Removing the remote back cover*

**2**

Insert two AAA batteries, corresponding to the (+) and (-) markings on the battery compartment.

*(Sample Illustration) Installing the batteries*

**3**

Replace the battery cover.

**42**

Do not expose batteries to excessive heat such as sunshine, fire, etc.

[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)

1  
...  
39  
40  
41  
42  
43  
44  
45  
46

Quick Links:

[Features](#)

[Overview of Installation, Setup, and Use](#)

[Tv Front and Side Panel Controls...](#)

[Navigating Menu System](#)

## Related Manuals for Toshiba 39L2300U

[LED TV TOSHIBA 50L2300U User Manual](#)

(123 pages)

[LED TV Toshiba 23L2300U Resource Manual](#)

Integrated high definition led television (2 pages)

[LED TV Toshiba 23L1350U Resource Manual](#)

Integrated high definition led television (2 pages)

[LED TV Toshiba 32L2300UM Resource Manual](#)



Integrated high definition led television (2 pages)

[LED TV Toshiba 50L1350U Specifications](#)

50" class led hd tv (2 pages)

[LED TV Toshiba 39L22U User Manual](#)

Integrated high definition led television (131 pages)

[LED TV Toshiba 39L4300UM User Manual](#)

Integrated high definition led television (186 pages)

[LED TV TOSHIBA 65L7300U User Manual](#)

(98 pages)

[LED TV TOSHIBA 65L7300U User Manual](#)

(90 pages)

[LED TV Toshiba 32L4300UC User Manual](#)

Integrated high definition led television (182 pages)

[LED TV Toshiba 23L2300UC Resource Manual](#)

Integrated high definition led television (2 pages)

[LED TV Toshiba Esteem 399 User Manual](#)

Low nox gas fired boiler (48 pages)

[LED TV Toshiba 39L4300 Series Owner's Manual](#)

With android (60 pages)

[LED TV Toshiba 32L3300 Series Owner's Manual](#)

(54 pages)

[LED TV Toshiba 32P2300 Series Owner's Manual](#)

(34 pages)

[LED TV Toshiba 32L310U20 Manual](#)

32" 720p 60hz led tv (65 pages)

## Related Content for Toshiba 39L2300U

[49UL5A63DB Remote Control](#)

Toshiba 49UL5A63DB

[32L1343 DG The Remote Control](#)

Toshiba 32L1343 DG

[58L9300UC Chapter 3: Using The Remote Control](#)

Toshiba 58L9300UC

[40D355 DB Series The Remote Control \(Tv - Dvd\)](#)

Toshiba 40D355 DB Series

[55 XA9D Series Remote Control](#)

Toshiba 55 XA9D Series

[55UK3C63DB Remote Control](#)

Toshiba 55UK3C63DB

[55UA3D63DB Remote Control](#)

Toshiba 55UA3D63DB

[24L3965EA Remote Control](#)

Toshiba 24L3965EA

This manual is also suitable for:

[23|2300u23|2300u129|1350um32|1350u132|2300u132|2300um](#) ... [Show all](#)