

Setting The Timer; How To Set The Present Time; How To Set The Off/On Time; How To Set For Daily On/Off Operation - Sanyo KS0911 Instruction Manual

Split system air conditioner

1	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
Table Of Contents	
16	



-

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



1) How to set the present time



Setting the Timer

(Example) To set to 9:10 p.m.

Operation
1. Press the PROGRAM button three times. The time indication alone flashes.
2. <ul style="list-style-type: none">• Press the HH button until 9 and (PM) are displayed.• Press the MM button until 10 is displayed. The display will automatically

Table of Contents

[Previous Page](#)
[Next Page](#)

1
...
9
10
11
12
13
14
15
16

Quick Links:

[Contents](#)

[Electrical Requirements](#)

[Installation Location](#)

[Names of Parts](#)

[Remote Control Unit](#)

[Care and Cleaning](#)

[Casing and Grille](#)

[Troubleshooting](#)

Related Manuals for Sanyo KS0911

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS2422 Service Manual](#)

Split system air conditioner (51 pages)

[Air Conditioner Sanyo KS1822 Service Manual](#)

Split system air conditioner (41 pages)

[Air Conditioner Sanyo 09KS51 Submittal Sheet](#)

Indoor/outdoor wall mount air conditioner (3 pages)

[Air Conditioner Sanyo KS1251 Instruction Manual](#)

Split system air conditioner (24 pages)

[Air Conditioner Sanyo 09KS71 Submittal Data](#)

Split system indoor/outdoor wall mounted air conditioner (2 pages)

[Air Conditioner Sanyo 12KS71 Dimensional Data](#)

Sanyo air conditioner data sheet (1 page)

[Air Conditioner Sanyo 18KHS72 Specifications](#)

Wall mounted air conditioners & heat pumps 9,000-24,000 btu/h 16-20 seer (2 pages)

[Air Conditioner Sanyo KS1271 Instruction Manual](#)

Inverter-controlled split system air conditioner (50 pages)

[Air Conditioner Sanyo C1271 Technical & Service Manual](#)

Dc inverter split system air conditioner (108 pages)

[Air Conditioner Sanyo KS0971 Technical & Service Manual](#)

Dc inverter split system air conditioner (81 pages)

[Air Conditioner Sanyo 09KLS71 Submittal Data](#)

Split system indoor/outdoor wall mounted low ambient air conditioner (2 pages)

Related Content for Sanyo KS0911

[SPW-CR365GXH56 I Setting The Timer](#)

Sanyo SPW-CR365GXH56

[XS1271 Setting The Timer](#)

Sanyo XS1271

[COOL Setting The Timer](#)

Sanyo COOL

[SAP-KRV96EHDS Setting The Timer](#)

Sanyo SAP-KRV96EHDS

[SAP-KRV96EH Setting The Timer](#)

Sanyo SAP-KRV96EH

[SAP-CRV93EHN Setting The Timer](#)

Sanyo SAP-CRV93EHN

[SAP-KRV94EHDX Setting The Timer](#)

Sanyo SAP-KRV94EHDX

[KS1872 Setting The Timer](#)

Sanyo KS1872

This manual is also suitable for:

[Ks1822Ks1211wKs3622Ks2422Ks3012w](#)