

Installation Location; Electrical Requirements; Safety Instructions - Sanyo KS0911 Instruction Manual

Split system air conditioner

| | |
|-------------------|--|
| 1 | |
| 2 | |
| 3 | |
| 4 | |
| 5 | |
| 6 | |
| 7 | |
| 8 | |
| 9 | |
| 10 | |
| 11 | |
| 12 | |
| 13 | |
| 14 | |
| 15 | |
| Table Of Contents | |
| 16 | |



-

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks





WARNING:



Avoid:

Installation Location

- We recommend that this air conditioner be installed properly by a qualified installation technician with the Installation Instructions provided.
- Before installation, check that the voltage of your home or office is the same as the voltage shown on the nameplate.

- **Do not install this air conditioner where there are flammable gases, or in an extremely humid or dusty house.**
- **Do not install the air conditioner where there are heat-generating objects are places.**
- To protect the air conditioner from heavy corrosion, do not install the outdoor unit where salty sea water can splash.

Table of Contents

[Previous Page](#)
[Next Page](#)

1
2
3
4
5
6
7

Quick Links:

[Contents](#)

[Electrical Requirements](#)

[Installation Location](#)

[Names of Parts](#)

[Remote Control Unit](#)

[Care and Cleaning](#)

[Casing and Grille](#)

[Troubleshooting](#)

Related Manuals for Sanyo KS0911

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS2422 Service Manual](#)

Split system air conditioner (51 pages)

[Air Conditioner Sanyo KS1822 Service Manual](#)

Split system air conditioner (41 pages)

[Air Conditioner Sanyo 09KS51 Submittal Sheet](#)

Indoor/outdoor wall mount air conditioner (3 pages)

[Air Conditioner Sanyo KS1251 Instruction Manual](#)

Split system air conditioner (24 pages)

[Air Conditioner Sanyo 09KS71 Submittal Data](#)

Split system indoor/outdoor wall mounted air conditioner (2 pages)

[Air Conditioner Sanyo 12KS71 Dimensional Data](#)

Sanyo air conditioner data sheet (1 page)

[Air Conditioner Sanyo 18KHS72 Specifications](#)

Wall mounted air conditioners & heat pumps 9,000-24,000 btu/h 16-20 seer (2 pages)

[Air Conditioner Sanyo KS1271 Instruction Manual](#)

Inverter-controlled split system air conditioner (50 pages)

[Air Conditioner Sanyo C1271 Technical & Service Manual](#)

Dc inverter split system air conditioner (108 pages)

[Air Conditioner Sanyo KS0971 Technical & Service Manual](#)

Dc inverter split system air conditioner (81 pages)

[Air Conditioner Sanyo 09KLS71 Submittal Data](#)

Split system indoor/outdoor wall mounted low ambient air conditioner (2 pages)

Related Content for Sanyo KS0911

[SAP-K91AA Installation Location](#)

Sanyo SAP-K91AA

[SAP-FDRV96EH Installation Location](#)

Sanyo SAP-FDRV96EH

[SAP-K77GHAX Installation Location](#)

Sanyo SAP-K77GHAX

[SAP-K71GJA Installation Location](#)

Sanyo SAP-K71GJA

[SAP-K161GJA Installation Location](#)

Sanyo SAP-K161GJA

[KS2432 Installation Location](#)

Sanyo KS2432

[SAP-KMV91G-S Installation Location](#)

Sanyo SAP-KMV91G-S

[SAP-K91A Installation Location](#)

Sanyo SAP-K91A

This manual is also suitable for:

[Ks1822Ks1211wKs3622Ks2422Ks3012w](#)