

Using The Remote Control Unit; How To Install Batteries; How To Use The Remote Control Unit; Remote Control Unit Installation Position - Sanyo KS0911 Instruction Manual

Split system air conditioner

1	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
Table Of Contents	
16	



-

[Table of Contents](#)

-

Troubleshooting


•

Bookmarks



How to Install Batteries

Slide to open →



Using the Remote Co

1. Press and slide the lid on the back of the remote control in the direction of the arrow.
2. Install two AAA alkaline batteries. Make sure they are inserted in the direction marked in the battery compartment.
3. Press the ACL button, then replace the lid. The ON time, OFF time, and OFF time are all reset to their default values. (See "S

Table of Contents

[Previous Page](#)
[Next Page](#)

1
...
5
6
7
8
9
10
11
12

Quick Links:

[Contents](#)

[Electrical Requirements](#)

[Installation Location](#)

[Names of Parts](#)

[Remote Control Unit](#)

[Care and Cleaning](#)

[Casing and Grille](#)

[Troubleshooting](#)

Related Manuals for Sanyo KS0911

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS0911 Instruction Manual](#)

Split system air conditioner (15 pages)

[Air Conditioner Sanyo KS2422 Service Manual](#)

Split system air conditioner (51 pages)

[Air Conditioner Sanyo KS1822 Service Manual](#)

Split system air conditioner (41 pages)

[Air Conditioner Sanyo 09KS51 Submittal Sheet](#)

Indoor/outdoor wall mount air conditioner (3 pages)

[Air Conditioner Sanyo KS1251 Instruction Manual](#)

Split system air conditioner (24 pages)

[Air Conditioner Sanyo KS1271 Instruction Manual](#)

Inverter-controlled split system air conditioner (50 pages)

[Air Conditioner Sanyo C1271 Technical & Service Manual](#)

Dc inverter split system air conditioner (108 pages)

[Air Conditioner Sanyo KS0971 Technical & Service Manual](#)

Dc inverter split system air conditioner (81 pages)

[Air Conditioner Sanyo 09KLS71 Submittal Data](#)

Split system indoor/outdoor wall mounted low ambient air conditioner (2 pages)

[Air Conditioner Sanyo 09KS71 Submittal Data](#)

Split system indoor/outdoor wall mounted air conditioner (2 pages)

[Air Conditioner Sanyo 12KS71 Dimensional Data](#)

Sanyo air conditioner data sheet (1 page)

[Air Conditioner Sanyo 18KHS72 Specifications](#)

Wall mounted air conditioners & heat pumps 9,000-24,000 btu/h 16-20 seer (2 pages)

Related Content for Sanyo KS0911

[MINI ECO-i XHX1252 Using The Wireless Remote Control Unit](#)

Sanyo MINI ECO-i XHX1252

[SAP-C302AH-S Remote Control Unit Installation Position](#)

Sanyo SAP-C302AH-S

[C2432A How To Install The Remote Control Unit](#)

Sanyo C2432A

[SAP-KM97GHS5A Remote Control Unit Installation Position](#)

Sanyo SAP-KM97GHS5A

[SAP-K91AA Changing Address Of Remote Control Unit In Indoor Unit](#)

Sanyo SAP-K91AA

[SAP-K92A Changing Address Of Remote Control Unit In Indoor Unit](#)

Sanyo SAP-K92A

[SAP-K91AA-S Changing Address Of Remote Control Unit In Indoor Unit](#)

Sanyo SAP-K91AA-S

[SAP-FDRV96EH Using The Remote Control Unit](#)

Sanyo SAP-FDRV96EH

This manual is also suitable for:

[Ks1822Ks1211wKs3622Ks2422Ks3012w](#)