



# Outdoor Unit Control Panel Led Display - Sanyo CHDXR09663\* Service Manual

2-way eco-i multi system



1

2

3

Table Of Contents

4

5

6

7

8

9

10

11

12

13

14

15


16

17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142



•

[Table of Contents](#)



•

## Bookmarks





## 2. Outdoor Unit Control Panel LED Display

### LED (RED)

1

2

(Both ON)

(OFF)

(ON)

(Both OFF)

(Blinking alternately)

(Both blinking)

(Blinking alternately)



|   |   |  |
|---|---|--|
|   |   |  |
|   |   |  |
| ○ | ○ |  |
| ● | ○ |  |

After the power is turned ON (and automatic address setting is not in progress), no communication with the indoor units in that system is possible.

After power is turned ON (and automatic address setting is not in progress), one or more indoor

units are confirmed in that system; however, the number of indoor units does not match the number that was set.

Automatic address setting was completed successfully. (After the power is turned ON, and automatic address setting is not in progress, the number of detected indoor units connected to that system matches the number that was set, and regular communications are occurring.)

Automatic address setting is in progress.

At time of automatic address setting, the number of indoor units did not match the number that was set.



Alarm display

LED 1 blinks M times, then LED 2 blinks N times. The cycle then repeats.

M = 2: P alarm 3: H alarm 4: E alarm 5: F alarm 6: L alarm

N = Alarm No.

Example: LED 1 blinks 2 times, then LED 2 blinks 7 times. The cycle then repeats.

Alarm is "P17."

(

: ON

**Display meaning**

5 - 4

W-2WAY ECO-i SYSTEM

*Trouble Diagnosis*

: Blinking

: OFF)

|  |       |  |
|--|-------|--|
|  |       |  |
|  |       |  |
|  | ----- |  |
|  |       |  |
|  | ----- |  |
|  |       |  |
|  | ----- |  |
|  |       |  |
|  | ----- |  |
|  |       |  |
|  | ----- |  |

[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)

1

...

112

113

114

115

Quick Links:

[Outdoor Unit Control Panel Led Display](#)

## Related Manuals for Sanyo CHDXR09663\*

[Air Conditioner Sanyo XM18AAB Installation Instructions Manual](#)

W-2way system air conditioner (50 pages)

[Air Conditioner Sanyo ECO-i AHX0752 Technical Data Manual](#)

(265 pages)

[Air Conditioner Sanyo MINI ECO-i XHX1252 Service Manual & Test Run Service Manual](#)

(190 pages)



[Air Conditioner Sanyo ECO-i CHDZR07263 Series Service Manual](#)

(146 pages)

[Air Conditioner Sanyo CHDZ07263 Service Manual](#)

(128 pages)

[Air Conditioner Sanyo AHX0752 Service Manual](#)

W-2way eco-i multi system (114 pages)

[Air Conditioner Sanyo W-3WAY ECO-i 85464369098000 Installation Instructions Manual](#)

W-3way eco-i system air conditioner (106 pages)

[Air Conditioner Sanyo 85464359982001 Installation Instructions Manual](#)

W-2way system air conditioner (96 pages)

[Air Conditioner Sanyo Mini ECO-i CHXR03652 Service Manual](#)

(93 pages)

[Air Conditioner Sanyo Mini ECO-i 85464359981002 Installation Instructions Manual](#)

Sanyo air conditioner installation instructions (90 pages)

[Air Conditioner Sanyo R410A Installation Instructions Manual](#)

W-3way eco-i system air conditioner (54 pages)

[Air Conditioner Sanyo ECO R410A Installation Instructions Manual](#)

Eco-i system air conditioner (48 pages)

[Air Conditioner Sanyo XHX1252 Instruction Manual](#)

Split system air conditioner (20 pages)

[Air Conditioner Sanyo THX2452 User Manual](#)

(4 pages)

[Air Conditioner Sanyo DHX4852 Manual](#)

Indoor unit (4 pages)

[Air Conditioner Sanyo THX1852 Manual](#)

Indoor unit (4 pages)

## Related Content for Sanyo CHDXR09663\*

[MINI ECO-i SPW-CR365GXH56B Outdoor Unit Control Pcb](#)

Sanyo MINI ECO-i SPW-CR365GXH56B

[SPW-D253GH56 Led Indication On The Outdoor Unit's P.c.b. Ass'y](#)

Sanyo SPW-D253GH56

[SPW-XR253GH56 Led Indication On The Outdoor Unit's P.c.b. Ass'y](#)

Sanyo SPW-XR253GH56

[ECO-i 3-WAY MULTI SYSTEM Outdoor Unit Electronic Control Valves \[Mov1, Mov2, Mov3, Mov4\]](#)

Sanyo ECO-i 3-WAY MULTI SYSTEM

[SPW-CR1503GDYH8 Inter-Outdoor Unit Oil Recovery Control](#)

Sanyo SPW-CR1503GDYH8

[SAP-K91AHA Remote Control Unit \(Display\)](#)

Sanyo SAP-K91AHA

[SPW-C256VH Contents Of Led Display On The Outdoor Unit Control](#)

[Pcb](#)

Sanyo SPW-C256VH

[SPW-C0705DZH8 Outdoor Unit Control Pcb](#)

Sanyo SPW-C0705DZH8

This manual is also suitable for:

[Chdx09663Chdxr07263Chdx07263Uhx0762Ahx0752Uhx0962](#) ... [Show all](#)