





Whirlpool 1188927 Use And Care Manual



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

|  |  |
|--|--|
|  |  |
|--|--|

-

•

Bookmarks

|  |
|--|
|  |
|--|

Available languages

EN

ES

## Quick Links

[Download this manual](#)



# DEHUMIDIFIER

For questions  
about  
features,  
operation/performance,  
parts,  
accessories  
or service call; 1-800-253-1301  
or visit our website at... [www.whirlpool.com](http://www.whirlpool.com)  
In Canada, call for assistance,  
installation  
and service,  
call: 1-800-807-6777  
or visit our website  
at... [www.whirlpool.ca](http://www.whirlpool.ca)

# DESHUMIDIFICADOR

Si tiene preguntas  
respecto a las características,  
funcionamiento,  
rendimiento,  
partes,  
accesorios



o servicio tecnico,  
llame al: 1-800-253-1301  
o visite nuestro sito web en... www.whirlpool.com

Table of Contents/Indice

2  
1188927



[Table of Contents](#)

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Whirlpool 1188927

### [Dehumidifier Whirlpool 1185020 Use And Care Manual](#)

Whirlpool dehumidifier 1185020 use & care guide (24 pages)

### [Dehumidifier Whirlpool 1182182 Use And Care Manual](#)

Whirlpool dehumidifier 1182182 use & care guide (24 pages)

### [Dehumidifier Whirlpool AD25BBK0 Use And Care Manual](#)

Whirlpool dehumidifier use & care guide (24 pages)

### [Dehumidifier Whirlpool AD35DSS0 Use And Care Manual](#)

Whirlpool dehumidifier use and care guide (16 pages)

### [Dehumidifier Whirlpool 1187984 Use And Care Manual](#)

Whirlpool dehumidifier use & care guide (16 pages)

### [Dehumidifier WHIRLPOOL 1184914-W Warranty](#)

(1 page)

### [Dehumidifier Whirlpool 1ADM202XX0 Use And Care Manual](#)

Whirlpool dehumidifier use & care guide (13 pages)

### [Dehumidifier Whirlpool Dehumidifier Use & Care Manual](#)

Dehumidifier (22 pages)

### [Dehumidifier Whirlpool AD50GUSB Use & Care Manual](#)

(22 pages)

### [Dehumidifier Whirlpool WDH70EAPW Use & Care Manual](#)

(15 pages)

### [Dehumidifier Whirlpool Dehumidifier Use & Care Manual](#)

Whirlpool dehumidifier user manual (12 pages)

### [Dehumidifier Whirlpool AD25G0 Use & Care Manual](#)

(12 pages)

### [Dehumidifier Whirlpool WHAD703PAW Use And Care Manual](#)

(36 pages)

### [Dehumidifier Whirlpool WHAD703AW Use And Care Manual](#)

(40 pages)

### [Dehumidifier Whirlpool AD050 Use And Care Manual](#)

(15 pages)

### [Dehumidifier Whirlpool SS226 Owner's Instruction Manual](#)

Ionizer dehumidifier (13 pages)

## Summary of Contents for Whirlpool 1188927

**Page 1** In Canada, call for assistance, installation and service, call: 1-800-807-6777 or visit our website at [www.whirlpool.ca](http://www.whirlpool.ca) DESHUIVHDIFICADOR Si tiene preguntas respecto a las características, funcionamiento, rendimiento, partes, accesorios o servicio técnico, llame al: 1-800-253-1301 o visite nuestro sitio web en... [www.whirlpool.com](http://www.whirlpool.com) Table of Contents/Indice .....1188927...

**Page 2** TABLE OF CONTENTS DEHUMIDIFIER SAFETY ..... Normal Sounds  
.....INSTALLATION REQUIREMENTS .....DEHUMIDIFIER CARE .....Electrical  
Requirements ..... Cleaning the Air Filter (on some models) .....7 Cleaning the  
Dehumidifier .....Location Requirements .....TROUBLESHOOTING  
.....DEHUMIDIFIER USE .....ASSISTANCE OR SERVICE .....Setting the Controls

(Control Types 1 and 2 Only) .....

### [Page 3: Installation Requirements](#)

**INSTALLATION REQUIREMENTS** Electrical Shock Hazard Plug into a grounded 3 prong outlet. Do not remove ground prong. Do not use an adapter. Do not use an extension cord. A. Allow at least 12" to 18" (30.5 to 45.7 cm) of air space. Failure to follow these instructions can result in death, fire, or electrical shock.

[Page 4](#) **DEHUMIDIFIER USE** ..Starting/Stopping the Dehumidifier **NOTE:** Before turning on the dehumidifier, be sure that the bucket is empty and fits all the way into the dehumidifier. **Control Type 1 NOTES:** • Minimum operating temperature is 65°F (18°C) for model Electrical Shock Hazard AD25B.

[Page 5](#) **Starting/Stopping the Dehumidifier** **NOTES:** • Before turning on the dehumidifier, be sure that the bucket is empty and fits all the way into the dehumidifier. • Each time you unplug the dehumidifier or power is interrupted, the control will return to your previous settings when power is restored.

[Page 6](#) **Max Dry--Will operate the dehumidifier at the selected fan speed until the humidity levels are lowered to the Desired Humidity maximum level.** 1. Press **DESIRED HUMIDITY** to select the desired humidity **Continuous Run--Will operate the dehumidifier setting.** continuously at the selected fan speed regardless of humidity level.

[Page 7](#) 4. Place the other end of garden hose into a floor drain. Check to see that the hose lies flat and is in the drain. Option 2-- Connect Drain Hose 5. Reinstall bucket. If you plan to run your dehumidifier continuously, you may want to attach a garden hose to the drain hose connector.

[Page 8](#) **DEHUMIDIFIER CARE** Your new dehumidifier is designed to give you many years of dependable service. This section tells you how to clean and care for your dehumidifier. Call your local authorized dealer for an annual cleaning of the dehumidifier. The air filter is removable for easy cleaning. A clean filter helps Pull bottom edge of air filter toward you to clear the bottom of the dehumidifier.

[Page 9](#) **TROUBLESHOOTING** Before calling for service, try the suggestions below to see whether you can solve your problem without outside help. Dehumidifier will not run Ice forms on coils • Is the dehumidifier turned on? Turn on dehumidifier. Model AD25B dehumidifiers do not have an automatic deicer.

[Page 10](#) For further assistance • Features and specifications on our full line of appliances. If you need further assistance, you can write to Whirlpool • Installation information. Corporation with any questions or concerns at: • Use and maintenance procedures.

[Page 11](#) Please record the model and serial number information below. Please record your model's information. Also, record the purchase date of your appliance and the store's Whenever you call to request service on your appliance, you name, address, and telephone number. need to know your complete model number and serial number.

### [Page 12: Seguridad Del Deshumidificador](#)

**SEGURIDAD DEL DESHUMIDIFICADOR** Su seguridad y la seguridad de los demás es muy importante. Hemos incluido muchos mensajes importantes de seguridad en este manual y en su electrodoméstico. Lea y obedezca siempre todos los mensajes de seguridad. Este símbolo le llama la atención sobre peligros potenciales que pueden ocasionar la muerte o una lesión a usted y a los demás.

### [Page 13: Requisitos Electricos](#)

**REQUISITOS DE INSTALACION** Peligro de Choque Eléctrico Conecte a un contacto de pared de conexión a tierra de 3 terminales. No quite la terminal de conexión a tierra. No use un adaptador. No use un cable eléctrico de extensión. A.

### [Page 14: Como Usar El Deshumidificador](#)

**COMO USAR EL DESHUMIDIFICADOR** it\_) l,p;\_Y \_' \_ft<\_'©S ....O \_'':,,B / , s ,} Encender/Apagar el deshumidificador **NOTA:** Antes de encender el deshumidificador, asegúrese de que el balde este vacío y debidamente insertado en el deshumidificador. **Control tipo 1 NOTAS:** •

Temperatura mínima de funcionamiento 65°F (18°C) para el Peligro de Cheque Eléctrico...

[Page 15](#) NOTAS: Dryness Control (Control de sequedad) • Para los primeros días de uso, gire el DRYNESS CONTROL (Control de sequedad) en la dirección de las manecillas del El Dryness Control (Control de sequedad) controla la cantidad de reloj hasta CONTINUOUS RUN (Funcionamiento continuo) humedad en la habitación.

[Page 16](#) Velocidad de ventilación Humedad deseada (Sblo paramodelos con control tipo 3) Oprima DESIRED HUMIDITY (Humedad deseada) para Oprima FAN (ventilación) para seleccionar la velocidad de seleccionar el ajuste de humedad deseado. ventilación. Elija Normal, Dry (seco), Max Dry (máxima sequedad) o Seleccione Low (bajo), High (alto) o Auto (automático).

[Page 17](#) Quite el balde. 3. Vierta el agua a través de la abertura en un fregadero o tina. Conecte una manguera de jardín al conector de la manguera de desagüe en la parte interior del deshumidificador. Apriete con la mano. Vuelva a colocar el balde. IMPORTANTE: Si la luz de Empty/Adjust Bucket (Vacío/Ajuste)...

[Page 18](#) CUIDADO DEL DESHUMIDIFICADOR Su nuevo deshumidificador está diseñado para darle muchos años de servicio confiable. Esta sección le ofrece la información acerca de la limpieza y el cuidado de su deshumidificador. Llame al vendedor autorizado de su localidad para una limpieza anual del deshumidificador.

[Page 19](#) SOLUCIÓN DE PROBLEMAS Antes de solicitar servicio, pruebe las sugerencias que se incluyen a continuación para ver si puede resolver el problema sin ayuda. El deshumidificador no funciona Se forma hielo en los serpentines Los deshumidificadores de modelo AD25B no tienen un •...

## [Page 20: In Canada](#)

Whirlpool más cercano a su localidad. Por favor anote la información sobre su modelo. Llame al Centre para la experiencia del cliente de Whirlpool sin costo alguno al: 1-800-253-1301 o visite nuestro sitio web en Siempre que llame para solicitar servicio del aparato, necesitará [www.whirlpool.com](http://www.whirlpool.com).