

Toshiba DMF102XKU Setup Manual

Digital media frame

19 Table Of Contents 20

ć

.

Table of Contents

Bookmarks


•

Quick Links Download this manual See also: Owner's Manual




TO STOPS HIBA

Leadingeladingtimnovation >>>



INCLUDED I






Digital Media Frame

□ Stand



Coin-shaped battery





LCD Screen f) Remote Control OSHIBA Sensor @ Leading Innovation >>>> Touch Control	INCLUDED I
Keys O Stand Digital Media Frame f) Speakers DMF102XKU @ Rubber Supporter DMF82XKU	Digital Media Frame Stand
Touch Control Key 582XWU Rear View 2000 -ttCt MACK -tt&.'t SETUP GUIDE	Coin-shaped battery (CR2025) is already inserted.
O MODE i) MENU @ ~ O ENTER For more detailed instructions, please refer to O ENTER For more detailed instructions, please refer to O BACK frame.com/ownermanual. If you an tiseling ~ download the Owner's Manual, call 1-800-631- • The funt@ibhfkegesidtance. light up when touched.	Remote Control (SE-R0351) AC Ada Important important s and disclair before usin Important s
O Stand f) Speakers	
Wall-Mounting Holes O Rubber Supporter	

Next Page

Related Manuals for Toshiba DMF102XKU

MP3 Player Toshiba DMF82XKU Owner's Manual Dmf82xku user's guide (78 pages) Digital Photo Frame Toshiba DMF102XKU Owner's Manual Digital media frame (18 pages) Digital Photo Frame Toshiba DMF102XKU Specifications Toshiba digital media frame product brochure (2 pages) Digital Photo Frame Toshiba DMF82XKU Specification Sheet Toshiba digital media frame specification sheet (2 pages) Digital Photo Frame Toshiba DMF82XWU Specifications Toshiba digital media frame product brochure (2 pages) Digital Photo Frame Toshiba Gigaframe L80 User Manual (870 pages) **Digital Photo Frame Toshiba GIGAFRAME Q81 Specifications** Toshiba digital photo frame user manual (2 pages) Digital Photo Frame Toshiba AR100 User's Information Manual (310 pages) Digital Photo Frame Toshiba GIGAFRAME L80 Specifications Toshiba digital photo frame user manual (2 pages) **Digital Photo Frame Toshiba JOURNE F700 Specifications** Toshiba digital photo frame user manual (2 pages)

Summary of Contents for Toshiba DMF102XKU

<u>Page 1</u> Please read the booklet For more detailed instructions, please refer to before using the Digital Media Frame. the Owner's Manual. The Owner's Manual can be downloaded from the website at www.toshiba- Important Information frame.com/ownermanual. If you are unable to download the Owner's Manual, call 1-800-631- 3811 for assistance.

Page 2 DIGITAL MEDIA FRAME OVERVIEW (CONT.) Side View Remote Control Power Button SD/MMC/xD Card Slot MS/MS Duo Card Slot 0 - - WPS Button pROTATE ZOOM IN C> Headphone Jack ON/STANDBY MENU SLIDESHOW .T~~ (I!) PC Port e~ CLOCK/CALENDAR (USB Mini-B) mMODE o cm.

Page 3: Viewing Photos

VIEWING PHOTOS Insert a memory card or connect a USB memory device (e.g. USB To View a Photo Slideshow thumb drive, digital camera [with USB mass storage function] or USB card reader). (Digital Media Frame supports the USB mass Press SLiDESHOW to display a slideshow.

Page 4: Connecting To Online Services

3 Press ..to go through the secondary menus to make your selections. \bullet Viewing Settings \bullet Device Settings For more details on each selection, download the full owner's manual for this product at www.toshibaframe. com/ownermanual. © Toshiba Corporation Printed in China PIN 7525000040A...

Page 5 TOSHIBA >> Leading Innovation Digital Media FraIne DMF102XKU DMF82XKU DMF82XKU IMPORTANT INFORMATION This document contains important information and should be read before using your Toshiba Digital Media Frame. © 2009 Toshiba Corporation...

Page 6: Safety Precautions

Operation with non-compliant 4. Follow all instructions. peripherals or peripherals not recommended by Toshiba is likely to result in interference 5. Do not use this apparatus near water. to radio and TV reception. Shielded cables 6. Clean only with dry cloth.

Page 7 For details on repair, apparatus and/or around it. consult Toshiba Customer Service. 16. Do not place a vessel containing liquid 24. Coin-shaped Battery (such as a vase), or a metal object on top a) CAUTION: Danger of explosion if battery of the apparatus.

Page 8: Notes On Handling

....•...............................f) Do not leave a dead or exhausted battery in The radio waves generated by the product the remote control. may negatively affect equipment, causing malfunction and eventual accident. For g) If you do not use the remote control for details, follow the instructions given by each a long period of time, remove the battery to airline.

Page 9: Notes And Information

..•.....•....•...•... IMPORTANT INFORMATION • When cleaning the LCD screen, use a soft, dry cloth. NOTES AND INFORMATION NOTES ON MOISTURE CONDENSATION TRADEMARKS Moisture condensation damages the • FrameChannel® is a registered trademark digital media frame. Please read the of Frame Media, Inc. following carefully.

Page 10: Wireless Lan Information

.....Because Wireless LAN products operate within the guidelines found in radio frequency WIRELESS LAN safety standards and recommendations, TOSHIBA believes Wireless LAN is safe for INFORMATION use by consumers. These standards and recommendations reflect the consensus Wireless Interoperability of the scientific community and result from...

<u>Page 11</u> Such services are provided by third parties, and the availability, functionality, and/or content thereof may be changed, removed, discontinued, interrupted, restricted, or disabled at any time. Toshiba makes no warranties, representations, or assur- ances about the content, availability or functionality of third-party services. Without...

Page 12: Limited Warranty

CONSUMER PURCHASER AND TO NO www. or register your DAV Product on-line at OTHER PURCHASER OR TRANSFEREE. tacp.toshiba.com/service as soon as possible. DAV PRODUCTS PURCHASED IN THE By registering your DAV Product you will U.S.A. AND USED ANYWHERE OUTSIDE enable TACP to bring you new products OF THE U.S.A., INCLUDING, WITHOUT...

Page 13 TACP Warranty Exchange Center. limitation does not apply to implied warranties arising under state law. For additional information, visit TACP's website:www.tacp.toshiba.com. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH MAY VARY FROM STATE TO STATE IN THE U.S.A.

<u>Page 14</u> TOSHIBA the use of or inability to use such software or a third party. The TOSHIBA Digital Media components. The same applies even when Frame uses software components that are...

Page 15 TOSHIBA Printed in China PIN 7525000035A...

Page 16 We are available to answer all of your questions Monday - Friday 10:00am to 7:00pm EST Many questions regarding parts, service and warranties can be answered by visiting the Customer Support section of our website: www.tacp.toshiba.com THANK YOU TOSHIBA >>...

Page 17 Area Code Area Code Month Year IMPORTANT! To ensure your enrollment in Toshiba's Consumer Information Program, write the complete model number of the product you purchased in the space below, Model Number Serial Number Price paid (excluding tax) \$ L L . . . I .. I .. . O O §...

Page 18: Product Registration Card

See details inside... you have comments or suggestions about our product, please write to: Toshiba America Consumer Products, L.L.C. » 82 Totowa Road » Wayne, NJ 07470 Copyright 2004 All Rights Reserved Please seal with tape. Do not staple.

Page 19 Please send products and other correspondence to: First Class Toshiba America Consumer Products, L.L.C. Postage 82 Totowa Road Required Wayne, NJ 07470 Post Office will not deliver without proper postage. Toshiba America Consumer Products, L.L.C. P.O. Box 174007 Denver, CO 80217-4007...

This manual is also suitable for:

Dmf82xkuDmf82xwu