



# Aux; Sleep - Toshiba HD-S25 Owner's Manual

Digital high definition receiver



1

2

3

4

Table Of Contents

5

6

7

8

9

10

11

12

13


14

15

16

17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56



•

[Table of Contents](#)

•

Troubleshooting

•

## Bookmarks







## AUX

If your TV only has only one set of Component Video inputs, this AUX feature allows you to play your

### AUX

DVD movies via the "AUX INPUT" connectors located at the back of the HD-S25 receiver. (For connections to DVD player and TV, please refer to CONNECTION TO DVD PLAYER on page 16)

(a) When the HD-S25 receiver is in ON mode, connections to DVD player and TV, please refer to CONNECTION TO DVD P

Press "AUX" button on the remote control, the HD-S25 receiver displays the DVD program and the orange LED indicator (refer to page 7) is turned on

Pressing "AUX" button again, make the HD-S25 receiver displays off

orange LED indicator (refer to page 7) is turned off.

Notes

Notes



90 min  
120 min  
120 min  
43

## AUX

[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)

1  
...  
40  
41  
42  
43  
44  
45  
46  
47

## Related Manuals for Toshiba HD-S25

[TV Receiver Toshiba HDR5010KB Quick Start Manual](#)

Digital tv recorder (2 pages)

[TV Receiver Toshiba DST-3000 Owner's Manual](#)

Toshiba dst-3000: user guide (96 pages)

[TV Receiver Toshiba DST-3100 Owner's Manual](#)

Directv high-definition receiver/hdtv tuner (96 pages)

[TV Receiver Toshiba DST-3000 Owner's Manual](#)

High definition digital receiver (98 pages)

[TV Receiver Toshiba Solid State Service Manual](#)

25"/29"/34"/38" solid state color television receiver (19 pages)

## Related Content for Toshiba HD-S25

[DST-3000 Controlling Other Components Using The Aux Button](#)

Toshiba DST-3000