



Asus security system User Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18


19
20
21
22
23
24
25
26

•

Bookmarks

[Download this manual](#)

Quick Links



Asus Security System BASIC USER GUIDE

Store Business Management Dept.

th

18

March 2013

ManualsLib.com

ASUS

Inspiring Innovation • Persistent Performance

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus security system

[Security System Asus HG100 Quick Start Manual](#)

(17 pages)

[Security System Asus AS101 User Manual](#)

(116 pages)

Summary of Contents for Asus security system

[Page 1](#) Asus Security System BASIC USER GUIDE Store Business Management Dept. March 2013...

[Page 2](#) Introduction • This security system kit contains all the materials needed to build an anti-theft/anti-lost system for a product displayed in an exhibition or retail store. • The security system prevents a product from being lost or stolen by triggering...

[Page 3](#) 1 PORT SECURITY ALARM...

[Page 4](#) 1 PORT - 1 SYSTEM TO 1 DEVICE A Control box B Instruction manual C Tablet cradle assy. set D AC adaptor set E 4.5 X 12mm screw(2EA) G Phillips-head screwdriver H Velcro cable ties (1Set) I Sensor cap (5set)

[Page 5](#) DETAILS OF THE 1 PORT CONTROL BOX 1 Speaker 6 LED Lamp Removes all the pairing settings between the control box When the power switch is on, the red light turns on and DC and the remote control. power is supplied. 2 USB Ports 7 Area for Double-sided Tape Ports for plugging in the USB connectors of the charging &...

[Page 6](#) 1 PORT DETAIL INSTALLATION PROCEDURE STEP 1 For the final installation, determine where the control box will be located. And then, Lock the control box on the determined location with two screws (4.5mmx12mm, You need to prepare a Phillips screwdriver). STEP 2 Plug the USB connectors of the Charging &...

[Page 7](#) 1 PORT DETAIL INSTALLATION PROCEDURE STEP 3 Plug the power tip of AC adaptor to the power-in port of the controller, and plug the AC adaptor to an AC outlet. (AC 110~220V, Please use the attached plug gender for 110V) STEP 4 Turn the power switch on, and check the LED light If the volume dial is at the end in a counter-...

[Page 8](#) 1 PORT DETAIL INSTALLATION PROCEDURE STEP 5 Plug the USB connectors of the Charging & security cables into the USB ports of the controller. STEP 6 For testing of the connection between the security sensor and tablet device, please unplug the USB connector from the USB port.

[Page 9](#) 1 PORT DETAIL INSTALLATION PROCEDURE STEP 9 If it rings the alarm sound, the connection is successful. Otherwise, please check the connection, and rework the chapter, "CONNECTING THE CHARGING & SECURITY CABLE" of this installation instructions. STEP 10 If the test is successful, turn off the power and unplug all the cables from the controller.

[Page 10](#) 5 PORT SECURITY ALARM...

[Page 11](#) 5 PORT - 1 SYSTEM TO 5 DEVICE A Control box B Instruction manual C Tablet cradle assy. set (5Set) D AC adaptor set E 4.5 X 12mm screw(2EA) F Velcro cable ties G Charging & security cable (5set) H Phillips-head screwdriver I Remote control set J Sensor cap (5set)

[Page 12](#) Port for plugging in the mini USB connector of the IR sensor. control Instruction manual 8 USB Ports 3 Speaker Ports for plugging in the USB connectors of the charging &

Sounds the alarm when the security system is tampered security cable. with. 9 Power-in Port 4 LED Lamp Port for plugging in the power tip of the AC Adaptor .

[Page 13](#) DETAILS OF THE REMOTE CONTROL - 5 PORT 1 LED indicator The LED light blinks when the pairing setup is in progress, and goes off when the pairing setup finishes. 2 Alarm off button Turns off the alarm sound of the control box. 3 LED off button Turns off the LED light of the security sensor of the charging &...

[Page 14](#) 5 PORT - OVERVIEW OF INSTALLATION PROCEDURE STEP 1 Mounting the IR sensor STEP 2 Assembling & mounting the cradle STEP 3 Connecting the charging & security cable...

[Page 15](#) 5 PORT - OVERVIEW OF INSTALLATION PROCEDURE STEP 4 Installing the control box STEP 5 Setting up the pairing with the remote control STEP 6 Testing the pairing and sensor connection COMPLETE...

[Page 16](#) 5 PORT DETAIL INSTALLATION PROCEDURE STEP 1 - MOUNTING THE IR SENSOR Determine where the IR sensor will be mounted on the table, and clean the determined surface thoroughly with a glass cleaner and a clean towel. Peel off the protective film of the adhesive tape underneath the sensor.

[Page 17: Step 2 - Assembling The Cradle](#)

5 PORT DETAIL INSTALLATION PROCEDURE STEP 2 - ASSEMBLING THE CRADLE Position guide label In order to make the assembling works more easier, place the bottom of cradle facing up wards. Match the position guide label on the middle of the cradle, and push the charging &...

[Page 18: Step 2 - Mounting The Cradle](#)

5 PORT DETAIL INSTALLATION PROCEDURE STEP 2 - MOUNTING THE CRADLE Determine where the cradle will be mounted on the table, and clean the determined surface thoroughly with a glass cleaner and a clean towel. Peel off all the protective films of the adhesive tapes underneath the cradle.

[Page 19](#) 5 PORT DETAIL INSTALLATION PROCEDURE STEP 3 - CONNECTING THE CHARGING & SECURITY CABLE Plug the charging & security connector to the charging port of tablet device. ※ The position of the charging port may vary depending on the product. Remove the dust or contaminants on sensor attachment location and stick the security-sensor after peel off the protecting film.

[Page 20](#) 5 PORT DETAIL INSTALLATION PROCEDURE STEP 3 - CONNECTING THE CHARGING & SECURITY CABLE Plug the charging & security connector to the charging port of tablet device. ※ The position of the charging port may vary depending on the product. Remove the dust or contaminants on sensor attachment location and stick the security-sensor after peel off the protecting film.

[Page 21](#) 5 PORT DETAIL INSTALLATION PROCEDURE STEP 4 - CONNECTING THE CHARGING & SECURITY CABLE For the final installation, determine where the control box will be located, then lock the control box onto the determined location with two screws (4.5x12 mm; prepare a "+"...

[Page 22](#) 5 PORT DETAIL INSTALLATION PROCEDURE STEP 5 - SETTING-UP THE PAIRING WITH REMOTE CONTROL Turn on the power switch, and check if the LED light is on. Turn on the pairing setup switch and turn off the pairing reset switch. Push the pairing button of the remote control.

[Page 23](#) 5 PORT DETAIL INSTALLATION PROCEDURE STEP 5 - SETTING-UP THE PAIRING WITH REMOTE CONTROL What is pairing? "Pairing" is the configuration needed to make the control box and the remote control transmit and receive the signal between each other. -A control box can be paired with several numbers of remote controls. -A remote control can be paired with several numbers of control boxes.

[Page 24](#) 5 PORT DETAIL INSTALLATION PROCEDURE STEP 6 - TESTING THE PAIRING AND SENSOR CONNECTION For testing the pairing and sensor connection, please unplug one of the USB connectors of the charging & security cables from the USB port. If the alarm is triggered, it means successful connection.

[Page 25](#) 5 PORT DETAIL INSTALLATION PROCEDURE STEP 6 - TESTING THE PAIRING AND SENSOR CONNECTION Cable short-circuit detection When the short circuit is occurred by deterioration of cable, the short alarm sounds constantly. In this case, the led on the cable is off and the charging stops at the same time.

[Page 26](#) The End...