



# Whirlpool AWD60A Operation Manual

Tumble dryer



1
Table Of Contents
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32

--

---

•

[Table of Contents](#)

- 

Troubleshooting

•

## Bookmarks



## Table of Contents

1 Table of Contents

2 Name of Parts

3 Important safety instructions

4 Installation

5 Wallmounting Instructions

6 Wall Mounting Instructions

[7 Rack Fitting Instructions](#)

[8 Rack Fitting Instructions](#)

[9 How to Operate the Dryer](#)

[10 Control Panel](#)

[11 Drying Methods](#)

[12 Cleaning and Maintenance](#)

[13 Trouble Shooting](#)

[14 Specifications](#)

[15 Wiring Circuit](#)

[16 Program Descriptions](#)

[Download this manual](#)

[See also: Service Manual](#)



# TUMBLE DRYER AWD60A

1

TumbleDryer\_AWD60A-4.indd 1  
5/8/08 4:25:42 PM



## Table of Contents

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Whirlpool AWD60A

### [Dryer Whirlpool AWD60A Service Manual](#)

Tumble dryer (22 pages)

### [Dryer Whirlpool AWD60A Operation Manual](#)

(17 pages)

### [Dryer Whirlpool AED4475TQ User Instructions](#)

Whirlpool aed4475tq: user guide (24 pages)

### [Dryer Whirlpool AWZ 7913 WP Instructions For Use Manual](#)

6kg-load 6th sense condenser tumble dryer, awz 7913 awz 7913 wp (9 pages)

### [Dryer WHIRLPOOL AWZ 7913 Quick Reference Manual](#)

(4 pages)

### [Dryer Whirlpool AWZ 3520 WP Instructions For Use Manual](#)

7kg-load 6th sense air vented tumble dryer, awz 3520 wp (9 pages)

### [Dryer WHIRLPOOL AWZ 3520 Quick Reference Manual](#)

(4 pages)

### [Dryer Whirlpool AWZ 7303 Instructions For Use Manual](#)

6kg-load condenser tumble dryer, awz 7303 (10 pages)

### [Dryer WHIRLPOOL AWZ 481 E Service Manual](#)

Tumble dryer air vent (9 pages)

### [Dryer Whirlpool AWZ-7813 Service Manual](#)

Condensation electr (15 pages)

### [Dryer Whirlpool AWZ220 Instructions For Use Manual](#)

(6 pages)

### [Dryer Whirlpool AWZ220 Quick Start Manual](#)

(5 pages)

### [Dryer Whirlpool AWZ 234 Service Manual](#)

Tumble dryer (14 pages)

### [Dryer Whirlpool AWZ9CD/PRO Use And Installation Manual](#)

(136 pages)

### [Dryer Whirlpool AWD712S User Manual](#)

Electric dryer (24 pages)

### [Dryer Whirlpool AWZ10CDS/PRO Use, Care And Installation Manual](#)

(32 pages)

## Summary of Contents for Whirlpool AWD60A

[Page 1](#) OPERATION MANUAL TUMBLE DRYER AWD60A TumbleDryer\_AWD60A-4.indd 1 5/8/08 4:25:42 PM...

### [Page 2: Table Of Contents](#)

TABLE OF CONTENTS BEFORE USING THE DRYER Name of Parts Important Safety Instructions  
INSTALLATION Wall Mounting Instructions 6 - 8 Rack Fitting Instructions 9 - 10 HOW TO  
OPERATE THE DRYER Control Panel Drying Methods Cleaning and maintenance Trouble shooting  
Specifications Wiring circuit PROGRAM DESCRIPTIONS...

### [Page 3: Name Of Parts](#)

NAME OF PARTS Control panel Program selector Adjustable outlet Door grill and lint filter Power supply cord Back plate Model number Air intake grill and Serial number Warning Read all instructions before using this dryer. Operating, care and installations instructions have been provided.

### [Page 4: Importantsafetyinstructions](#)

IMPORTANTSAFETYINSTRUCTIONS petrol, kerosene, spot removers, turpentine, To reduce the risk waxes and wax removers, etc. Do not store or Warning of fire, electrical use these items on or in the vicinity of the dryer. shock or injury to Do not place items exposed to cooking oils in persons when using this dryer, please follow basic your dryer.Items contaminated with cooking oils precautions and read the following:...

### [Page 5: Installation](#)

INSTALLATION Dimensions A = 825 mm B = 560 mm C = 595 mm Weight = 30 kg Remove the transport packaging and the tape before starting dryer. Packing accessories Check list of the accessories and materials provided with the machine: Name Operation Wall...

### [Page 6: Wallmounting Instructions](#)

WALLMOUNTING INSTRUCTIONS The dryer can be mounted to a wall by following these instructions. Firstly select whether to mount the dryer vertically, with the control panel at the top - or invent the dryer so the control panel is at the botom(see figure 4) this allows easier access to the controls.

[Page 7](#) WALL MOUNTING INSTRUCTIONS 2 screws 2 corks FIG. 2. Hooks Spacers FIG. 3. TumbleDryer\_AWD60A-4.indd 7 5/8/08 4:25:51 PM...

### [Page 8: Wall Mounting Instructions](#)

WALLMOUNTING INSTRUCTIONS FIG. 4. nverted dryer is supplied. To fit this film, pull off the knob then clean surface of old film with a cloth. Peel the release paper from the back of inverted film then place new control panel film on the surface so that writing is the correct way around.

### [Page 9: Rack Fitting Instructions](#)

RACK FITTING INSTRUCTIONS DRYER FREESTANDING OR WALL MOUNTED(UPRIGHT). For ease of access, the rack is to be mounted near the dryer. Firstly, hold the rack horizontally with the two end projections pointing upwards and away from yourself.Position the rack near the top of the dryer and place the end of the DRYER UPRIGHT Rack in operating...

### [Page 10: Rack Fitting Instructions](#)

RACK FITTING INSTRUCTIONS To hold the drying rack out of the way when not in use, it will be necessary to attach the retaining clip to the base of your dryer. To do this, firstly remove the screw located Remove screw 4cm from the right corner of the inverted dryer (Fig.

### [Page 11: How To Operate The Dryer](#)

OPERATION 1. Before operation, clean off any dust or dirt from inside the dryer drum with a damp towel. 2. Clean off any build up on the filter screen and in the duct to increase drying efficiency. Before turning on the power for the dryer, check: into the dryer.

### [Page 12: Control Panel](#)

CONTROL PANEL Turn this knob to choose the drying program you desire. This dryer has 7 program options available for you to choose. After turning on the power, select the drying program you desire. Gently touch Start/Pause button to start the dryer. To Pause a program gently touch this button Press the Start/Pause button again and the program will continue to operate.

### [Page 13: Drying Methods](#)

DRYING METHODS Insert the power plug into an appropriate socket to turn on the power. Operating power supply: (220-240)V/50Hz. Open the door and place the treated laundry into the drum of the dryer. To save energy and achieve a better drying result, please spin the laundry as



dry as possible. Place the laundry evenly into the drum after shaking them loose.

## [Page 14: Cleaning And Maintenance](#)

CLEANING AND MAINTENANCE Warning Wipe off dust and dirt on the body of the dryer and the surface of the main control panel . NOTE: Do not use excessive water, just a damp cloth. Do not use solvents. Do not use spray cleaners when cleaning the interior. Do not use harsh or abrasive cleaners.

## [Page 15: Trouble Shooting](#)

Did the amount of the loaded laundry exceed the rated load? Was the loaded laundry spun dry? Did the laundry become twisted whilst drying? SPECIFICATIONS SPECIFICATIONS ITEM (TYPE) AWD60A Power supply (220-240)V /50Hz Max operating current (A) Rated load (kg) Drying programs...

## [Page 16: Program Descriptions](#)

30 minute drying cycle, the last 10 minutes in cool down mode. Manually set drying cycle from 20 minutes to 240 minutes, the last 10 minutes in cool down mode. 30 minute cool air cycle. No heat applied. TUMBLE DRYER AWD60A TumbleDryer\_AWD60A-4.indd 16 5/8/08 4:26:06 PM...

[Page 17](#) AWD60A TumbleDryer\_AWD60A-4.indd 1 5/8/08 4:25:42 PM...

[Page 18](#) 6 - 8 9 - 10 TumbleDryer\_AWD60A-4.indd 2 5/8/08 4:25:42 PM...

[Page 19](#) TumbleDryer\_AWD60A-4.indd 3 5/8/08 4:25:43 PM...

[Page 20](#) TumbleDryer\_AWD60A-4.indd 4 5/8/08 4:25:44 PM...

[Page 21](#) A = 825 mm B = 560 mm C = 595 mm = 30 kg • • • • • 10°C. 35°C. 50mm TumbleDryer\_AWD60A-4.indd 5 5/8/08 4:25:45 PM...

[Page 22](#) 50mm ,12g x 50mm 553mm 553mm ,12g x 50mm TumbleDryer\_AWD60A-4.indd 6 5/8/08 4:25:46 PM...

[Page 23](#) TumbleDryer\_AWD60A-4.indd 7 5/8/08 4:25:51 PM...

[Page 24](#) Start Pause Start Pause TumbleDryer\_AWD60A-4.indd 8 5/8/08 4:25:54 PM...

[Page 25](#) TumbleDryer\_AWD60A-4.indd 9 5/8/08 4:25:58 PM...

[Page 26](#) Retaining clip Drying rack 1 kg TumbleDryer\_AWD60A-4.indd 10 5/8/08 4:26:01 PM...

[Page 27](#) 6 kg 3 kg 950g 800g 300g 800g 3000g 800g 800g 200g 300g TumbleDryer\_AWD60A-4.indd 11 5/8/08 4:26:02 PM...

[Page 28](#) B. Start Pause C. LED Start Pause 1 40 Delay 4 00 Delay Start Pause 0 20 Start Pause Start Pause TumbleDryer\_AWD60A-4.indd 12 5/8/08 4:26:02 PM...

[Page 29](#) (220-240)V /50Hz Start Pause 60min TumbleDryer\_AWD60A-4.indd 13 5/8/08 4:26:02 PM...

[Page 30](#) TumbleDryer\_AWD60A-4.indd 14 5/8/08 4:26:05 PM...

[Page 31](#) Start Pause AWD60A (220-240)V /50Hz (kg) 2100 (HxDxW) mm 825 x 560 x 595 (kg) IPX4 Th - Tf - TumbleDryer\_AWD60A-4.indd 15 5/8/08 4:26:06 PM...

[Page 32](#) 1. EXTRA DRY 2.NORMAL DRYER 3.100 min 4.60 min 5.30 min 6.SET 7.COLD AWD60A TumbleDryer\_AWD60A-4.indd 16 5/8/08 4:26:06 PM...

Save PDF