



Whirlpool 漩涡AKZ 531 Product Description

1
2


--

•

Bookmarks

[Download this manual](#)


Quick Links



AKZ 531

PRODUCT DESCRIPTION SHEET

DE AT BE GB FR NL GR RU



1. Control panel
2. Cooling fan (not visible)
Fan operation switches on only when the oven and/or hob have reached a certain temperature, and may continue even after the appliance has been turned off, for a few minutes.
3. Top heating element (can be lowered)
4. Oven light
5. Fan
6. Circular heating element
7. Bottom heating element (not visible)
8. Oven cool door

ACCESSORIES


Baking tray:




Wire Shelf:



CONTROL PANEL



1. ON/OFF - Function Selector Knob.
2. Confirm and programme selection button
3. Pre-set values changing knob (temperature, time, levels)
4. Knob to switch on the left front cooking zone of the hob*
5. Knob to switch on the left rear cooking zone of the hob*
6. Knob to switch on the right rear cooking zone of the hob*
7. Knob to switch on the right front cooking zone of the hob*
8. Cooktop warning lights



*) The hob knobs are not interchangeable. After any cleaning or Service operation, replace them in their original position.

Retractable knobs

- To use this type of knob, press it in the middle.
- The knob comes out.
- Turn it to the required position.

Once cooking is over, turn the knob to 0 and press it again to restore it to its original position.

Oven Functions		
Function	Preset temperature	Adaptation
Oven OFF	-	
LAMP	-	
MLTF (Heat Maintenance)	35°C - 60°C	
STATIC	200°C	50°
FAST	150°C	5
FAN/THERMO-VENTILATED	160°C	50°
TURBOFAN	160°C	50°
GRILL	3	
TURBOGRILL	3	
PIZZA/BREAD	-	P1 P2
BOOSTER	200°C	50°

5019 310 56254

[Next Page](#)

1
2

Related Manuals for Whirlpool 烤箱AKZ 531

[Oven Whirlpool ACWT 5G311/WH Instructions For Use Manual](#)

(72 pages)

[Oven Whirlpool 501930001639 Instructions For Use Manual](#)

(94 pages)

[Oven Whirlpool ACMT 5131/IX/2 Instructions For Use Manual](#)

(52 pages)

[Oven Whirlpool AKZ 162/WH Instructions For Use Manual](#)

Built-in circa fan double oven, white akz 162/wh (11 pages)

[Oven Whirlpool AKZ 244 Series User And Maintenance Manual](#)

(95 pages)

[Oven Whirlpool AKZ 179 Product Sheet](#)

(6 pages)

[Oven Whirlpool AKZ 562 Operation And Maintenance](#)

(23 pages)

[Oven Whirlpool AKZ 218 User And Maintenance Manual](#)

Built-in oven (19 pages)

[Oven Whirlpool AKZ 232 User And Maintenance Manual](#)

(37 pages)

[Oven Whirlpool AKZ 390 IX Instructions For Use Manual](#)

(8 pages)

[Oven Whirlpool AKZ 246 User And Maintenance Manual](#)

(95 pages)

[Oven Whirlpool AKZ 478/01 User And Maintenance Manual](#)

(27 pages)

[Oven Whirlpool AKZ 230 User And Maintenance Manual](#)

(37 pages)

[Oven Whirlpool AKZ 595 User And Maintenance Manual](#)

(47 pages)

[Oven Whirlpool AKZ 561 User And Maintenance Manual](#)

(25 pages)

[Oven Whirlpool OAKZ9 7961 SP IX Manual](#)

(21 pages)

This manual is also suitable for:

Akz 531