

Remote Calling Station Messaging; Busy Station Messaging - Toshiba Strata DK8 User Manual

Dk digital lcd telephone

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48

•

[Table of Contents](#)

•

Bookmarks



9. Press the Mode button.

10. Dial 0.

To Receive a Called Station
Message:

1. Press the Intercom and

Msg button.

To Set a Calling Station

Message for Another Station:

1. Press the Mode button when
your telephone is idle.

2. Dial 9 5.

3. Dial the "destination" station
number.

4. Press the Page button.

5. Enter the desired message

number.

6. Press the Page button.

7. Press the Mode button.

8. Dial 0.

4-12

The LCD displays "MODE NO.?"

The LCD displays date/day/time. The LCD then displays "SENT NNM" at originating station, and the originating station number and a message indication are displayed on the destination station LCD.

The message will display on the destination station LCD.

REMOTE CALLING STATION MESSAGING

The LCD displays "MODE?"

The LCD displays "MODE 95 DEST EKT NO.?"

The LCD displays "MODE 95 DEST EKT NO.NN".

The LCD displays "MSG NO.?"

The LCD displays the message.

The LCD displays "MSG NO.?"

NOTE:

Remote calling station messaging allows you to set a calling station message for only one station at a time.

The LCD displays "MODE NO.?"

Your LCD shows the time and date. The message is displayed at the "destination" station. Any station calling the "destination" station receives the message.

BUSY STATION MESSAGING

When reaching a busy or DND LCD station, a message can be sent to that station (an audible tone will be heard). The busy or DND station may also return a message to the calling station's LCD. The two stations may continue this procedure to carry on a "silent" conversation.

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
41
42
43
44
45
46
47
48

Related Manuals for Toshiba Strata DK8

[Telephone System Toshiba Strata DK8 Installation And Maintenance Manual](#)

Digital key telephone systems (609 pages)

[Telephone Toshiba strata DK8 Installation Instructions Manual](#)

(584 pages)

[Telephone System Toshiba Strata DK 16 Installation And Maintenance Manual](#)

Toshiba digital key telephone systems installation and maintenance manual (321 pages)

[Telephone Toshiba Strata DK8 User Manual](#)

Digital telephone (90 pages)

[Telephone System Toshiba Strata DK8 General Description Manual](#)

Digital key telephone system (46 pages)

[Telephone TOSHIBA Strata DK8 User Manual](#)

Standard telephone (26 pages)

[Telephone Toshiba Strata DK16 User Manual](#)

Add-on module and direct station selection console (18 pages)

[Telephone Toshiba Strata DK8 Quick Reference Manual](#)

Business telephone (9 pages)

[IP Phone Toshiba DK User Manual](#)

Includes lcd, add-on module, and direct station selection console (163 pages)

[IP Phone Toshiba CT User Manual](#)

Includes lcd, add-on module, and direct station selection console (136 pages)

[Telephone Toshiba Strata DK User Manual](#)

Electronic telephone (134 pages)

[Handsets Toshiba Strata AirLink Integrated Wireless Handset User Manual](#)

Toshiba integrated wireless handset user guide (131 pages)

[Cordless Telephone Toshiba Strata DK User Manual](#)

Cordless digital telephone (107 pages)

[Telephone Toshiba Strata DK System Administration Manual](#)

(60 pages)

[IP Phone Toshiba Strata DK User Manual](#)

Digital single line telephone (60 pages)

[Telephone System Toshiba Strata DK14 System Administrator Manual](#)

Strata dk digital business telephone systems (56 pages)

Related Content for Toshiba Strata DK8

[Strata CIX IP5000-Series Calling A Station](#)

Toshiba Strata CIX IP5000-Series

[Strata CIX DP-5000 series Calling A Station](#)

Toshiba Strata CIX DP-5000 series

[DP5000-Series Calling A Station](#)

Toshiba DP5000-Series

[Strata IPT Calling A Station](#)

Toshiba Strata IPT

[DP5000-Series Calling A Station](#)

Toshiba DP5000-Series

[Strata DK Group Notification Station Messaging](#)

Toshiba Strata DK

[PERCEPTIONe&x Station-To-Station Calling](#)

Toshiba PERCEPTIONe&x

[Strata DK8 Calling System Or Station Speed Dial Numbers](#)

Toshiba Strata DK8

This manual is also suitable for:

[Strata dk16](#)