



Whirlpool UXB0600DYS Installation Instructions Manual

600 cfm and 1200 cfm internal blowers for range hoods

1
2
3
4
5
6
7
8
9
10
11
12

--


•

[Table of Contents](#)

•

Bookmarks

Available languages




Quick Links

[1 Installation Requirements](#)

[2 Installation Instructions](#)

[Download this manual](#)



INSTALLATION INSTRUCTIONS

600 CFM AND 1200 CFM INTERNAL BLOWERS

FOR RANGE HOODS

INSTRUCTIONS D'INSTALLATION

VENTILATEURS INTERNES AVEC DÉBIT DE 600 PP/MIN ET

1200 PP/MIN POUR HOTTES D'ÉVACUATION

Table of Contents/Table des matières

RANGE HOOD SAFETY	1	INSTALLATION INSTRUCTIONS 600 CFM AND 1200 CFM INTERNAL FOR RANGE HOODS
INSTALLATION REQUIREMENTS	3	
Tools and Parts	3	
INSTALLATION INSTRUCTIONS	3	INSTRUCTIONS D'INSTALLATION VENTILATEURS INTERNES AVEC DÉBIT DE 1200 PI³/MIN POUR HOTTES D'ÉVA
Install Range Hood Blower Motor	4	
ASSISTANCE OR SERVICE	5	
In the U.S.	5	
In Canada	5	
WARRANTY	6	

Sécurité de la hotte de cuisinière	7	Table of Contents/Table des matières	
EXIGENCES D'INSTALLATION	9	RANGE HOOD SAFETY	1
Outils et pièces	9	INSTALLATION REQUIREMENTS	3
INSTRUCTIONS D'INSTALLATION	9	Tools and Parts	3
Install Range Hood Blower Motor	9	INSTALLATION INSTRUCTIONS	3
ASSISTANCE OU SERVICE	10	Install Range Hood Blower Motor	4
In the U.S.	10	ASSISTANCE OR SERVICE	5
In Canada	11	WARRANTY	6
WARRANTY	11	SÉCURITÉ DE LA HOTTE	7
GARANTIE	12	EXIGENCES D'INSTALLATION	9
		Outils et pièces	9
		INSTRUCTIONS D'INSTALLATION	9
		Installation du moteur du ventilateur de la hotte	9
		ASSISTANCE OU SERVICE	10
		GARANTIE	11

RANGE HOOD SAFETY

Your safety and the safety of others are very important. We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the safety alert symbol.
 This symbol alerts you to potential hazards that can kill or hurt you and others.
 All safety messages will follow the safety alert symbol and either the word "DANGER" or "WARNING."
 These words mean:
 You can be killed or seriously injured if you don't immediately follow instructions.
 You can be killed or seriously injured if you don't follow instructions.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.
IMPORTANT: READ AND SAVE THESE INSTRUCTIONS.

FOR RESIDENTIAL USE ONLY.
IMPORTANT: LIRE ET CONSERVER CES INSTRUCTIONS POUR UTILISATION RÉSIDENTIELLE SEULEMENT.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.
IMPORTANT: READ AND SAVE THESE INSTRUCTIONS.

Table of Contents

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool UXB0600DYS

[Ventilation Hood Whirlpool UXI0600DYS Product Dimensions](#)

600 cfm and 1200 cfm in-line blowers for range hoods (1 page)

Summary of Contents for Whirlpool UXB0600DYS

Page 1 INSTALLATION INSTRUCTIONS 600 CFM AND 1200CFM INTERNAL BLOWERS FOR RANGEHOODS INSTRUCTIONS D'INSTALLATION VENTILATEURS INTERNES A VEC DEBIT. DE600 PP/MIN ET 1200 PP/MIN POURHOTTES D'EVACUATION Table of Contents/Table des mah_res RANGE HOOD SAFETYSECURITE DE LA HOTTE DE CUISINIERE

[Page 2: Important Safety Instructions](#)

IMPORTANT SAFETY INSTRUCTIONS WARNING: TO REDUCE THE RISK OF A RANGE TOP WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC GREASE FIRE: SHOCK, OR INJURY TO PERSONS, OBSERVE THE FOLLOWING: m Never leave surface units unattended at high settings. Boilovers cause smoking and greasy spillovers that may m Use this unit only in the manner intended by the ignite.

[Page 3: Installation Requirements](#)

INSTALLATION REQUIREMENTS INSTALLATION INSTRUCTIONS IMPORTANT: Perform steps 1-4 before mounting the range hood. 1. Remove grease filters from range hood. See the "Range Gather the required tools and parts before starting installation. Hood Care" section in the Use and Care Guide. Read and follow the instructions provided with any tools listed here.

Page 4 Install the 6 mm nuts to the outside top or outside back Dual Blower Motor Assembly (alternate location on some models) of the range hood at the proper location for the selected motor system. • Two 6 mm nuts are required for the single motor system. Clip nuts into the small square notches located at the left and right end of the square vent opening.

[Page 5: Assistance Or Service](#)

© area, you can also look in your telephone directory Yellow Pages. For further assistance If you need further assistance, you can write to Whirlpool Corporation with any questions or concerns at: Whirlpool Brand Home Appliances Customer eXperience Center 553 Benson Road Benton Harbor, MI 49022-2692 Please include a daytime phone number in your correspondence.

Page 6 YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE. If outside the 50 United States and Canada, contact your authorized Whirlpool dealer to determine if another warranty applies. If you need service, first see the "Troubleshooting"...

Page 7 SECURITE DE LA HOTTE DE CUISINIERE Votre securite et celle des autres est tres importante. Nous donnons de nombreux messages de securite importants dans ce manuel et sur votre appareil menager. Assurez-vous toujours lire tousles messages de securite et de vous y conformer. Ce symbole d'alerte de securite vous signale les dangers potentiels de deces et de blessures graves &...

Page 8 IMPORTANTES INSTRUCTIONS DE SECURITE AVERTISSEMENT : POUR MINIMISER LE RISQUE AVERTISSEMENT : POUR REDUIRE LE RISQUE D'UN FEU DE GRAISSE SUR LA CUISINIERE : D'INCENDIE, CHOC ELECTRIQUE OU DOMMAGES CORPORELS, RESPECTER LES INSTRUCTIONS =1 Ne jamais laisser un element de surface fonctionner & SUIVANTES puissance de chauffage maximale sans surveillance.

[Page 9: Exigences D'installation](#)

EXIGENCES D'INSTALLATION INSTRUCTIONS D'INSTALLATION IMPORTANT : Executer les etapes 1 & 4 avant de monter la hotte R assembler les outils et composants necessaires avant de

cuisiniere. d'entreprendre l'installation. Lire et observer les instructions 1. Retirer les filtres & graisse de la hotte. Voir la section fournies avec chacun des outils de la liste ci-dessous.

[Page 10](#) Fixer les écrous de 6 mm en haut & l'extérieur ou & l'arrière Ensemble & deux moteurs-ventilateurs (autre emplacement sur certains modèles) de la hotte, & l'endroit correct selon le système de ventilation sélectionné • Deux écrous de 6 mm sont nécessaires pour le système & un seul ventilateur.

[Page 11: Assistance Ou Service](#)

l'usine, dans votre région, nous appeler ou téléphoner au centre de service désigné le plus proche. Veuillez appeler sans frais le Centre pour l'expérience de la clientèle de Whirlpool Canada LP au : 1-800-807-6777. A. Plaque de montage du moteur Nos consultants...

[Page 12](#) CONFIRMEZ VOS DROITS JURIDIQUES SPÉCIFIQUES ET VOUS POUVEZ ÉGALEMENT JOUIR D'AUTRES DROITS QUI PEUVENT VARIER D'UNE JURIDICTION À UNE AUTRE. Si vous résidez & l'extérieur du Canada et des 50 États des États-Unis, contactez votre marchand Whirlpool autorisé pour déterminer si une autre garantie s'applique.

This manual is also suitable for:

[Uxb1200dys](#)