




Sanyo DMP-P3 Instruction Manual

Clock radio for ipod

| |
|-------------------|
| 1 |
| Table Of Contents |
| 2 |
| 3 |
| 4 |
| 5 |
| 6 |
| 7 |
| 8 |
| 9 |
| 10 |
| 11 |
| 12 |
| 13 |
| 14 |



•

[Table of Contents](#)


•

Bookmarks

Quick Links

[1 General Functions](#)

[Download this manual](#)



DMP-P3

Clock Radio for iPod

INSTRUCTION MANUAL

Table of Contents

[Next Page](#)

1
2
3
4
5

Related Manuals for Sanyo DMP-P3

[Clock Radio Sanyo DMP P1 Instruction Manual](#)

Clock radio with ipod dock (37 pages)

[Clock Radio Sanyo DMP-P1 Instruction Manual](#)

Clock radio with ipod docking (16 pages)

[Clock Radio SANYO DMP-P7 Instruction Manual](#)

Clock radio with dock for ipod (17 pages)

[Clock Radio SANYO DMP-P8 Instruction Manual](#)

Clock radio with ipod dock (20 pages)

[Clock Radio Sanyo DMP-P6 Instruction Manual](#)

With dock for ipod (20 pages)

[Clock Radio Sanyo RM-6090 Instruction Manual](#)

Am/fm digital alarm clock radio (10 pages)

[Clock Radio Sanyo RM 5900 Service Manual](#)

Digital clock radio (9 pages)

[Clock Radio SANYO RM-6860 Instruction Manual](#)

Am/fm digital alarm clock radio (8 pages)

[Clock Radio SANYO RM-5750 Instruction Manual](#)

Am/fm digital alarm clock radio (8 pages)

[Clock Radio Sanyo RM-D500 Instruction Manual](#)

Compact disc dual alarm clock radio (13 pages)

[Clock Radio SANYO RM-630 User Manual](#)

Am/fm clock radio with night light (11 pages)

[Clock Radio Sanyo RM-5090 Instruction Manual](#)

(10 pages)

[Clock Radio Sanyo RM-X100 Instruction Manual](#)

(6 pages)

[Clock Radio Sanyo RM-X105 Instruction Manual](#)

(4 pages)

[Clock Radio Sanyo RM5008 Service Manual](#)

Digital clock radio (10 pages)

[Clock Radio SANYO RM-7970 Instruction Manual](#)

Am/fm clock radio (2 pages)

Summary of Contents for Sanyo DMP-P3

[Page 1](#) DMP-P3 Clock Radio for iPod...

[Page 2: Table Of Contents](#)

| | | | |
|-----------------------------|-----------------------------------|-------------------------------|----|
| TABLE OF CONTENTS | IMPORTANT SAFETY INSTRUCTION..... | 1 | |
| PREPARATION FOR USE..... | 3 | OVERVIEW..... | 5 |
| GENERAL FUNCTIONS..... | 7 | TUNER MODE..... | 8 |
| iPod MODE..... | 9 | CLEANING AND MAINTENANCE..... | 9 |
| INFORMATION..... | 10 | SPECIFICATIONS..... | 10 |
| COMPATIBLE IPODS CHART..... | 11 | | |

[Page 3: Important Safety Instruction](#)

IMPORTANT SAFETY INSTRUCTIONS 1.) Read these instructions. Keep these instructions. Follow all instructions. Heed all warnings. 2.) Install this unit in accordance with the manufacturer's instructions. 3.) Only use attachments / accessories / replacement parts specified by the manufacturer. 4.) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the unit.

[Page 4](#) 22.) Do not destroy the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety.

[Page 5: Preparation For Use](#)

PREPARATION FOR USE Before Setting Up The Unit • Operate controls and switches as described in the manual. • Before turning on the power, make certain that the power cord is properly installed. • When moving the unit, be sure to first disconnect the AC power cord. •...

[Page 6](#) Power Source This product is designed to operate on normal 240V~50Hz AC power only. Do not attempt to operate the unit on any other power source. You could cause damage to the product that is not covered by your warranty. AC Power Supply Connection 1.

[Page 7: Overview](#)

OVERVIEW FRONT VIEW TOP VIEW REAR VIEW...

[Page 8](#) SIDE VIEW BOTTOM VIEW...

[Page 9: General Functions](#)

GENERAL FUNCTIONS Switching On and Off 1. The unit will automatically switch to standby mode once the AC power source is connected. 2. Switch on the device from standby mode by sliding the FUNCTION switch to ON position. 3. Switch the device to standby mode by sliding the FUNCTION switch to OFF position.

[Page 10: Tuner Mode](#)

Sleep Function This function switches the unit from operation mode to STANDBY mode after the specified time. (Supports AM / FM mode only). 1. Press and hold the SLEEP button to turn the unit on and press HOUR and MIN buttons to set the sleep time.

[Page 11: Ipod Mode](#)

iPod MODE iPod Universal Dock Adaptor 1. Select the iPod universal dock adaptor (not included, check your iPod packaging if it came with this adaptor) that fits with your iPod model. 2. Install the adaptor with the 2 tabs facing the front, by pushing it down in the universal dock on top of the unit.

[Page 12: Information](#)

INFORMATION Troubleshooting If a fault occurs, first refer to this information before you take the device for repair. If you are unable to rectify the fault using the information given here, contact Customer Support for advice. Under no circumstances should you attempt to repair the device yourself, as this would invalidate the warranty.

[Page 13: Compatible Ipods Chart](#)

Designed specifically to work with your docking iPod, this system provides high quality audio and radio performance that brings out the best in your music. Please read this instruction book carefully before operating the DMP-P3, and keep it for future reference.

[Page 14](#) 309-031750-0001...