



Whirlpool ACM 394 N Service Manual

Electric cooker

1
2
3
4
5
6
7
8

--


•

Bookmarks

--

[Download this manual](#)

Quick Links



SERVICE

Model

Version

Service Nr.

Whirlpool Europe

Consumer Services



Service Manual

Electric cooker

ACM 394 N

ACM 394 N

8576 394 32000

0000 000 00000

Spare parts list

Exploded view



Spare parts list

Exploded view

Electric diagram

Electric diagram

Technical features

This documentation is only intended for qualified technicians who are aware of the respective safety regulations.

Date: 15.01.2001

Document-No.: 0000 000 00000

Register No.:

ACM 394 N

0000 000 00000

0000 000 00000

0000 000 00000

0000 000 00000

0000 000 00000

0000 000 00000

0000 000 00000

cod. C6N0WH011W

Subject to modification

cat. 18.C1891

Manualele ih.com

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool ACM 394 N

[Kitchen Appliances Whirlpool ACE 600 IX Service Manual](#)

(6 pages)

[Kitchen Appliances Whirlpool ACM 388 WH Service Manual](#)

(6 pages)

[Kitchen Appliances Whirlpool AKT 780 Product Description Sheet](#)

(4 pages)

[Kitchen Appliances Whirlpool AKT 352 Product Description Sheet](#)

(4 pages)

[Kitchen Appliances Whirlpool ACM 224 Instructions For Use Manual](#)

(126 pages)

[Kitchen Appliances Whirlpool AMW 393 Instructions For Use Manual](#)

(17 pages)

[Kitchen Appliances Whirlpool ACM 959/WH Service Manual](#)

(6 pages)

[Kitchen Appliances Whirlpool ACMK 6110/WH/1 Instructions For Use Manual](#)

Cooker and oven (56 pages)

[Kitchen Appliances Whirlpool WML55011HW Service Manual](#)

Low profile microwave hood combination (43 pages)

[Kitchen Appliances Whirlpool WHW45S Use & Care Manual](#)

(10 pages)

[Kitchen Appliances Whirlpool WHW16BKMSW Use And Care Manual](#)

(16 pages)

[Kitchen Appliances Whirlpool WHB36S Use & Care Manual](#)

(10 pages)

[Kitchen Appliances Whirlpool MBNA920B Quick Manual](#)

(33 pages)

[Kitchen Appliances WHIRLPOOL AKR 804 Installation Manual](#)

(12 pages)

[Kitchen Appliances Whirlpool AMW423/IX Daily Reference Manual](#)

(21 pages)

[Kitchen Appliances Whirlpool WHB27S Use And Care Manual](#)

(9 pages)

Summary of Contents for Whirlpool ACM 394 N

[Page 1](#) Whirlpool Europe S E R V I C E ACM 394 N Consumer Services Service Manual Electric cooker ACM 394 N Model ACM 394 N Version 8576 394 32000 Service Nr. 0000 000 00000 Spare parts list 0000 000 00000...

[Page 2](#) Whirlpool Europe S E R V I C E Consumer Services Spare part list Date 15.01.2001 for Electric Cooker Model ACM 394 N Version 8576 394 32000 Service Nr. 00/0000-00 00 Pos. No. Spare Part No. Denomination 355VC6120 Glass with frame...

[Page 3](#) Model ACM 394 N Version 8576 396 32000 2.15 Service Nr. 2.13 5.30 2.14 5.29 5.31

5.33 5.32 5.27 5.11 5.23 5.15 5.17 5.26 5.16 5.14 5.12 5.25 5.23 5.10 4.45 4.47 4.46 5.21 4.32
4.11 4.14 4.38 4.25 4.13 4.52...

[Page 4: Spare Part List](#)

Whirlpool Europe S E R V I C E Consumer Services Spare part list Date 15.01.2001 for Electric Cooker Model ACM 394 N Version 8576 394 32000 Service Nr. 00/0000-00 00 Pos. No. Spare Part No. Denomination 04732230 Radiant hotplate Ø 180 - 1800W 04711230 Radiant hotplate Ø...

[Page 5](#) Model ACM 394 N Version 8576 394 32000 Service Nr. 2.10 10.4 11.34 11.34 11.33B 8.16 8.15 11.30 10.1 11.33A 8.41 8.40 11.1 11.2 8.17 11.10 11.11 8.18 11.25 8.24 11.3...

[Page 6](#) Whirlpool Europe S E R V I C E Consumer Services Cooker mod. ACM 394 N PILOT PILOT PILOT PILOT 1131261 DIAGRAM FOR ELECTRIC PLATE ENERGY REGULATOR PILOT Reciprocation 0 ÷ 12 0 ÷ 12 DIAGRAM FOR OVEN SELECTOR SWITCH (F1)

[Page 7](#) Whirlpool Europe S E R V I C E Consumer Services Cooker mod. ACM 394 N PILOT PILOT PILOT PILOT 1131261 ELECTRIC DIAGRAM KEY 230V -V3 230V 1 2 3 1 2 3 Oven commutator F2/5 Radiant heater commutators Oven lamp...

[Page 8](#) Whirlpool Europe S E R V I C E Consumer Services Cooker mod. ACM 394 N Technical Data No. 0000 000 00000 Electricity Voltage 230/400 V ~ 50 Hz Power Cooktop power Front left hotplate Ø 210 mm 2100 Rear left hotplate Ø...