


General Information; Purpose; Feature Buttons - Toshiba Strata DK8 User Manual

Digital telephone

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90



•

[Table of Contents](#)

•

Bookmarks



Chapter 1

PURPOSE

This chapter is designed to familiarize you with the controls and indicators located on your telephone. Understanding the function of the feature buttons and their associated LEDs will improve your efficiency in using the telephone and will help you to take advantage of all of the benefits offered by your telephone.

FEATURE BU

Some of the feature buttons described below appear on your telephone, depending on just how your system is programmed. The button label designations for 2000-series telephones are provided here. The designations for

the 1000-series models are in Appendix A.

2000-SERIES

BUTTONS

Account

ACCOUNT CODE BUTTON

Code

Press to enter a Voluntary Account Code anytime during a CO line call without interrupting the conversation.

Alarm

ALARM RESET BUTTON

Reset

Press to turn off a telephone alarm connected to a facility alarm mechanism.

All Call

ALL CALL VOICE PAGE BUTTON

Page

Press to page all of the digital and electronic telephones in the All Call Page group.

Auto Busy

AUTOMATIC BUSY REDIAL BUTTON

Redial

Press to set up Automatic Busy Redial after receiving busy tone on a dialed CO line call.

Auto

AUTOMATIC CALLBACK BUTTON

Callback

Press to recall a busy station or station in the Do Not Disturb Mode (DND) as soon as that station becomes idle or deactivates DND. Also used for CO line queuing.

Call Frwd

CALL FORWARD-ALL CALLS BUTTON

All Calls

Press to forward all calls to another station or voice mail device.

Call Frwd

CALL FORWARD-BUSY BUTTON

Busy

Press to forward calls immediately to another station or voice mail device when your station is busy or in the Do Not Disturb mode.

1-1

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
8
9
10
11
12
13
14
15

Quick Links:

[Intercom Calls](#)

Related Manuals for Toshiba Strata DK8

[Telephone System Toshiba Strata DK8 Installation And Maintenance Manual](#)

Digital key telephone systems (609 pages)

[Telephone Toshiba strata DK8 Installation Instructions Manual](#)

(584 pages)

[Telephone System Toshiba Strata DK 16 Installation And Maintenance Manual](#)

Toshiba digital key telephone systems installation and maintenance manual (321 pages)

[Telephone Toshiba Strata DK8 User Manual](#)

Dk digital lcd telephone (48 pages)

[Telephone System Toshiba Strata DK8 General Description Manual](#)

Digital key telephone system (46 pages)

[Telephone TOSHIBA Strata DK8 User Manual](#)

Standard telephone (26 pages)

[Telephone Toshiba Strata DK16 User Manual](#)

Add-on module and direct station selection console (18 pages)

[Telephone Toshiba Strata DK8 Quick Reference Manual](#)

Business telephone (9 pages)

[IP Phone Toshiba Strata DK 2000-series User Manual](#)

Toshiba digital telephone user guide (164 pages)

[IP Phone Toshiba DK User Manual](#)

Includes lcd, add-on module, and direct station selection console (163 pages)

[IP Phone Toshiba CT User Manual](#)

Includes lcd, add-on module, and direct station selection console (136 pages)

[Handsets Toshiba Strata AirLink Integrated Wireless Handset User Manual](#)

Toshiba integrated wireless handset user guide (131 pages)

[Cordless Telephone Toshiba Strata DK User Manual](#)

Cordless digital telephone (107 pages)

[Telephone Toshiba Strata DK System Administration Manual](#)

(60 pages)

[IP Phone Toshiba Strata DK User Manual](#)

Digital single line telephone (60 pages)

[Telephone System Toshiba Strata DK14 System Administrator Manual](#)

Strata dk digital business telephone systems (56 pages)

Related Content for Toshiba Strata DK8

[strata DK8 General](#)

[Toshiba strata DK8](#)

[Strata DK40 General Voice Mail \(Standard Telephone Port\)](#)

[Programming](#)

[Toshiba Strata DK40](#)

[CTX100-S General Description](#)

[Toshiba CTX100-S](#)

[STRATA CTX100 General Description](#)

[Toshiba STRATA CTX100](#)

[Strata DK24 General](#)

[Toshiba Strata DK24](#)

[Strata DK Publication Information](#)

[toshiba Strata DK](#)

[Strata CIX IPT General Operation](#)

Toshiba Strata CIX IPT

[Strata CTX28 General Description](#)

Toshiba Strata CTX28

This manual is also suitable for:

[Strata dk16](#)