

Led Indications; Line Button Led Indications - Toshiba Strata DK8 User Manual

Digital telephone

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14


15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90



•

[Table of Contents](#)

•

Bookmarks



2000-SERIES

BUTTONS

Spd Dial

PAUSE BUTTON

Pause

Press to set either a one-half or two-second pause when programming Speed Dial numbers. (The pause time is set in system programming.)

Spkr

SPEAKER BUTTON (FIXED)

Press to turn the speaker on/off. The Spkr button will also select a line or the intercom if programmed for auto preference in system programming. Also, used to disconnect on-hook speakerphone calls.

BACKGROUND MUSIC BUTTON

Tel Set

Press to turn Background Music on or off over your station speaker.

Music

TONE BUTTON

Tone Dial

Press to change the outgoing dialing of the CO line in use from dial pulse to tone

Select

signaling.

DOOR LOCK BUTTON

Unlock

Press to unlock a door lock mechanism.

Door _____

VOLUME BUTTON (FIXED)

Vol

Press to adjust volume levels. See "VOLUME CONTROLS" later in this chapter.

Vol

LED INDICATIONS

Each line and feature button has a Light Emitting Diode (LED) next to it which indicates the status of the line or feature associated with the button.

LINE BUTTON LED INDICATIONS

Line LEDs light as red or green and flash at varying rates to indicate call status.

Line In-use—When you access an outside line, the LED will appear at your station as follows:

Flash rate: 2 seconds on—1/8 second off—1/8 second on—1/8 second off

Color: Green

Other stations with the Line: Steady, red

1-5

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
12
13
14
15
16
17
18
19

Quick Links:

[Intercom Calls](#)

Related Manuals for Toshiba Strata DK8

[Telephone System Toshiba Strata DK8 Installation And Maintenance Manual](#)

Digital key telephone systems (609 pages)

[Telephone Toshiba strata DK8 Installation Instructions Manual](#)

(584 pages)

[Telephone System Toshiba Strata DK 16 Installation And Maintenance Manual](#)

Toshiba digital key telephone systems installation and maintenance manual (321 pages)

[Telephone Toshiba Strata DK8 User Manual](#)

Dk digital lcd telephone (48 pages)

[Telephone System Toshiba Strata DK8 General Description Manual](#)

Digital key telephone system (46 pages)

[Telephone TOSHIBA Strata DK8 User Manual](#)

Standard telephone (26 pages)

[Telephone Toshiba Strata DK16 User Manual](#)

Add-on module and direct station selection console (18 pages)

[Telephone Toshiba Strata DK8 Quick Reference Manual](#)

Business telephone (9 pages)

[IP Phone Toshiba Strata DK 2000-series User Manual](#)

Toshiba digital telephone user guide (164 pages)

[IP Phone Toshiba DK User Manual](#)

Includes lcd, add-on module, and direct station selection console (163 pages)

[IP Phone Toshiba CT User Manual](#)

Includes lcd, add-on module, and direct station selection console (136 pages)

[Handsets Toshiba Strata AirLink Integrated Wireless Handset User Manual](#)

Toshiba integrated wireless handset user guide (131 pages)

[Cordless Telephone Toshiba Strata DK User Manual](#)

Cordless digital telephone (107 pages)

[Telephone Toshiba Strata DK System Administration Manual](#)

(60 pages)

[IP Phone Toshiba Strata DK User Manual](#)

Digital single line telephone (60 pages)

[Telephone System Toshiba Strata DK14 System Administrator Manual](#)

Strata dk digital business telephone systems (56 pages)

Related Content for Toshiba Strata DK8

[DKT3000 Series Responding To A Lit Msg Led](#)

Toshiba DKT3000 Series

[DP5000-Series Led Indicator Details](#)

Toshiba DP5000-Series

[IP4100 Series Led States](#)

Toshiba IP4100 Series

[IP5000 Series Responding To A Lit Msg Led](#)

Toshiba IP5000 Series

[Strata CIX IP5000-Series Responding To A Lit Msg Led](#)

Toshiba Strata CIX IP5000-Series

[Strata CIX DP-5000 series Led Indicator Details](#)

Toshiba Strata CIX DP-5000 series

[DP5000-Series Led Indicator Details](#)

Toshiba DP5000-Series

This manual is also suitable for:

[Strata dk16](#)