Group Listening; Automatic Off-Hook Selection - Toshiba Strata DK8 User Manual

Digital telephone

```
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
```

68			
69			
70			
71			
72			
73			
74			
75			
76			
77			
78			
79			
80			
81			
82			
83			
84			
85			
86			
87			
88			
89			
90			
90			
(

Table of Contents







To Activate Group Listening:

- 1. Establish an off-hook call with
- a distant party.
- 2. Hold down the Spkr button.
- 3. When you want to talk to the distant party, release the

Spkr button.

To Make a Call:

1. Lift the handset or press the

Spkr button

2. Dial a telephone number, and proceed with your call.

2-4

GROUP LISTENING

This feature enables you to set your telephone so that you and people near your telephone can hear the distant party over the speaker, but the distant party will not be able to hear you.

The Spkr LED will light red and you will be able to hear the distant party on the telephone speaker. The distant party will not be able to hear you. The handset is activated. Continue to operate in an alternate fashion as desired.

AUTOMATIC OFF-HOOK SELECTION

Automatic Off-hook Selection allows you to access intercom or a specific line or line group just by lifting the handset or pressing the Spkr button. This is an optional feature enabled in system programming.

You will be connected to the option programmed.

If you hear silence, you must press the Intercom button or a Line or Pooled Line Grp button before dialing the telephone number.

NOTE: If your station is programmed with Ringing Line Preference, you can answer a line ringing your station by lifting the handset or pressing the Spkr button.

Table of Contents

Previous Page Next Page

...

Quick Links:	
Intercom Calls	

Related Manuals for Toshiba Strata DK8

<u>Telephone System Toshiba Strata DK8 Installation And Maintenance Manual</u>

Digital key telephone systems (609 pages)

Telephone Toshiba strata DK8 Installation Instructions Manual

(584 pages)

Telephone System Toshiba Strata DK 16 Installation And Maintenance Manual

Toshiba digital key telephone systems installation and maintenance manual (321 pages)

Telephone Toshiba Strata DK8 User Manual

Dk digital lcd telephone (48 pages)

Telephone System Toshiba Strata DK8 General Description Manual

Digital key telephone system (46 pages)

Telephone TOSHIBA Strata DK8 User Manual

Standard telephone (26 pages)

Telephone Toshiba Strata DK16 User Manual

Add-on module and direct station selection console (18 pages)

Telephone Toshiba Strata DK8 Quick Reference Manual

Business telephone (9 pages)

IP Phone Toshiba Strata DK 2000-series User Manual

Toshiba digital telephone user guide (164 pages)

IP Phone Toshiba DK User Manual

Includes lcd, add-on module, and direct station selection console (163 pages)

IP Phone Toshiba CT User Manual

Includes Icd, add-on module, and direct station selection console (136 pages)

Handsets Toshiba Strata AirLink Integrated Wireless Handset User

Manual

Toshiba integrated wireless handset user guide (131 pages)

Cordless Telephone Toshiba Strata DK User Manual

Cordless digital telephone (107 pages)

Telephone Toshiba Strata DK System Administration Manual

(60 pages)

IP Phone Toshiba Strata DK User Manual

Digital single line telephone (60 pages)

Telephone System Toshiba Strata DK14 System Administrator Manual

Strata dk digital business telephone systems (56 pages)

Related Content for Toshiba Strata DK8

Strata CIX Make Attendant Group Assignments On Cix

Toshiba Strata CIX

CTX100-S Pad Group Assignment

Toshiba CTX100-S

STRATA DK14 Transfer From Built-In Auto Attendant (Aa) To Acd Group

Toshiba STRATA DK14

Strata DK14 Program *30 - Telephone Group Page Assignments

Toshiba Strata DK14

DP5000 Series Group Pickup

Toshiba DP5000 Series

STRATA CIX Group Pickup

Toshiba STRATA CIX

Strata CTX28 Pad Group Assignment

Toshiba Strata CTX28

DKT3000 Series Group Pickup Toshiba DKT3000 Series

This manual is also suitable for:

Strata dk16