

Do Not Disturb - Toshiba Strata DK8 User Manual

Digital telephone

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67


68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90

•

[Table of Contents](#)

•

Bookmarks



2. Station—Dial a Station number to pick up a call that is ringing in at or held at the station.

... or ...

Intercom Page—Dial 3 0.

... or ...

External Page—Dial 3 5.

... or ...

CO line on hold

(selective)—Dial the CO line

access code (7 0 1 ~ 7 0 4 for DK8, 7 0 1 ~ 7 0 8 for DK16).

... or ...

Any ringing CO line—Dial 9.

... or ...

Ringling door phone—Dial

3 0.

To Activate Do Not Disturb:

1. Press the Do Not Disturb button.

To Deactivate Do Not Disturb:

1. Press the Do Not Disturb button.

You will be connected to the call ringing in or the held call.

You will be connected to the station from which the page is coming.

You will be connected to the station from which the page is coming.

You will be connected to the CO line that is on hold.

You will be connected to the CO line that is ringing in.

You will be connected to the door phone that is ringing.

DO NOT DISTURB

If your station is in the Do Not Disturb mode, intercom calls will not ring your station, calls can't be transferred to it, and Off-hook Call Announce calls to it will be denied. Incoming CO line calls, though, will mute ring at your station. You can continue to make calls as normal while in the Do Not Disturb mode.

After you press the button, the Do Not Disturb LED will light steady red, and the Do Not Disturb mode will be activated.

The Do Not Disturb LED will turn off, and the Do Not Disturb mode will be deactivated.

NOTES:

1.

Calls will forward from your station if it is set for Call Forward-Busy or Call Forward-Busy/No Answer while in the Do Not Disturb mode.

2.

Some stations may be programmed to override Do Not Disturb.

2-31

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
50
51
52
53
54
55
56
57

Quick Links:

[Intercom Calls](#)

Related Manuals for Toshiba Strata DK8

[Telephone System Toshiba Strata DK8 Installation And Maintenance Manual](#)

Digital key telephone systems (609 pages)

[Telephone Toshiba strata DK8 Installation Instructions Manual](#)

(584 pages)

[Telephone System Toshiba Strata DK 16 Installation And Maintenance Manual](#)

Toshiba digital key telephone systems installation and maintenance manual (321 pages)

[Telephone Toshiba Strata DK8 User Manual](#)

Dk digital lcd telephone (48 pages)

[Telephone System Toshiba Strata DK8 General Description Manual](#)

Digital key telephone system (46 pages)

[Telephone TOSHIBA Strata DK8 User Manual](#)

Standard telephone (26 pages)

[Telephone Toshiba Strata DK16 User Manual](#)

Add-on module and direct station selection console (18 pages)

[Telephone Toshiba Strata DK8 Quick Reference Manual](#)

Business telephone (9 pages)

[IP Phone Toshiba Strata DK 2000-series User Manual](#)

Toshiba digital telephone user guide (164 pages)

[IP Phone Toshiba DK User Manual](#)

Includes lcd, add-on module, and direct station selection console (163 pages)

[IP Phone Toshiba CT User Manual](#)

Includes lcd, add-on module, and direct station selection console (136 pages)

[Handsets Toshiba Strata AirLink Integrated Wireless Handset User Manual](#)

Toshiba integrated wireless handset user guide (131 pages)

[Cordless Telephone Toshiba Strata DK User Manual](#)

Cordless digital telephone (107 pages)

[Telephone Toshiba Strata DK System Administration Manual](#)

(60 pages)

[IP Phone Toshiba Strata DK User Manual](#)

Digital single line telephone (60 pages)

[Telephone System Toshiba Strata DK14 System Administrator Manual](#)

Strata dk digital business telephone systems (56 pages)

Related Content for Toshiba Strata DK8

[Strata DK14 Do Not Disturb](#)

Toshiba Strata DK14

[DKT3000 Series Do Not Disturb](#)

Toshiba DKT3000 Series

[DP5000-Series Do Not Disturb](#)

Toshiba DP5000-Series

[IP4100 Series Do Not Disturb](#)

Toshiba IP4100 Series

[IP5000 Series Do Not Disturb](#)

Toshiba IP5000 Series

[Strata CIX IP5000-Series Do Not Disturb](#)

Toshiba Strata CIX IP5000-Series

[Strata Vle Do Not Disturb](#)

Toshiba Strata Vle

[Strata CIX DP-5000 series Do Not Disturb](#)

Toshiba Strata CIX DP-5000 series

This manual is also suitable for:

[Strata dk16](#)