





Asus K8V-VM Ultra Quick Start Manual



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18




•

[Table of Contents](#)

•

## Bookmarks

Available languages



A language selection menu with five options. Each option consists of a small flag icon on the left and a text label on the right. The options are: EN (English, blue bar), ES (Spanish, red bar), PT (Portuguese, green and red bar), RU (Russian, light grey bar), and CN (Chinese, red bar).


Language Code	Flag Description
EN	Flag of the United Kingdom (Union Jack)
ES	Flag of Spain (Three horizontal stripes)
PT	Flag of Portugal (Two vertical stripes)
RU	Flag of Russia (Three horizontal stripes)
CN	Flag of China (Red field with yellow stars)

More

## Quick Links

[Download this manual](#) See also: [User Manual](#)





U2467

# K8V-VM Ultra

Quick Start Guide

English



Español

Русский

Português

First Edition V1 Published March 2006

Copyright © 2006 ASUSTeK COMPUTER INC. All Rights Reserved.

15G0636480K0

[Table of Contents](#)

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Asus K8V-VM Ultra

### [Motherboard Asus K8V-VM User Manual](#)

K8v-vm user's manual (78 pages)

### [Motherboard Asus K8V-VM Ultra User Manual](#)

K8v-vm ultra user's manual for english edition (78 pages)

### [Motherboard Asus ASUS K8V SE User Manual](#)

Asus computer hardware (140 pages)

### [Motherboard Asus A8N-E Update Manual](#)

Technical information update for amd 754/939 installation in quick start guide (2 pages)

### [Motherboard Asus A8V Deluxe Quick Setup Manual](#)

K8 series quick setup guide (10 pages)

### [Motherboard Asus K8V User Manual](#)

K8v user manual (92 pages)

### [Motherboard Asus K8V-MX User Manual](#)

K8v-mx user's manual for english edition (72 pages)

### [Motherboard Asus K8V-MX User Manual](#)

Motherboard (70 pages)

### [Motherboard Asus K8V-X SE User Manual](#)

Atx motherboard (82 pages)

### [Motherboard Asus Motherboard K8V-X User Manual](#)

Asus k8v-x motherboard user manual (84 pages)

### [Motherboard Asus K8V-XE User Manual](#)

K8v-xe user's manual for english edition (86 pages)

### [Motherboard Asus K8V-XE Benutzerhandbuch](#)

Motherboard diy troubleshooting guide (86 pages)

### [Motherboard Asus K8V-F User Manual](#)

Asus motherboard user guide (66 pages)

### [Motherboard Asus K8V Deluxe User Manual](#)

K8v deluxe user manual (144 pages)

### [Motherboard Asus K8T800 Pro User Manual](#)

System board (120 pages)

### [Motherboard Asus K8AE-LM User Manual](#)

(22 pages)

## Summary of Contents for Asus K8V-VM Ultra

### [Page 1: Quick Start Guide](#)

U2467 K8V-VM Ultra Quick Start Guide English 简体中文 Español Русский Português First Edition V1  
Published March 2006 Copyright © 2006 ASUSTeK COMPUTER INC. All Rights Reserved.  
15G0636480K0...

### [Page 2: Motherboard Layout](#)

Lift up the socket lever to at least a 90° angle. WARNING! The CPU fits only in one correct orientation. DO NOT force the CPU into the socket to prevent bending the pins and damaging



ADVERTÊNCIA! O CPU apenas pode ser encaixado numa direcção. NÃO force a entrada do CPU no socket para evitar dobrar os pinos e danificar o CPU! ASUS K8V-VM Ultra...

### [Page 15: Memória Do Sistema](#)

- Para uma compatibilidade óptima, obtenha módulos de memória de vendedores qualificados. Visite o web site da ASUS para consultar a lista de Vendedores Aprovados.
- Instale sempre DIMMs com a mesma latência CAS. Para uma óptima compatibilidade, recomendamos-lhe a obtenção de módulos de memória...

[Page 16](#) Se se deparar com problemas ao nível do sistema, ou se o sistema ficar instável após alteração das definições, carregue as predefinições de configuração. Visite o web site da ASUS ([www.asus.com](http://www.asus.com)) para obter as actualizações.

[Page 18](#) [www.asus.com...](http://www.asus.com...)