



# TOSHIBA

## Toshiba StrataCT Quick Reference Manual

Digital key telephone



1  
2

--


•

Bookmarks

--

## Quick Links

[Download this manual](#) See also: [User Manual](#)



Enlarged version





Do Not Disturb

Activate

Press Do Not Disturb (LED On).

Deactivate

Press Do Not Disturb again (LED Off).

Hold

Place call on Hold

Press the Hold button.

Retrieve held call

Press the flashing line button or directory number button.

Place call on

While on a call, press Hold twice. (No

Exclusive Hold

one can accidentally pick up your call.)

Handsfree Answerback/Monitoring

Receive a

You hear a single warning tone

Handsfree

followed by the caller's voice. Without

Answerback call

lifting the handset, speak toward the telephone at a normal voice level.

Use Handsfree

1 While off-hook, on a call, hold down

Monitoring

Spkr and place the handset on-hook.

2 Release Spkr.

3 Lift the handset to resume the conversation.

Frequently Used Numbers

Number

Name

© Copyright 2000

Toshiba Information Systems (U.K.) Ltd

Telecommunication Systems Division

Toshiba Court, Weybridge Business Park

Addlestone Road, Weybridge,

Surrey KT15 2UL

CT-DKT-Q-R-G

Version 1.0

www.toshiba-europe.com

Internal Call

1 Lift the handset or press the directory number button, then dial a directory number.

2 Make a voice announcement after you hear a single tone or when the called party answers.

Message Waiting

Light Message Waiting

After reaching a busy or unanswered

LED at another station

station, press Msg or 7 to light the

Msg button.

Answer a Message

Press Msg, lift the handset. If the

Waiting at your station

message sender does not answer, hang up and repeat this step to skip to the next message.

Cancel your station's

Press a directory number button

Message Waiting light

+ #409.

Override/OCA

Busy Override or

Press 2 after dialling the busy station.

Off-hook Call

Or press 21 or 12 if the called

Announcement (OCA)

telephone allows Off-hook Call

Announce.

Busy Override or

Press 3 after reaching a busy station.

OCA (barge in)

Paging

Make Page

1 Lift the handset and press a

Announcement

directory number.

2 Enter a page zone code (below):

All Call Page group

#30

Station groups

#311~#318

All Call Page group

#39

and external page

zones

External Page

#35~#38 ...or #351~#358

zones

Zone in size -

see your System Administrator.

Redial

Redial last

1 Lift the handset, then press an

number dialled

available directory number or line.

2 Press Redial.

Save a number to

After dialling a telephone number

Redial later

(before disconnecting), press Save

Last Number.

Redial a saved

Access an outside line or press a

number

primary or phantom directory number, then press Save Last Number.

Soft Keys

LCD phone only. When active, the Mode, Page, and Scroll keys perform different actions as described by the LCD readout directly above the keys. See the Strata CT Digital Telephone User Guide for more details.

Soft Keys On

Press Mode + 71 (when phone is idle).

Soft Keys Off

Press Mode + 70 (when phone is idle).

Speed Dial

Store a Speed

1 Do not lift the handset.

Dial number

2 Press Redial.

3 Press any button labelled SD, then

enter the phone number you wish

to store; press Redial

...or

press Speed Dial (or \* ), then enter a personal or System Speed Dial code (below). Then enter the phone number you wish to store; press Redial.

Speed Dial Codes

Personal:

100~139

System:

200~999

Make a call with

Lift the handset and press the

Speed Dial

SD button

...or

lift the handset and press Speed Dial, then enter the Speed Dial code.

Digital Key

STRATA

Telephone

Quick

Reference

Guide

[Next Page](#)

1  
2

## Related Manuals for Toshiba StrataCT

[Telephone Toshiba StrataCT User Manual](#)

Electronic telephone includes lcd and direct station selection console (130 pages)

[Telephone Toshiba strata CT Installation & Maintenance Manual](#)

Digital business telephone system (385 pages)

[Telephone System Toshiba Strata CT System Administrator Manual](#)

Digital business telephone solutions (57 pages)

[Telephone Toshiba Strata CT User Manual](#)

Standard telephone (54 pages)

[Telephone System Toshiba Strata CT Digital Business Telephone Solutions Supervisor Manual](#)

Acad supervisor guide (41 pages)

[Telephone Accessories Toshiba Strata CT Manual](#)

Acad agent guide (37 pages)

[Telephone System Toshiba Strata DK Admin User Manual](#)

Digital business telephone systems release 4 (178 pages)

[Telephone System TOSHIBA STRATA CTX User Manual](#)

Dkt/ipt telephone with digital business telephone systems (139 pages)

[Telephone System Toshiba Strata CTX User Manual](#)

(38 pages)

[Telephone System Toshiba Strata CTX Manual](#)

Digital business telephone systems (60 pages)

[Telephone System Toshiba Strata DK14 System Administrator Manual](#)

Strata dk digital business telephone systems (56 pages)

[Telephone System Toshiba Strata CTX Series Installation And Maintenance Manual](#)

Digital business telephone systems (40 pages)

[Telephone System Toshiba Strata VI Series Installation Instructions Manual](#)

Electronic key telephone system (22 pages)

[Telephone System Toshiba Strata CTX Attendant Console Quick Reference Manual](#)

(8 pages)

[Telephone System Toshiba Strata CIX LUCA User Manual](#)

Messaging voice mail (36 pages)

[Telephone System Toshiba Strata CIX LVMU Installation And Programming Manual](#)

Voice processing system (36 pages)

## Summary of Contents for Toshiba StrataCT

[Page 1](#) Zone(s) depend on system size - Make a call with Lift the handset and press the © Copyright 2000 see your System Administrator. Toshiba Information Systems (U.K.) Ltd Speed Dial SD button Telecommunication Systems Division ...or Toshiba Court, Weybridge Business Park...

[Page 2](#) Introduction Automatic Busy Redial Busy No Answer Press Call Frwd Busy/NANs, enter Pick up a ringing Press Directed Pickup ...or press a the primary or phantom directory priority call, a page, directory number#5. Then press + #30. This quick reference guide applies to DKT 2500-series digital Activate After dialling a busy outside phone number to forward to;...

This manual is also suitable for:

Strata ct