

Installation Dimension Diagram - Sanyo SAP-K18AM Instruction Manual

Split system air conditioner

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37

--

•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



6. INSTALLATION DIMENSION DIAGRAM

Space to the ceiling

15cm Above

Space to the wall

- The dimensions of the space necessary for correct installation of the appliance including the minimum permissible distances to adjacent structures.


The Outdoor Unit Installation

Dimension

A

550mm

23



Installation Service

15cm

Above

300cm

Above

Air outlet side

Space to the obstruction

30cm Above

Space to the wall

Air outlet side

B

350mm

SAP-C18AM, SAP-C18AGH

15cm Above

250

cm

Above

Space to the floor

A

Models


Space to the wall

Air inlet side

Space to the wall

50cm Above

B



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
22
23
24
25
26
27
28
29

Quick Links:

[Table of Contents](#)

[Notices for Operation](#)

[Operation and Maintenance](#)

[Names and Functions of each Part](#)

[Operation of Wireless Remote Control Unit](#)

[Troubleshooting](#)

[Install Outdoor Unit](#)

[Check after Installation and Test Operation](#)

Related Manuals for Sanyo SAP-K18AM

[Air Conditioner Sanyo SAP-K9AP Instruction Manual](#)

Split system air conditioner (37 pages)

[Air Conditioner Sanyo SAP-K77RAX Technical & Service Manual](#)

Split system air conditioner (68 pages)

[Air Conditioner Sanyo SAP-K91AHA Technical & Service Manual](#)

(78 pages)

[Air Conditioner Sanyo SAP-K181AHA-S Technical & Service Manual](#)

(78 pages)

[Air Conditioner Sanyo SAP-K92A Technical & Service Manual](#)

Split system air conditioner (58 pages)

[Air Conditioner Sanyo SAP - K92AH Technical & Service Manual](#)

(52 pages)

[Air Conditioner Sanyo SAP-K91AA Technical & Service Manual](#)

(66 pages)

[Air Conditioner Sanyo SAP-K161GJA Technical & Service Manual](#)

Split system air conditioner (86 pages)

[Air Conditioner Sanyo SAP-K71GJA Technical & Service Manual](#)

Split system air conditioner (81 pages)

[Air Conditioner Sanyo SAP-K77GHAX Technical & Service Manual](#)

(164 pages)

[Air Conditioner Sanyo SAP-K71GJHA Technical & Service Manual](#)

(86 pages)

[Air Conditioner Sanyo SAP-K71GJA-S Technical & Service Manual](#)

(81 pages)

[Air Conditioner Sanyo SAP-K181GJH Technical & Service Manual](#)

Indoor/outdoor units (75 pages)

[Air Conditioner Sanyo SAP-K181AA Technical & Service Manual](#)

Split system air conditioner (66 pages)

[Air Conditioner Sanyo SAP-CMRV1426EH Technical & Service Manual](#)

(148 pages)

[Air Conditioner Sanyo SAP-KMRV74EH Installation Instructions Manual](#)

Inverter split system air conditioner (24 pages)

Related Content for Sanyo SAP-K18AM

[SAP-CMRV1923GJH Diagram Of Outdoor Unit Installation](#)

Sanyo SAP-CMRV1923GJH

[SAP-CMRV3656EH Diagram Of Outdoor Unit Installation](#)

Sanyo SAP-CMRV3656EH

[SAP-CMRV1424EH Diagram Of Outdoor Unit Installation](#)

Sanyo SAP-CMRV1424EH

[COOL Diagram Of Outdoor Unit Installation](#)

Sanyo COOL

[CMH1972A Diagram Of Outdoor Unit Installation](#)

Sanyo CMH1972A

[CM1972A Diagram Of Outdoor Unit Installation](#)

Sanyo CM1972A

[CMH1972 Diagram Of Outdoor Unit Installation](#)

Sanyo CMH1972

[CMH3172A Diagram Of Outdoor Unit Installation](#)

Sanyo CMH3172A

This manual is also suitable for:

Sap-k18amsSap-c18amSap-c18amsSap-k18aghSap-c18aghSap-kc18agh