Install Outdoor Unit - Sanyo SAP-K18AM Instruction Manual

Split system air conditioner

```
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
```

19 20 21 22 23 24	
21222324	
222324	
23 24	
24	
25	
26	
27	
28	
29	
30	
31	
32	
33	
34	
35	
36	
37	

Table of Contents










10. INSTALL OUTDOOR UNIT

10.1 Wiring Instructions for the Outdoor Unit

Regulations on wire size differ from locality. For field wiring requirements, please refer to your local electrical codes. Make sure that the installation fully complies with all local and national regulations.

- 1. Disassemble the handle on the outdoor unit right side plate. (Screw x 1pc)
- 2. Take off wire clamp, connect and fix



bank. Connect the inter-unit wiring and power line according to the drawing on the handle.

3. Fix the power connection cable with wire clamp. (Fig. 24 / 25)

Use the wire clamp to fix the signal control wire, then connect to the corresponding connector.

- 4. Be sure to size each wire allowing approx.

 10 cm longer than the required length for wiring, Store excess wiring inside the cabinet.
- 5. When connections are completed, check that all connections are correct as shown in the wiring system diagram on the handle.
- 6. Be sure to ground the unit according to your local codes.
- 7. Install back the handle. (Screw x 1pc)



(Cooling Only Model)

Blue Yellow-green Black

Wire clamp

1. 2.

Fig. 24


(Heat Pump Model)

Blue Black Brown Violet Orange

Wire clamp

Fig. 25








Table of Contents
Previous Page
Next Page

...

Quick	Links:		
Table	e of Contents		
Notio	ces for Operation		
Oper	ration and Maintenance		
Nam	es and Functions of each Part		
Oper	ration of Wireless Remote Control Unit		
Trou	bleshooting		
Insta	all Outdoor Unit		
Chec	ck after Installation and Test Operation		

Related Manuals for Sanyo SAP-K18AM

<u>Air Conditioner Sanyo SAP-K9AP Instruction Manual</u>

Split system air conditioner (37 pages)

<u>Air Conditioner Sanyo SAP-K77RAX Technical & Service Manual</u>

Split system air conditioner (68 pages)

Air Conditioner Sanyo SAP-K91AHA Technical & Service Manual

(78 pages)

<u>Air Conditioner Sanyo SAP-K181AHA-S Technical & Service Manual</u>

(78 pages)

Air Conditioner Sanyo SAP-K92A Technical & Service Manual

Split system air conditioner (58 pages)

Air Conditioner Sanyo SAP - K92AH Technical & Service Manual

(52 pages)

Air Conditioner Sanyo SAP-K91AA Technical & Service Manual

(66 pages)

Air Conditioner Sanyo SAP-K161GJA Technical & Service Manual

Split system air conditioner (86 pages)

Air Conditioner Sanyo SAP-K71GJA Technical & Service Manual

Split system air conditioner (81 pages)

<u>Air Conditioner Sanyo SAP-K77GHAX Technical & Service Manual</u>

(164 pages)

Air Conditioner Sanyo SAP-K71GJHA Technical & Service Manual

(86 pages)

Air Conditioner Sanyo SAP-K71GJA-S Technical & Service Manual

(81 pages)

Air Conditioner Sanyo SAP-K181GJH Technical & Service Manual

Indoor/outdoor units (75 pages)

Air Conditioner Sanyo SAP-K181AA Technical & Service Manual

Split system air conditioner (66 pages)

Air Conditioner Sanyo SAP-CMRV1426EH Technical & Service Manual

(148 pages)

Air Conditioner Sanyo SAP-KMRV74EH Installation Instructions Manual

Inverter split system air conditioner (24 pages)

Related Content for Sanyo SAP-K18AM

SPW-X483GH56 How To Install The Outdoor Unit

Sanyo SPW-X483GH56

26 series How To Install The Outdoor Unit

Sanyo 26 series

COOL How To Install The Outdoor Unit

Sanyo COOL

R410A How To Install The Outdoor Unit

Sanyo R410A

KS3082 How To Install The Outdoor Unit

Sanyo KS3082

COOL How To Install The Outdoor Unit

Sanyo COOL

XHS1271 How To Install The Outdoor Unit

Sanyo XHS1271

XS1872 How To Install The Outdoor Unit

Sanyo XS1872

This manual is also suitable for:

Sap-k18amsSap-c18amSap-c18amsSap-k18aghSap-c18aghSap-kc18agh