

Operation And Maintenance; Notices For Operation - Sanyo SAP-K18AM Instruction Manual

Split system air conditioner

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37

•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks






1. NOTICES FOR OPERATION

Each unit must be properly grounded with a ground (or earth) wire or through the supply wiring.

If not, please ask the qualified personnel to install.

Furthermore, do not connect each wire to the gas pipe, water pipe, drainage pipe or any other improper places.

Don't leave windows and doors open for a long time while operating



It can decrease the air conditioning capacity.

Please make sure whether the installed stand is firm enough or not.


If it is damaged, it may lead to the fall of the unit and cause the injury.



Hand Maintenance

Don't attempt to repair the air conditioner by yourself.

The wrong repair will lead to an electric shock or fire, so you should contact the SANYO service center for repair.



Don't block the air intake or outlet vents of both the outdoor and indoor units.

It can decrease the air conditioning capacity or cause a malfunction.

Do not step on the top of the outdoor unit or place things on it.

As falling off the outdoor unit can be dangerous.


Select the most appropriate temperature.

Keep room cooler than outside about

5 C.

It can help to prevent electricity wasted.

Never use or store gasoline or other flammable vapor or liquid near the air conditioner.




It is very dangerous and it may cause a fire or explosion.

If abnormal phenomenon (like burning odor, etc) occur, turn off power supply and contact SANYO service center.

Cut Off Power

If abnormal phenomenon



ManualsLib.com



damaged and cause electric
shock or fire.

2

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
2
3
4
5
6
7
8

Quick Links:

[Table of Contents](#)

[Notices for Operation](#)

[Operation and Maintenance](#)

[Names and Functions of each Part](#)

[Operation of Wireless Remote Control Unit](#)

[Troubleshooting](#)

[Install Outdoor Unit](#)

[Check after Installation and Test Operation](#)

Related Manuals for Sanyo SAP-K18AM

[Air Conditioner Sanyo SAP-K9AP Instruction Manual](#)

Split system air conditioner (37 pages)

[Air Conditioner Sanyo SAP-K77RAX Technical & Service Manual](#)

Split system air conditioner (68 pages)

[Air Conditioner Sanyo SAP-K91AHA Technical & Service Manual](#)

(78 pages)

[Air Conditioner Sanyo SAP-K181AHA-S Technical & Service Manual](#)

(78 pages)

[Air Conditioner Sanyo SAP-K92A Technical & Service Manual](#)

Split system air conditioner (58 pages)

[Air Conditioner Sanyo SAP - K92AH Technical & Service Manual](#)

(52 pages)

[Air Conditioner Sanyo SAP-K91AA Technical & Service Manual](#)

(66 pages)

[Air Conditioner Sanyo SAP-K161GJA Technical & Service Manual](#)

Split system air conditioner (86 pages)

[Air Conditioner Sanyo SAP-K71GJA Technical & Service Manual](#)

Split system air conditioner (81 pages)

[Air Conditioner Sanyo SAP-K77GHAX Technical & Service Manual](#)

(164 pages)

[Air Conditioner Sanyo SAP-K71GJHA Technical & Service Manual](#)

(86 pages)

[Air Conditioner Sanyo SAP-K71GJA-S Technical & Service Manual](#)

(81 pages)

[Air Conditioner Sanyo SAP-K181GJH Technical & Service Manual](#)

Indoor/outdoor units (75 pages)

[Air Conditioner Sanyo SAP-K181AA Technical & Service Manual](#)

Split system air conditioner (66 pages)

[Air Conditioner Sanyo SAP-CMRV1426EH Technical & Service Manual](#)

(148 pages)

[Air Conditioner Sanyo SAP-KMRV74EH Installation Instructions Manual](#)

Inverter split system air conditioner (24 pages)

Related Content for Sanyo SAP-K18AM

[SAP-KMRV93GJH Operation Functions](#)

Sanyo SAP-KMRV93GJH

[SAP-K71GJA-S Dry Operation](#)

Sanyo SAP-K71GJA-S

[KMS0912 Operation With The Remote Control Unit](#)

Sanyo KMS0912

[SAP-K71GJHA Dry Operation](#)

Sanyo SAP-K71GJHA

[MINI ECO-i XHX1252 Operation](#)

Sanyo MINI ECO-i XHX1252

[STW-2 Series Defrosting Operation \(Heating\)](#)

Sanyo STW-2 Series

[SI-10T3SDIA Series Operation Conditions](#)

Sanyo SI-10T3SDIA Series

[Mini ECO-i CHXR03652 Operation Of Solenoid Valves](#)

Sanyo Mini ECO-i CHXR03652

This manual is also suitable for:

Sap-k18amsSap-c18amSap-c18amsSap-k18aghSap-c18aghSap-kc18agh