




# Teletext Operation - Sanyo LCD-27XA2 Instruction Manual

Lcd colour television



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
Table Of Contents  
29




•

•

## Bookmarks







## Teletext Operation


### Reveal switch

To reveal hidden items on the text page e.g. a hidden answer to a quiz question.

Direct access to a page

To select a page number directly using the (0-9)

NUMERIC buttons. For example, to select page 301, press



3, then 0 and then 1.

Sub page access

Some ~~text pages are made up~~ of several sub pages which rotate automatically. If you wish to view page-4, press the Sub Page button, and "S----" will appear. Then enter "0004" using NUMERIC buttons.

Teletext / TV selector

To switch TV, TEXT and PAT (Picture and Teletext) mode.

TELETEXT  
DISPLAY

(Picture and Teletext mode)

Hold

To stop sub pages from changing.

Teletext language selection

You can select a teletext language. Please return to the TV mode (See Setting menu.)

Teletext brightness level

You can change the teletext brightness level. Please return to the TV mode. (See Picture Adjustments.)

Sound volume control in teletext mode.

In teletext mode, sound volume and sound muting can be controlled. However they are not displayed on the screen

Teletext reception

If your aerial signal is poor, the teletext reception may be poor.



## 20

Cancel

To view the TV picture in the teletext mode while waiting for sub page to change or page to update. Press again to



ManualsLib.com

return to teletext mode. (Note:  
The page number will appear  
when the page is updated.)

Up/down page access

To select the next or previous  
page number.

Size switch

Either the top half or the  
bottom half of the page can  
be expanded.

Index page selector

To select one of the teletext  
index pages.

Direct access to subject  
cs

headings

Coloured boxes are displayed  
at the bottom of the screen.

The 4 coloured buttons give  
access to the corresponding  
subjects or pages.




Table of Contents

[Previous Page](#)  
[Next Page](#)

1  
...  
17  
18  
19  
20  
21  
22  
23  
24

Quick Links:

[Instruction Manual](#)

[Control Panel](#)

[Menu Operation](#)

[Connecting Other Equipment](#)

[Specifications](#)

## Related Manuals for Sanyo LCD-27XA2

[TV Sanyo LCD-27XA2 Service Manual](#)

Lcd television (40 pages)

[Lcd television Sanyo LCD-32XA2 Service Manual](#)

Sanyo lcd-32xa2 lcd television (40 pages)

[LCD TV Sanyo LCD-32XL2 Service Manual](#)

(48 pages)

[LCD TV Sanyo LCD-27XR1/AU Service Manual](#)

(20 pages)

[LCD TV Sanyo LCD-22XR9DA Instruction Manual](#)

Sanyo lcd tv instruction manual (40 pages)

[LCD TV Sanyo LCD-26XR9DA Instruction Manual](#)

Sanyo lcd tv instruction manual (38 pages)

[LCD TV Sanyo LCD-26XR9DA Instruction Manual](#)

(33 pages)

[LCD TV Sanyo LCD-19E3 Instruction Manual](#)

Sanyo lcd tv instruction manual (27 pages)

[LCD TV Sanyo LCD-24K50 Instruction Manual](#)

(28 pages)

[LCD TV SANYO LCD-24XR10F Instruction Manual](#)

(38 pages)

[LCD TV Sanyo LCD-24XR11F Instruction Manual](#)

Sanyo lcd-24xr11f lcd tv instruction manual (40 pages)

[LCD TV Sanyo LCD-24XAZ10F Service Manual](#)

(41 pages)

[LCD TV Sanyo LCD-15CA1Z Instruction Manual](#)

(36 pages)

[LCD TV Sanyo LCD-22XR7S Service Manual](#)

(37 pages)

[LCD TV Sanyo LCD-22XR11F Service Manual](#)

(38 pages)

[LCD TV Sanyo LCD-22XR9DKH Service Manual](#)

(46 pages)

## Related Content for Sanyo LCD-27XA2

[LCD22XR9DZ Teletext & Subtitle](#)

Sanyo LCD22XR9DZ

[LCD-32XR12F Teletext & Subtitle](#)

Sanyo LCD-32XR12F

[LCD-40XZ11F Teletext & Subtitle](#)

Sanyo LCD-40XZ11F

[LCD-22XR11F Teletext & Subtitle](#)

Sanyo LCD-22XR11F

[LED-22XR11F Teletext & Subtitle](#)

Sanyo LED-22XR11F

[LCD-26XR11 Teletext & Subtitle](#)

Sanyo LCD-26XR11

[LCD-40XZ10F Teletext & Subtitle](#)

Sanyo LCD-40XZ10F

[LCD-32XZ10 Teletext & Subtitle](#)

Sanyo LCD-32XZ10

This manual is also suitable for:

[Lcd-32xa2](#)