



Asus T1 Series User Manual

Lcd tv monitor t1 series

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34

--

-

[Table of Contents](#)


•

Bookmarks

--

[Download this manual](#)

Quick Links



LCD TV Monitor



T1 Series

User's Manual



E

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus T1 Series

[Monitor Asus 22T1EH User Manual](#)

T1 series (38 pages)

[Monitor Asus T1 Series User Manual](#)

(34 pages)

[Monitor Asus 22T1E User Manual](#)

T1 series (36 pages)

[Monitor Asus TUF Gaming VG24V Series User Manual](#)

(27 pages)

[Monitor Asus TUF Gaming VG27V Series User Manual](#)

(31 pages)

[Monitor Asus VG259 Series User Manual](#)

Tuf gaming monitor (31 pages)

[Monitor Asus PA329CRV Series User Manual](#)

(38 pages)

[Monitor Asus BE279QSK Series User Manual](#)

(40 pages)

[Monitor Asus VG1A Series User Manual](#)

Tuf gaming monitor (35 pages)

[Monitor Asus ROG SWIFT PG38UQ User Manual](#)

(45 pages)

[Monitor Asus VT207 Series User Manual](#)

(27 pages)

[Monitor Asus VE278H User Manual](#)

User manual (23 pages)

[Monitor Asus VZ2491R Series User Manual](#)

(29 pages)

[Monitor Asus VG32AQA1A Series User Manual](#)

Tuf gaming monitor (32 pages)

[Monitor Asus VP278 Series User Manual](#)

(28 pages)

[Monitor Asus VG249Q3R Series User Manual](#)

(27 pages)

Summary of Contents for Asus T1 Series

[Page 1](#) LCD TV Monitor T1 Series User's Manual...

[Page 2](#) Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

[Page 3: Table Of Contents](#)

Electronic Programme Guide (EPG).....14 Programme List14 On-Screen Display (OSD) Menu 15 3.1.1 How to reconfigure15 3.1.2 OSD menu introduction.....16 Specifications Summary21 Troubleshooting (FAQ)

Page 5: Safety Information

Page 6: Care And Cleaning

Page 7: Where To Find More Information

Page 8: Recycling Place

Page 9: North America

Page 10

[illegible]

Page 11: Welcome

Thank you for purchasing the ASUS TV Monitor T1 Series LCD display! The latest LCD display

from ASUS provides a host of features that enhance your viewing experience. It integrates a number of various media input interfaces and a built-in TV tuner to meet your needs on a display for working as well as entertainment.

[Page 12: Display Introduction](#)

Press this button to turn the display on, off, or stand-by. ■ The colour of the power indicator is as the below table. Status Description Blue Stand-by Remote receiver ■ The display receives the signal from the remote controller here. ASUS LCD TV Monitor T1 Series...

[Page 13: Top View](#)

To switch to the next programme ■ To choose the right item of the OSD menu ■ To choose the next mode in Splendid™ mode selection or the next source in Input source selection ASUS LCD TV Monitor T1 Series...

[Page 14](#) Input source selection Source button ■ To switch among the input signal sources of ATV, DTV, SCART, Component, VGA, HDMI, Video, and S-Video ■ To exit from OSD menu or from Splendid mode selection ASUS LCD TV Monitor T1 Series...

[Page 15: Rear View](#)

1.3.3 Rear view 22T1E & 24T1E ASUS LCD TV Monitor T1 Series...

[Page 16](#) 14. CI card slot for CI (Common Interface) card from your CAM (Conditional Access Module, generally used for Pay per View services) provider 15. Headphone jack to output audio signal to headphone 16. Service port for manufacturer use ONLY 17. Kensington Lock ASUS LCD TV Monitor T1 Series...

[Page 17: Remote Controller Introduction](#)

7 meters and within 30 degree to the left and to the right. ■ Dispose of used batteries in a recycle bin to prevent from environment pollution. ASUS LCD TV Monitor T1 Series...

[Page 18](#) Teletext size 18. Electronic Program Guide; also Teletext reveal 19. Broadcast information; also Teletext index 20. Display or hide the time; also Teletext sub-page 21. Stereo sound mode; also Teletext cancel 22. Display digital subtitle ASUS LCD TV Monitor T1 Series...

[Page 19: Assembling The Display](#)

Hold the stand to prevent the monitor from falling when you change its angle. ■ You can adjust the display's angle from -5° - 15°. It is normal that the monitor slightly shakes while you adjust the viewing angle. ASUS LCD TV Monitor T1 Series...

[Page 20: Connecting The Display](#)

Turning the Display On Press the power button. See section 1.3 Display Introduction for the location of the power button. The power indicator lights up in blue to show that the monitor is ON. ASUS LCD TV Monitor T1 Series...

[Page 21: Setting The Monitor](#)

Modes not listed in the table may possibly not be supported. ■ Press button for 2 - 3 seconds if noise, trembling, or picture offset appears on the screen while VGA input in use. ASUS LCD TV Monitor T1 Series...

[Page 22: Setting The Television](#)

Select "Auto Programme" and choose the country of the broadcasting system. Select "Start" to scan all the available channels and store them in the memory. ■ For further information of setting the TV, please read the chapter 3.1.2. ASUS LCD TV Monitor T1 Series...

[Page 23: Using Teletext](#)

Teletext Reveal to reveal and to hide the concealed information, such as answer of riddles. ■ Teletext Sub-Page to select a sub-page in Teletext and to exit from this function. ■ Teletext Cancel to display the broadcast while searching for a certain Teletext page. ASUS LCD TV Monitor T1 Series...

Page 24: Electronic Programme Guide (Epg)

You can control the favourite programme list only by remote controller. The key pad on the display set does not provide with such functions. Please read chapter 3.1.2 Programme Edit for specifying your favourite programmes. ASUS LCD TV Monitor T1 Series...

Page 25: On-Screen Display (Osd) Menu

MENU button. Repeat step 2 and 3 to adjust any other function. To exit from the OSD menu, press the key on the key pad of the display set EXIT button on the remote controller. ASUS LCD TV Monitor T1 Series...

Page 26: Osd Menu Introduction

OSD Time Out: to specify the idle time of displaying the OSD menu before it is deactivated. ■
Reset All: to restore all the settings back to the factory default. Password is required if “Lock System” is on. ASUS LCD TV Monitor T1 Series...

Page 27 CI Information: To display the information of your CAM, Conditional Access Module, in the CI card slot. CAM is not an accessory of this product. It is generally provided by your Pay-TV services provider. ASUS LCD TV Monitor T1 Series...

Page 28 In user's mode, you may adjust the level of the red, green, and blue to define your preferred white colour. ■ **ASCR:** to switch on and off the ASUS Smart Contrast Ratio function. ■ **Noise Reduction:** to specify the intense of noise reduction function among high, moderate, low, and off.

Page 29 Balance: to adjust the sound balance of the speakers to your preferred levels ■ Auto Volume: to automatically keep the volume level equal even if changing programmes ■ Surround Sound: to turn on and off the simulated surround sound system ASUS LCD TV Monitor T1 Series...

Page 30 Time Zone: to specify your time zone. ■ Sync Time: to automatically get time information from broadcasting signal ■ Sleep Timer: to set a countdown of 15, 30, 60, 90, 120, 180, 240 minutes till the display automatically switches off. ASUS LCD TV Monitor T1 Series...

Page 31: Specifications Summary

NTSC 3.58, 4.43 (video-in only) Channel Coverage Analogue 48.25 – 855.25 MHz Digital VHF Band III (177.5 – 226.5 MHz) UHF E21 – E69 (474 – 858 MHz) Specifications are subject to change without prior notice. ASUS LCD TV Monitor T1 Series...

Page 32 NTSC 3.58, 4.43 (video-in only) Channel Coverage Analogue 48.25 – 855.25 MHz
Digital VHF Band III (177.5 – 226.5 MHz) UHF E21 – E69 (474 – 858 MHz) Specifications are
subject to change without prior notice. ASUS LCD TV Monitor T1 Series...

[Page 33: Troubleshooting \(Faq\)](#)

Check the antenna is undamaged ■ Check the location and direction of the antenna ■ Ensure the antenna not too old. PC screen image not ■ Use “Auto Adjust” function centred or sized properly ASUS LCD TV Monitor T1 Series...

Page 34

[illegible]

Monitor T1 Series...	ASUS LCD TV

This manual is also suitable for:

22t1e24t1e