





## Sanyo AWD-D800T Instruction Manual

Drum type front loading



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22

---

•

Bookmarks

[Download this manual](#)

## Quick Links



INSTRUCTION MANUAL



---

AWD-D



[Next Page](#)

1  
2  
3  
4  
5

# Related Manuals for Sanyo AWD-D800T

## [Washer/Dryer Sanyo SW-225AP Service Manual](#)

Twin-tup washer/ spin dryer (10 pages)

## Summary of Contents for Sanyo AWD-D800T

[Page 7](#) Request of installing the Machine from the wall ° The front side and up side of washing machine should be free. ° Place washing machine at the location that distance from the wall is more than dimension of table as below: (This problem could cause abnormal vibration or sound). NOTE: Distance from wall (mm) Location...

[Page 8](#) 4. For appliances with ventilation openings in the base, that a carpet must not obstruct the openings. 5. That the appliance must not be installed behind a lockable door, a sliding door or a door with a hinge on the opposite side to that of the washing machine, in such a way that am full opening of the washing machine door is restricted.

[Page 16](#) Items such as foam rubber (latex foam), shower caps, waterproof textiles, rubber backed articles and clothes with pillows fitted with foam rubber pads should not be dried in the washing machine. The final part of a washing machine cycle occurs without heat (cool down cycle) to ensure that the items are left at a temperature that ensures that the items will not be damaged.

[Page 19](#) 5. The lint must not to be allowed to accumulate around the washing machine (not applicable for appliances intended to be vented to the exterior of the building).

This manual is also suitable for:

[Awd-d800ht](#)