

Dividing A Title - Toshiba D-VR660KU Owner's Manual

Dvd video recorder and video cassette recorder

1

2

3

4

5

Table Of Contents

6

7

8

9

10

11

12

13

14

15


16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133



•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



EDITING DISCS

Dividing a Title

Playlist

You can divide one title into two new titles.

OPEN/
INPUT

CLOSE

SELECT

.@/:

ABC

GHI

JKL

PQRS

TUV

SPACE

DTV/TV

SETUP

DISC MENU

DISC MENU

ENTER

ENTER

CLEAR

INSTANT

SKIP

REV

REV

PLAY


PLAY

SKIP


Dividing a Title



You can divide one title into two new titles.



3 Use [▲ / ▼] to see
press [ENTER].
e.g.) VR mode DVD-R'



SKIP
STOP
STOP
PAUSE
PAUSE
DUBBING
REPEAT
TIMER SET
SE-R0294

EDITING DISCS

Dividing a Title

Press [DVD].



1

You can divide one title into two new titles.

In stop mode, press [TOP MENU].

• For VR mode DVD-RW, press [DISC MENU] to select "Playlist".

Use [K / L / s / B] to select a desired

2


title, then press [ENTER].

Note

• You cannot divide a title of the disc when the number of recording titles reaches the maximum of 99 (-RW) or 49 (+RW), and the number of recording chapters reaches the maximum of 999 (-RW) or 254 (+RW).

EDITING DISCS

HDMI
DEF
CH
MNO
WXYZ
TIMER
PROG.
DISPLAY
AUDIO
TOP MENU
TOP MENU
RETURN
RETURN
1.3x/0.8x
TIME SLIP
PLAY
FWD
FWD
SKIP
SKIP
VCR
DVD
DVD
REC MODE
REC
SEARCH
ZOOM



3

Use [▲ / ▼] to se
press [ENTER].

e.g.) VR mode DVD-R



4

Use [SKIP ◀◀], [S
[FWD ▶▶], [PAU
to decide the po
divide the title.

5

Use [▲ / ▼] to se
then press [ENTE

6

Use [▲ / ▼] to se
[ENTER].

e.g.) VR mode DVD-R



The title will be divid
Both title names are i
For DVD+RW: Data w
momer



This operation m
awhile to be com

For VR mode DVD-RV

Use [K / L] to select

1

Press [DVD].

In stop mode, press [TOP MENU].

• For VR mode DVD-RW, press [DISC MENU] to select "Playlist".

3

press [ENTER].

2


Use [▲ / ▼ / ◀ / ▶] to select a desired title, then press [ENTER].

EDITING DISCS

Dividing a Title



You can divide one title into two new titles.



e.g.) VR mode DVD-RW playlist

Title List
 JAN/ 1/08 12:00AM
 CH10
 LP
 12:00AM (2:00:00)
 JAN/ 1/08
 1
 2
 Play From Start
 Edit
 Title Delete
 4
 5

4

Use [SKIP], [SKIP], [FWD D], [PAUSE F] and [PLAY B] to decide the point at which you will divide the title.
 Use [K / L] to select "Title Dividing",

5

then press [ENTER].
 Use [K / L] to select "Yes", then press

6

[ENTER].
 e.g.) VR mode DVD-RW playlist

Edit - Title Dividing
 1
 JAN/ 1/08 12:00AM CH10 LP

The title will be divided into two new titles.
 Both title names are identical.

For DVD+RW: Data will be written onto the disc momentarily.

1 Press [DVD].
In stop mode, press [TOP MENU].
This operation may take awhile to be completed: For VR mode DVD-RW, press [DISC MENU] to select "Playlist".
 For VR mode DVD-RW: Proceed to step 2.


Press [RETURN] or [STOP C] to exit.

2

Use [▲ / ▼ / ◀ / ▶] to select a desired title, then press [ENTER].

3

Use [▲ / ▼] to select a title, then press [ENTER].
 e.g.) VR mode DVD-RW



4


Use [SKIP ◀◀], [SKIP ▶▶], [PAUSE F] and [PLAY B] to decide the point at which you will divide the title.

5

Use [▲ / ▼] to select a title, then press [ENTER].

6

Use [▲ / ▼] to select a title, then press [ENTER].
 e.g.) VR mode DVD-RW



The title will be divided into two new titles.
 Both title names are identical.

For DVD+RW: Data will be written onto the disc momentarily.



This operation may take awhile to be completed.

For VR mode DVD-RW: Proceed to step 2.

7

EDITING DISCS

Dividing a Title

Data will be written on the disc temporarily.

This operation may take

awhile to be completed.



You can divide one title into two new titles.

CH10 LP
3
6
1/2

], [REV E],

G

Yes
No
1 : 25 : 47
90%

EN

91




Table of Contents

3

Use [▲ / ▼] to select
press [ENTER].

e.g.) VR mode DVD-R



[Previous Page](#)
[Next Page](#)

1
...
88
89
90
91
92
93
94
95

Quick Links:

[Connection to a Tv with an...](#)

Related Manuals for Toshiba D-VR660KU

[Cassette Player Toshiba D-VR660KU Owner's Manual](#)

Dvd video recorder / video cassette recorder (133 pages)

[DVD VCR Combo Toshiba D-VR650KU Owner's Manual](#)

Dvd video recorder / video cassette recorder (123 pages)

[DVD VCR Combo Toshiba D-VR660 Specifications](#)

Dvd recorder/vcr combo with built-in digital tuner (2 pages)

[DVD VCR Combo Toshiba D-VR610KU Owner's Manual](#)

Dvd video recorder / video cassette recorder (126 pages)

[DVD VCR Combo Toshiba DVR610 - DVDr/ VCR Combo Service Manual](#)

Dvd video recorder /video cassette recorder (87 pages)

[DVD VCR Combo TOSHIBA D-V610KU Owner's Manual](#)

Dvd video recorder / video cassette recorder (126 pages)

[DVD VCR Combo Toshiba DVR620KU Owner's Manual](#)

Dvd video recorder / video cassette recorder (113 pages)

[DVD VCR Combo Toshiba DVR670KU Owner's Manual](#)

Dvd video recorder / video cassette recorder (124 pages)

[DVD VCR Combo Toshiba D-VR600 Owner's Manual](#)

Hi-fi vcr & dvd video recorder (80 pages)

[DVD VCR Combo Toshiba DVR620KU Owner's Manual](#)

Dvd video recorder / video cassette recorder (113 pages)

[DVD VCR Combo Toshiba DVR620KU Owner's Manual](#)

Dvd video recorder / video cassette recorder (124 pages)

[DVD VCR Combo Toshiba DVR670KU Owner's Manual](#)

Dvd video recorder/video cassette recorder (126 pages)

[DVD VCR Combo Toshiba D-VR600KU Owner's Manual & Installation Instructions](#)

Hi-fi vcr & dvd video recorder (80 pages)

[DVD VCR Combo Toshiba DVR620KC Owner's Manual](#)

Dvd video recorder / video cassette recorder (106 pages)

[DVD VCR Combo Toshiba D-VR60DTKF Service Manual](#)

Dvd video recorder /video cassette recorder (119 pages)

[DVD VCR Combo Toshiba D-VR17KB Owner's Manual](#)

Dvd video recorder/video cassette recorder (83 pages)

Related Content for Toshiba D-VR660KU

[RDXV60KB Dividing A Title](#)

Toshiba RDXV60KB

[DVR20KB Dividing A Title](#)

Toshiba DVR20KB

[DVR670KU Dividing A Title](#)

Toshiba DVR670KU

[DVR620KU Dividing A Title](#)

Toshiba DVR620KU

[DKVR60KU Dividing A Title](#)

Toshiba DKVR60KU

[D-VR650KU Dividing A Title](#)

Toshiba D-VR650KU

[D-VR610KU Dividing A Title](#)

Toshiba D-VR610KU

[RD-XV48DTKF Dividing A Title](#)

Toshiba RD-XV48DTKF