



# Table Of Contents; Check Of Density Limit; Precautions For Installation Using New Refrigerant; New Refrigerant R410A Cannot Be Used For Earlier Models - Sanyo R410A Installation Instructions Manual

W-3way eco-i system air conditioner



1

2

3

4

5

Table Of Contents

6

7

8

9

10

11

12

13

14

15

16

17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54

• PAGE

6

OF 54 GO

•

[Table of Contents](#)

•

## Bookmarks







<b>IMPORTANT!</b> .....	<b>2</b>
<a href="#">Please Read Before Starting</a>	
<a href="#">Check of Density Limit</a>	
<a href="#">Precautions for Installation Using New Refrigerant</a>	
<a href="#">New refrigerant R410A cannot be used for earlier models</a>	
<b>1. GENERAL</b> .....	<b>7</b>
<a href="#">1-1. Tools Required for Installation (not supplied)</a>	
<a href="#">1-2. Accessories Supplied</a>	
<a href="#">1-3. Type of Copper Tube and Insulation Material</a>	
<a href="#">1-4. Additional Materials Required for Installation</a>	
<a href="#">1-5. Tubing Length</a>	
<a href="#">1-6. Tubing Size</a>	
<a href="#">1-7. Straight Equivalent Length of Joints</a>	
<a href="#">1-8. Additional Refrigerant Charge</a>	
<a href="#">1-9. System Limitations</a>	

[1-10. Installation Standards](#)  
[1-11. Check of Limit Density](#)  
[1-12. Installing Distribution Joint](#)  
[1-13. Optional Distribution Joint Kits](#)  
[1-14. Optional Solenoid Valve Kit](#)  
[1-15. Example of Tubing Size Selection and Refrigerant Charge Amount](#)  
**2. SELECTING THE INSTALLATION SITE ..... 20**

[2-1. Outdoor Unit](#)  
[2-2. Precautions When Installing in Heavy Snow Areas](#)  
[2-3. Dimensions of Wind Ducting](#)  
[2-4. Dimensions of Snow Ducting](#)  
**3. HOW TO INSTALL THE OUTDOOR UNIT ..... 24**

[3-1. Transporting](#)  
[3-2. Installing the Outdoor Unit](#)  
[3-3. Remove the Brackets Used for Transport](#)  
[3-4. Routing the Tubing](#)  
[3-5. Prepare the Tubing](#)  
[3-6. Connect the Tubing](#)

**4. ELECTRICAL WIRING ..... 28**

[4-1. General Precautions on Wiring](#)  
[4-2. Recommended Wire Length and Wire Diameter for Power Supply System](#)  
[4-3. Wiring System Diagram](#)

**CONTENTS**

Page

**5. HOW TO PROCESS TUBING ..... 32**

[5-1. Connecting the Refrigerant Tubing](#)  
[5-2. Connecting Tubing Between Indoor and Outdoor Units](#)  
[5-3. Insulating the Refrigerant Tubing](#)  
[5-4. Taping the Tubes](#)  
[5-5. Finishing the Installation](#)

**6. AIR PURGING ..... 36**

■ [Air Purging with a Vacuum Pump \(for Test Run\) Preparation](#)

**7. TEST RUN ..... 39**

[7-1. Preparing for Test Run](#)  
[7-2. Test Run Procedure](#)  
[7-3. Main Outdoor Unit PCB Setting](#)  
[7-4. Auto Address Setting](#)  
[7-5. Remote Controller Test Run Settings](#)  
[7-6. Caution for Pump Down](#)  
[7-7. Meaning of Alarm Messages](#)

[Previous Page](#)  
[Next Page](#)

1  
...  
3  
4  
5  
**6**  
7  
8  
9  
10

Quick Links:

[Remote Controller Test Run Settings](#)

[Meaning of Alarm Messages](#)

## Related Manuals for Sanyo R410A

[Air Conditioner Sanyo PW-UMR184EXH56 Installation And Operation Manual](#)

Eco-i system air conditioner (36 pages)

[Air Conditioner Sanyo ECO-i AHX0752 Technical Data Manual](#)

(265 pages)

[Air Conditioner Sanyo MINI ECO-i XHX1252 Service Manual & Test Run Service Manual](#)

(190 pages)

[Air Conditioner Sanyo ECO-i CHDZR07263 Series Service Manual](#)

(146 pages)

[Air Conditioner Sanyo CHDXR09663\\* Service Manual](#)

2-way eco-i multi system (142 pages)

[Air Conditioner Sanyo CHDZ07263 Service Manual](#)

(128 pages)

[Air Conditioner Sanyo AHX0752 Service Manual](#)

W-2way eco-i multi system (114 pages)

[Air Conditioner Sanyo W-3WAY ECO-i 85464369098000 Installation Instructions Manual](#)

W-3way eco-i system air conditioner (106 pages)

[Air Conditioner Sanyo 85464359982001 Installation Instructions Manual](#)

W-2way system air conditioner (96 pages)

[Air Conditioner Sanyo Mini ECO-i CHXR03652 Service Manual](#)

(93 pages)

[Air Conditioner Sanyo Mini ECO-i 85464359981002 Installation Instructions Manual](#)

Sanyo air conditioner installation instructions (90 pages)

[Air Conditioner Sanyo XM18AAB Installation Instructions Manual](#)

W-2way system air conditioner (50 pages)

[Air Conditioner Sanyo ECO R410A Installation Instructions Manual](#)

Eco-i system air conditioner (48 pages)

[Air Conditioner Sanyo THX2452 User Manual](#)

(4 pages)

[Air Conditioner Sanyo DHX4852 Manual](#)

Indoor unit (4 pages)

[Air Conditioner Sanyo THX1852 Manual](#)

Indoor unit (4 pages)

## Related Content for Sanyo R410A

[CM1812 / KMS0912 \(x2\) Table Of Contents](#)

Sanyo CM1812 / KMS0912 (x2)

[XS3632 / C3632 Table Of Contents](#)

Sanyo XS3632 / C3632

[XS2422 Table Of Contents](#)

Sanyo XS2422

[SAP91KC Table Of Contents](#)

Sanyo SAP91KC

[KS2432A Table Of Contents](#)

Sanyo KS2432A

[PO811 Table Of Contents](#)

Sanyo PO811

[KMS1212 Table Of Contents](#)

Sanyo KMS1212  
[C4272R Table Of Contents](#)  
Sanyo C4272R

This manual is also suitable for:

[Xhx1252Xhx1852Xhx2452Xhx3652Xmhx1252Xmhx1852](#) ... [Show all](#)