

Specifications Of Electrical Parts - Toshiba RAS-13SKV-E Service Manual

Indoor/outdoor unit, split type air conditioner

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119

120



•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



6. SPECIFICATIONS OF ELECTRICAL PARTS

6-1. Indoor Unit

Parts name

No.

13SKV-E

Fan motor

1				
10SKVR-E, 13SKVR-E (for indoor)				
16SKV-E, 16SKVR-E				
2				
Room temp. sensor (TA-sensor)				

3

Heat exchanger temp. sensor (TC-sensor)

4

Louver motor

6-2. Outdoor Unit

Parts name

No.

1				
Reactor				
2				
Outdoor fan motor				
3				
Suction temp. sensor (TS sensor)				
4				
Discharge temp. sensor (TD sensor)				
5				
Outside air temp. sensor (TO sensor)				
6				

Heat exchanger temp. sensor (TE sensor)

7

Terminal block (6P)

10SAVR-E, 13SAV-E

8

Compressor

13SAVR-E, 16SAV-E, 16SAVR-E

9				
COIL FOR P.M.V.				
10				
Coil for 4-way valve				
11				
Compressor thermo				
Type				
MMF-240-20-4B				
AFS-220-20-4AR				
ICF-340-30-2B				
(-)				
(
)				
-				
MP24Z3T				
Model name				
CH-57				
ICF-140-43-4R				
(Inverter attached)				
(Inverter attached)				

ManualsLib.com

(Inverter attached)

(Inverter attached)

DA89X1C-23FZ

DA111A1F-20F1

C12A-01-R

VHV

PW-2AL

- 20 -

Specifications

AC240/220V 20W

AC240V, 20W

DC 340V, 30W

10k

at 25°C

Ω

10kΩ at 25°C

Output (Rated) 1W, 16 poles, DC12V

Rating

L = 10mH, 16A

DC140V, 43W

10kΩ (25°C)

62kΩ (20°C)

10kΩ (25°C)

10kΩ (25°C)

30A, AC600V

3-phases 4-poles 750W

DC12V

AC220-240V

OFF : 125±4°C, ON : 90±5°C

Manualslib.com

Table of Contents

[Previous Page](#)
[Next Page](#)

1
...
17
18
19
20
21
22
23
24

Quick Links:

[Service Manual](#)

[Specifications](#)

[How to Diagnose the Trouble](#)

Chapters

[Service Manual 2](#)

[Auto Restart Function/Remote Controller and Its Functions 31](#)

Related Manuals for Toshiba RAS-13SKV-E

[Air Conditioner Toshiba RAS-13SKV-E Service Manual](#)

Split type indoor/outdoor unit (121 pages)

[Air Conditioner Toshiba RAS-B10SKVP-E Service Manual](#)

Split type air conditioner (119 pages)

[Air Conditioner Toshiba RAS-B10SKVP-E Owner's Manual](#)

Split type air conditioner (91 pages)

[Air Conditioner Toshiba RAS-B10SKVP-E Installation Manual](#)

(19 pages)

[Air Conditioner Toshiba RAS-B10SKVP-E Installation Manual](#)

(148 pages)

[Air Conditioner Toshiba RAS-B10SKVP-E Service Manual](#)

(120 pages)

[Air Conditioner Toshiba RAS-16SKVP-ND Owner's Manual](#)

(230 pages)

[Air Conditioner Toshiba RAS-10 SKV Series Owner's Manual](#)

(8 pages)

[Air Conditioner Toshiba RAS-10 SKV Series Owner's Manual](#)

Air conditioner (split type) (4 pages)

[Air Conditioner Toshiba RAS-13SKHP-E Service Manual](#)

Split wall type air conditioner (70 pages)

[Air Conditioner Toshiba RAS-10SKH-ES Service Manual](#)

Split wall type (68 pages)

[Air Conditioner Toshiba RAS-B10 Series Installation Manual](#)

(68 pages)

[Air Conditioner Toshiba RAS-10S3KV-E Owner's Manual](#)

(7 pages)

[Air Conditioner Toshiba RAS-13S3KV-E Service Manual](#)

(108 pages)

[Air Conditioner Toshiba RAS-24S3KHS-EE Owner's Manual](#)

(8 pages)

[Air Conditioner Toshiba RAS-10SKP Series Owner's Manual](#)

(8 pages)

Related Content for Toshiba RAS-13SKV-E

[RAV-GV1101AT8P-TR Specifications Of Electrical Parts](#)

Toshiba RAV-GV1101AT8P-TR

[RAV-GM562ATP-TR Specifications Of Electrical Parts](#)

Toshiba RAV-GM562ATP-TR

[RAV-HM301SDTY-E Specifications Of Electrical Parts](#)

Toshiba RAV-HM301SDTY-E

[RAS-24J2KVG-UA Specifications Of Electrical Parts](#)

Toshiba RAS-24J2KVG-UA

[RAV-GV1101ATP-TR Specifications Of Electrical Parts](#)

Toshiba RAV-GV1101ATP-TR

[RAV-GM901CTP Series Specifications Of Electrical Parts](#)

Toshiba RAV-GM901CTP Series

[RAS-B07G3KVSG-E Specifications Of Electrical Parts](#)

Toshiba RAS-B07G3KVSG-E

[RAV-GM561ATP-NZ Specifications Of Electrical Parts](#)

Toshiba RAV-GM561ATP-NZ

This manual is also suitable for:

[Ras-13sav-eRas-16skv-eRas-10savr-eRas-13skvr-eRas-13savr-eRas-16sav-e](#) ... [Show all](#)