





## Whirlpool LXR7144EQ2 Parts List

Whirlpool automatic washer parts list



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
Table Of Contents  
15

• PAGE

1



- 

[Table of Contents](#)

•

## Bookmarks

## Quick Links

[1 Top and Cabinet Parts](#)

[2 Controls and Rear Panel Parts](#)

[3 Agitator, Basket and Tub Parts](#)

[4 Brake, Clutch, Gearcase, Motor and Pump Parts](#)

[5 Optional Parts \(Not Included\)](#)

[Download this manual](#)





# TOP AND CABINET PARTS




For Models: LXR7144EQ2, LXR7144EZ2  
AUTOMATIC WASHER

(Designer White) (Designer Almond)

3-00 Litho In U.S.A. (rcg)

1

Part No. 881645 Rev.A



## Table of Contents

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Whirlpool LXR7144EQ2

[Washer WHIRLPOOL LSR8433KQ0 Use & Care Manual](#)

2 speed automatic wahser (12 pages)

[Washer WHIRLPOOL LXR9245EQ2 Use & Care Manual](#)

Two speed automatic washers (15 pages)

[Washer Whirlpool LSR5121JQ0 Use & Care Manual](#)

One speed automatic washers (11 pages)

[Washer Whirlpool LXR9445JQ0 Parts List](#)

Whirlpool automatic washer parts list (15 pages)

[Washer Whirlpool LXR6432JQ2 Parts List](#)

Automatic washer (15 pages)

[Washer Whirlpool LSQ9600LW0 User Instructions](#)

(25 pages)

[Washer Whirlpool LSR7300PQ2 User Instructions](#)

(24 pages)

[Washer Whirlpool LA5200XT Use & Care Manual](#)

Large capacity two speed automatic washers (16 pages)

[Washer Whirlpool LA5530XP Use & Care Manual](#)

Design 2000 large capacity (16 pages)

[Washer Whirlpool LA6500XP Use & Care Manual](#)

Estate series large capacity top-load automatic washer (16 pages)

[Washer Whirlpool LA7000XM Use & Care Manual](#)

Super capacity automatic washer (16 pages)

[Washer Whirlpool LA7700XW Use And Care Manual](#)

Large capacity variable two speed automatic washer (16 pages)

[Washer Whirlpool LA5530XK Use And Care Manual](#)

Regular capacity (13 pages)

[Washer Whirlpool LCR5232DQ0 Use And Care Manual](#)

Roper (24 pages)

[Washer Whirlpool LSC8244EZ0 Use And Care Manual](#)

Two speed with hand washables cycle (28 pages)

[Washer WHIRLPOOL LSQ8520JQ1 Use & Care Manual](#)

Easy-to-use automaticwasher (12 pages)

## Summary of Contents for Whirlpool LXR7144EQ2

### [Page 1: Top And Cabinet Parts](#)

TOP AND CABINET PARTS For Models: LXR7144EQ2, LXR7144EZ2 AUTOMATIC WASHER (Designer White) (Designer Almond) 3-00 Litho In U.S.A. (rcg) Part No. 881645 Rev.A...

[Page 2](#) TOP AND CABINET PARTS For Models: LXR7144EQ2, LXR7144EZ2 (Designer White) (Designer Almond) Illus. Part DESCRIPTION Literature Parts Use And Care Guide LIT3363573 English LIT3951073 French Installation Instructions LIT3952817 English LIT3951578 French LIT3953932 Wiring Diagram LIT3953891 Energy Label Following May Be Purchased DO-IT-YOURSELF...

### [Page 3: Controls And Rear Panel Parts](#)

CONTROLS AND REAR PANEL PARTS For Models: LXR7144EQ2, LXR7144EZ2 (Designer White) (Designer Almond) 881645...

[Page 4](#) CONTROL AND REAR PANEL PARTS For Models: LXR7144EQ2, LXR7144EZ2 (Designer White) (Designer Almond) Illus. Part Illus. Part Illus. Part DESCRIPTION DESCRIPTION DESCRIPTION 3951449 Hose, Pump To Tub 90767 Screw, 8A x 3/8 3976300 Washer, Water (Includes #30) 3366847 Switch, Water Level...

### [Page 5: Agitator, Basket And Tub Parts](#)

AGITATOR, BASKET AND TUB PARTS For Models: LXR7144EQ2, LXR7144EZ2 (Designer White) (Designer Almond) 881645...

[Page 6](#) AGITATOR, BASKET AND TUB PARTS For Models: LXR7144EQ2, LXR7144EZ2 (Designer White) (Designer Almond) Illus. Part DESCRIPTION 3355758 Cap, Agitator 358237 Screw & Washer (5–16–24 x 1) 3349019 Clothes Mover 3350830 Agitator 3360611 Tub Ring & Gasket 3359586 Gasket, Tub Ring...

### [Page 7: Brake, Clutch, Gearcase, Motor And Pump Parts](#)

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS For Models: LXR7144EQ2, LXR7144EZ2 (Designer White) (Designer Almond) Illus. Part Illus. Part DESCRIPTION DESCRIPTION 62611 Plate, Motor 388951 Brake & Drive Mount To Tube (Complete) Gearcase (Refer to Page 12 62691 Grommet, Motor (4)

### [Page 8: Machine Base Parts](#)

MACHINE BASE PARTS For Models: LXR7144EQ2, LXR7144EZ2 (Designer White) (Designer Almond) Illus. Part DESCRIPTION 3387485 Screw, Bracket Mounting (10–16 x 5/8) 64067 Bracket, Spring Outer (2) 63907 Spring Suspension,(3) 3362087 Support & Brake, 64065 Bracket, Spring Outer (L.F.) 63466 Link, Leveling...

### [Page 9: Wiring Harness Parts](#)

WIRING HARNESS PARTS For Models: LXR7144EQ2, LXR7144EZ2 (Designer White) (Designer Almond) WH2G 881645...

[Page 10](#) WIRING HARNESS PARTS For Models: LXR7144EQ2, LXR7144EZ2 (Designer White) (Designer Almond) Illus. Part Illus. Part Illus. Part DESCRIPTION DESCRIPTION DESCRIPTION 3348075 Block, Disconnect 3349557 Clip, Harness 3349494 Connector, Etc (Motor 3 Speed) 388498 Clip, Harness 60687 Connector, Relay (Use Term. 94613 3347812 Clip, Harness (Use Term.308569)

### [Page 11: Water System Parts](#)

WATER SYSTEM PARTS For Models: LXR7144EQ2, LXR7144EZ2 (Designer White) (Designer Almond) Illus. Part DESCRIPTION 285442 Connector Kit, Plastic Drain Hose 285321 Sleeve Kit, (Contains 2 Sleeves) 370447 Clamp, Hose 16272 Connector, Straight 285320 Siphon Break (Not Included) 65349 Clamp, Hose...

### [Page 12: Brake And Drive Tube Parts](#)

BRAKE AND DRIVE TUBE PARTS For Models: LXR7144EQ2, LXR7144EZ2 (Designer White) (Designer Almond) Illus. Part DESCRIPTION 388951 Brake And Drive Tube (Complete) 62658 Ring, Thrust 91939 Seal, Oil 356427 Seal, Drive Tube 356937 Spacer, Drive Tube 64027 Tube, Basket Drive (Includes Illus.

### [Page 13: Gearcase Parts](#)

GEARCASE PARTS For Models: LXR7144EQ2, LXR7144EZ2 (Designer White) (Designer Almond) Illus. Part DESCRIPTION 1 3360630 Gearcase (Complete) 285202 Cover, Gearcase 3 3349985 Seal, Gearcase Cover 285195 Sealer, Gasket (.20 Fl. Oz.) (6 ml) 63320 Pinion, Spin (Includes Illus. 25) 356427...

### [Page 14: Miscellaneous Parts](#)

MISCELLANEOUS PARTS For Models: LXR7144EQ2, LXR7144EZ2 (Designer White) (Designer

Almond) Illus. Part DESCRIPTION 3976263 Miscellaneous Parts Bag 3976300 Washer, Inlet Hose  
(1-1/16 x 5/8) (4) 3359452 Nut, Lock (3/8-16) 389102 Foot, Front (2) 3366912 Clamp, Hose  
OPTIONAL PARTS (NOT INCLUDED) Illus.

This manual is also suitable for:

[Lxr7144ez2](#)