



Whirlpool W10150624A User Instructions

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24

• PAGE

OF 24 GO

•

[Table of Contents](#)


•

Troubleshooting

•

Bookmarks

Available languages



Quick Links


[1 Table of Contents](#)

[2 Accessories](#)

[3 Washer Use](#)

4 Dryer Use

[Download this manual](#)



WASHER/DRYER USER INSTRUCTIONS



ASSISTANCE OR SERVICE	1
ACCESSORIES	2
WASHER/DRYER SAFETY	2
WASHER USE	4
DRYER USE	6
WASHER/DRYER CARE	6
TROUBLESHOOTING WASHER	8
TROUBLESHOOTING DRYER	10
WARRANTY	12

Para obtener acceso al manual de uso y cuidado en español, o para obtener información adicional acerca de su producto, visite:

www.whirlpool.com.

Tenga listo su número de modelo completo. Puede encontrar el número de modelo y de serie dentro de la cavidad superior de la

puerta.

If you need assistance or service, first see the "Troubleshooting" section. Additional help is available by calling our Customer eXperience Center at 1-800-253-1301 from anywhere in the U.S.A., or write:



Whirlpool Corporation
Customer eXperience Center
553 Benson Road
Benton Harbor, MI 49022-2692

Information may also be obtained by visiting our website at **www.whirlpool.com**.

In Canada, for assistance, installation or service, call us at **1-800-807-6777, or write:**

Whirlpool Canada LP
Customer Interaction Centre
1901 Minnesota Court

Mississauga, Ontario L5N 3A7

In Canada, visit www.whirlpool.ca.

Please include a daytime phone number in your correspondence.

W10150624A

INSTRUCTIONS POUR L'UTILISATEUR DE LA LAVEUSE/SÉCHEUSE

Table of Contents / Table des matières

ASSISTANCE OU SERVICE	13
ACCESSORIES	13
SÉCURITÉ DE LA LAVEUSE/SÉCHEUSE	13
UTILISATION DE LA LAVEUSE	15
UTILISATION DE LA SÉCHEUSE	17
ENTRETIEN DE LA LAVEUSE/SÉCHEUSE	17
DÉPANNAGE DE LA LAVEUSE	19
DÉPANNAGE DE LA SÉCHEUSE	22
GARANTIE	24

Assistance or Service

Keep this book and your sales slip together for future reference. You must provide proof of purchase or installation date for in-warranty service.

Write down the following information about your appliance to help you obtain assistance or service if you ever need it. You will need to know your complete model number and serial number. You can find this information on the model and serial number label, located at the top inside dryer door well.

Dealer name _____
 Serial number _____
 Address _____
 Phone number _____
 Model number _____
 Purchase date _____

[Next Page](#)

- 1
- 2
- 3
- 4
- 5

Troubleshooting

TROUBLESHOOTING WASHER 8

TROUBLESHOOTING DRYER 10

Related Manuals for Whirlpool W10150624A

[Washer/Dryer Whirlpool Gas Washer/Dryer Installation Instructions Manual](#)

27" (69 cm) gas washer/dryer (28 pages)

[Washer/Dryer Whirlpool LTE5243DQ User Instructions](#)

Combination washer/electric dryer (28 pages)

[Washer/Dryer Whirlpool Cabrio WTW5700XW Specifications](#)

High-efficiency laundry with 6th sense technology (1 page)

[Washer/Dryer Whirlpool Washer/Dryer User Manual](#)

27" (69 cm) electric washer/dryer (44 pages)