

TOSHIBA

Toshiba CIX Quick Start Manual

Telephone

1
2

--

•

Bookmarks

Quick Links

[Download this manual](#) See also: [User Manual](#), [Quick Reference Manual](#)



Enlarged version

Call Record:

•
While on a telephone call press the Record button and the LED will flash a second or so then turn solid this will record the conversation and drop it into your mailbox.

Notes:

The redial button calls the last number dialed from your phone. It can be an extension number or outside line number.

speaker button is used for hands free mode. The mic The

button is a mute button that only mutes the speaker. It does not mute the handset.

Telelink Communications, Inc.

397 Herndon Parkway, Suite 100

Herndon, VA 20170 (703) 674-5959

Toshiba Quick

Start Guide

CIX/CTX

For additional information, visit our website
www.TelelinkCom.com

TOSHIBA



ManualsLib.com



[Next Page](#)

1

2

Related Manuals for Toshiba CIX

[Telephone Toshiba CIX User Manual](#)

Strata cix and ctx ipt/dkt telephone (141 pages)

[Music Mixer Toshiba CIX Installation Manual](#)

Ip attendant console (28 pages)

[IP Phone Toshiba CIX series User Training Reference](#)

(23 pages)

[Telephone Toshiba STRATA CIX-CTX-QRG-VB VERSION B1 Quick Reference Manual](#)

Dkt / ipt telephone (13 pages)

[Voicemail Toshiba CIX Voicemail Quick Start Manual](#)

Toshiba telephone quick start guide (2 pages)

[Telephone Toshiba STRATA CIX DKT User Manual](#)

Strata cix and ctx ipt/dkt telephone (151 pages)

[Telephone Toshiba Strata CTX28 Programming Manual](#)

(592 pages)

[Telephone Toshiba STRATA CTX100 Installation And Maintenance Manual](#)

Digital business telephone systems (348 pages)

[Telephone Toshiba DP5000-Series User Manual](#)

Strata cix telephone (142 pages)

[Telephone Toshiba DP5000-Series User Manual](#)

Strata cix telephone (152 pages)

[Telephone Toshiba DP5000-series Quick Reference Manual](#)

Dp5000-series telephone quick reference guide (11 pages)

[Telephone Toshiba DP5000 Series Quick Reference Manual](#)

Featurephone (2 pages)

[Telephone Toshiba DP 5000 Series Quick Reference Manual](#)

(10 pages)

[Telephone Toshiba IP5000 Quick Reference Manual](#)

Featurephone (12 pages)

[Telephone Toshiba Strata CIX IP5000-Series User Manual](#)

(192 pages)

[Telephone Toshiba CTX 100 User Manual](#)

(3 pages)

Summary of Contents for Toshiba CIX

Page 1 LED will flash a second or so then turn solid this will record the conversation and drop it into your mailbox. Notes: Toshiba Quick The redial button calls the last number dialed from Start Guide your phone. It can be an extension number or outside line number.

Page 2 To Use All Page: To Use Call Forwarding: User Guide • Lift handset and press the All Page key on your • If programmed, the CFWD key functions to toggle call phone or lift the handset and dial #30. forwarding on and off. •...

This manual is also suitable for:

Ctx Ctx 28 Ctx 100 Ctx 670