



Toshiba 3000 series Quick Reference Manual

Strata ctx dkt/ipt telephone

1
2
3
4
5
6
7
8
9
10
11
12
Table Of Contents
13

--

•

[Table of Contents](#)

•

Bookmarks

--

Quick Links

[1 One Touch Buttons](#)

[2 Voice Mail Call Monitor](#)

[3 Flexible Buttons](#)

[Download this manual](#)

[See also: Operating Manual](#)



STRATA TOSHIBA CTX	
DKT / IPT Telephone	

Quick Reference Guide
Business Telephones
TOSHIBA
Helping You
Communicate Better

[Table of Contents](#)

[Next Page](#)

- 1
- 2
- 3
- 4
- 5

Related Manuals for Toshiba 3000 series

[Control Unit Toshiba V Series Operation Manual](#)

Integrated controller, ethernet module / ds connection module (126 pages)

[IP Phone Toshiba Strata DK 2000-series User Manual](#)

Toshiba digital telephone user guide (164 pages)

[IP Phone Toshiba Strata DK User Manual](#)

Digital business telephone systems includes lcd, add-on module, and direct station selection console (136 pages)

[IP Phone Toshiba 2000 series User Manual](#)

2000-series digital telephones for strata dk systems (134 pages)

[Control Unit Toshiba V Series Operation Manual](#)

Integrated controller, ethernet module (122 pages)

[IP Phone Toshiba Strata DK DKT 2000-Series Quick Reference Manual](#)

(8 pages)

[Telephone System Toshiba Strata DK DKT 2000-series Quick Reference Manual](#)

Digital business telephone system (2 pages)

[Toshiba 3000 Series, 2000 Series - DKT / IPT Business Telephone Quick Reference Guide with Button Codes](#)

(article)

[Telephone Toshiba DP5022F-SD User Manual](#)

Digital business telephone with 4-line lcd display. hearing aid compatible (12 pages)

[Telephone Toshiba DKT3220-SD - Digital Phone - Charcoal User Manual](#)

Ipt/dkt telephone (151 pages)

[Telephone Toshiba DKT User Manual](#)

Strata ctx dkt/ipt telephone (116 pages)

[Telephone Toshiba DP 5000 Series Quick Reference Manual](#)

(10 pages)

[Telephone Toshiba IP5000-Series Quick Reference Manual](#)

Toshiba telephone quick reference guide (13 pages)

[Telephone Toshiba DP5000-Series User Manual](#)

Strata cix telephone (142 pages)

[Telephone Toshiba CTX IPT/DKT User Manual](#)

Strata cix and ctx ipt/dkt telephone (171 pages)

[Telephone Toshiba DKT3000 Series User Manual](#)

Strata ctx digital business telephone systems (106 pages)

Summary of Contents for Toshiba 3000 series

[Page 2: What's My Line](#)

Introduction This quick reference guide applies to Toshiba 3000- and 2000-series digital telephones and Internet Protocol (IPT1020-SD) telephones connected to a Strata CTX system. See your Telephone System Administrator to find out which features you have. Use the check boxes or blank lines to enter the variable selections for your telephone.

[Page 3: Spkr Button](#)

Which Codes Do I Use? Default feature codes are listed in this guide. Check with your System Administrator to see if these codes have been changed. If so, write the new codes in the blank lines and cross out the default codes. For example: 8□s□U□□Ä...

[Page 4: Account Code Calls](#)

Account Code Calls ³ To dial with a Forced Account Code (FAC) 1. Place a call in the normal method. 2. After the tone burst, enter the Account Code. If the code is invalid, you hear re-order tone and the call is rejected.

[Page 5: Conference Calls](#)

Conference Calls 8□s□U□□ 1. While on a call, press 2. Call another station or outside line. 8□s□U□□ 3. When the called party answers, press . If it's busy or 8□s□U□□ there's no answer, press again to return to the original connection. All parties are conferenced. 4.

[Page 6](#) Hold C□yqÄ 1. To place a call on Hold, press the button. 2. To return to the held call, press the held line's button. If you do not return to the held call, it rings back to your phone. If you are busy on another call, you hear two tone bursts. If the held party hangs up, the call is released.

[Page 7: Call Park Orbits](#)

Call Park Orbits ³ To park a call Qh□xÄv□ÄP□iv□ 1. While on a call, press 8□s□U□□ Ä" fffffffÄ ...or 2. Specify the Park Orbit using one of the following: • Press and the system automatically selects a General &□□ &□ Park Orbit between .

[Page 8: Speed Dial](#)

Redial Use this button to redial the last number dialed from your phone. Srqvhy ³ To redial the last number, press Speed Dial ³ To store a Station Speed Dial Number We suggest storing Speed Dial numbers on a One Touch button; use Speed Dial Codes to store more numbers.

[Page 9: Voice Mail Call Monitor](#)

Voice Mail Call Monitor System Availability: Only with Strata CTX28 ³ To enable and disable Voice Mail Call Monitor 8hyyÄH□□v□□□ 1. Press button. Ä 2. Enter your voice mail password, then press ³ To cancel Call Monitor 8hyyÄH□□v□□□ ³ Press button.

[Page 10: Flexible Buttons](#)

DKT3014-SDL LCD Features ³ To use Speed Dial or Directory Menus 1. Press the Soft Key FRED J NO. 3371 next to the Speed FEB 18 MONDAY 12:00 Dial (SD) or Directory (DIR) to DIRECT SS view the first SYSTEM SD screen.

[Page 11: Flexible Button Codes](#)

Flexible Button Codes Account Code Auto Busy Redial Auto Callback Call Forward - Any Calls (Internal and External) All Call Busy No Answer Busy No Answer Call Park Orbit Call Pickup Incoming - Group Pickup Incoming - Directed Terminal Pickup Incoming - Directed Group Pickup Incoming - Directed DN Pickup On hold - Local Retrieve...

[Page 12](#) Digital Solutions Division 9740 Irvine Blvd., Irvine, CA 92618-1697 (949) 583-3700 www.telecom.toshiba.com © 2004 Toshiba America Information Systems, Inc. Printed in U.S.A. Digital Solutions Division. Strata is a registered trademark of Toshiba Corporation. Specifications subject to change without notice. Some features require optional...

This manual is also suitable for:

2000 series