



Asus RT- N66U Setup Manual

Dark knight series

1
2
3


--

•

Bookmarks

[Download this manual](#)

Quick Links



ASUS RT-N66U Dark Knight Router Setup Guide



ManualsLib.com



[Next Page](#)

- 1
- 2
- 3

Related Manuals for Asus RT- N66U

[Wireless Router Asus Dark Knight RT-N66U Quick Start Manual](#)

Gigabit router wireless-n900 (182 pages)

[Network Router Asus RT-N66U Dark Knight Quick Start Manual](#)

Gigabit router wireless-n900 (78 pages)

[Network Router Asus RT-N66U Dark Knight User Manual](#)

Dual-band wireless-n900 gigabit router (70 pages)

[Network Router Asus RT-N66U Dark Knight Quick Start Manual](#)

Gigabit router wireless-n900 (23 pages)

[Network Router Asus RT-N65U Quick Start Manual](#)

Dual-band wireless-n750 gigabit router (72 pages)

[Network Router Asus RT-N65U Quick Start Manual](#)

Dual-band wireless-n750 gigabit router (159 pages)

[Network Router Asus RT-N65U Quick Start Manual](#)

Dual-band wireless-n750 gigabit router (168 pages)

[Network Router Asus RT-N65R Quick Start Manual](#)

Dual-band wireless-n750 gigabit router (60 pages)

[Network Router Asus RT-N66R Quick Start Manual](#)

Gigabit router wireless-n900 (76 pages)

[Network Router Asus RT-N66R Dark Knight User Manual](#)

Gigabit router dual band wireless-n900 (70 pages)

[Network Router Asus RT-AC66U User Manual](#)

Dual band 3x3 802.11ac gigabit router (131 pages)

[Network Router Asus RT-N66W Dual Band 3x3 Quick Start Manual](#)

Wireless-n900 gigabit router (27 pages)

[Network Router Asus RT-N600RU User Manual](#)

Wireless high speed router (92 pages)

[Network Router Asus RT-N600P Quick Start Manual](#)

Wireless-n600 high speed router (28 pages)

[Network Router Asus RT-N16 Manual](#)

(9 pages)

[Network Router Asus RT-N300 B1 User Manual](#)

Wireless-n (88 pages)

Summary of Contents for Asus RT- N66U

[Page 1](#) ASUS RT- N66U Dark Knight Router Setup Guide...

[Page 2](#) Configure QoS Settings Log in to the ASUS router to create a User Name and Password. Select Traffic Manager. Click to turn QoS ON and then click Save.

[Page 3](#) When the QoS slider turns green, enter your current bandwidth for both the upload and download. (If unsure of your current bandwidth speed, please run a speed test at <http://www.megapath.com/speedtestplus/>.) Click Save after entering your bandwidth figures. Be sure to power cycle/reboot the router before proceeding. Your QoS should now be configured.

This manual is also suitable for:

[Rt-n66u dark knight](#)