

I How To Copy Group Programs - Sanyo SPW-CR365GXH56 Technical Data Manual

Mini eco-i system

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218


219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268

269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318

319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345

Table Of Contents

346



•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



5. Schedule Timer

I How to Copy Group Programs

STEP 1

Press the PROG. COPY GROUP button.

•
"CP-1" starts blinking in the present time display area and "CP" (copy) starts blinking in the program area to indicate the copy source.


STEP 2

Select a source group program to copy.

•
Select a copy source group using the GROUP button.

Once having selected the copy source group, press

•



the SET button to set it.

STEP 3

Select a copy destination group.

After pressing the SET button, "CP-2" starts blinking

• in the present time display area, the copy source group No. set appears in the program "PA" (paste) starts blinking in the program to indicate the copy destination.

• Select a copy destination group using the GROUP button.

STEP 4

Enter the selected copy destination group.

When the SET button is pressed, the number of the copy destination group appears in the program No. area.


NOTE

• If a group from numbers 1 to 4 was selected as the copy destination group, that number appears in the program area.

• If a group from numbers 5 to 8 was selected, that number appears in the program area.

Control of Mini ECO-i SYSTEM
area, and
area

3 - 71



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

116

117

118

119

Quick Links:

[Technical Data](#)

[Outdoor Units](#)

Troubleshooting

[I Troubleshooting 124](#)

[I Troubleshooting 136](#)

Related Manuals for Sanyo SPW-CR365GXH56

[Air Conditioner Sanyo Mini ECO-i SPW-ASR74GXH56\(A/B\) Installation Instructions Manual](#)

System air conditioner (49 pages)

[Air Conditioner Sanyo MINI ECO-i SPW-CR365GXH56B Service Manual](#)

(252 pages)

[Air Conditioner Sanyo SPW-X253G56 Service Manual](#)

Split system (72 pages)

[Air Conditioner Sanyo 2-WAY ECO-i SPW-C0705DXHN8 Service Manual](#)

Multi system (143 pages)

[Air Conditioner Sanyo SPW-C1155DXHN8 Technical Data & Service Manual](#)

2-way eco-i multi system (242 pages)

[Air Conditioner Sanyo SPW-X253GH56 Service Manual](#)

Split system (105 pages)

[Air Conditioner Sanyo SPW-U253GH56 Service Manual](#)

Split system air conditioner (108 pages)

[Air Conditioner Sanyo SPW-D253GH56 Service Manual](#)

Split system (108 pages)

[Air Conditioner Sanyo SPW-C0705DZH8 Technical Data Manual](#)

3-way eco-i multi system 5 series (703 pages)

[Air Conditioner Sanyo SPW-C483GYH8 Service Manual](#)

Eco multi system (235 pages)

[Air Conditioner Sanyo SPW-C256VH Technical Data & Service Manual](#)

4-way air discharge semi-concealed wall-mounted ceiling-mounted concealed-duct (517 pages)

[Air Conditioner Sanyo SPW-CR1503GDYH8 Technical Data & Service Manual](#)

W-eco multi system series (377 pages)

[Air Conditioner Sanyo SPW-FTR124EH56 Installation And Operation Manual](#)

Dc inverter air conditioner for refrigerant r410a (32 pages)

[Air Conditioner Sanyo Big PACi 18 Series Technical Data & Service Manual](#)

Big pack i dc inverter (275 pages)

[Air Conditioner Sanyo SPW-CR363GVH8 Service Manual](#)

(262 pages)

[Air Conditioner Sanyo SPW-XR253GH56 Technical Data & Service Manual](#)

(223 pages)

Related Content for Sanyo SPW-CR365GXH56

[RCS-SH80UA I How To Start Group Operation](#)

Sanyo RCS-SH80UA

[RCS-BH80UA.WL I How To Start Group Operation](#)

Sanyo RCS-BH80UA.WL

[C4272R S/C Wiring System Diagram For Group Control](#)

Sanyo C4272R S/C

[AHX0752 Group Control Using 2 Remote Controllers](#)

Sanyo AHX0752

[SPW-C0705DZH8 How To Copy Group Programs](#)

Sanyo SPW-C0705DZH8

[SPW-C256VH Operating Multiple In/Outdoor Units Simultaneously \(Group Control\)](#)

Sanyo SPW-C256VH

This manual is also suitable for:

[Spw-cr485gxn56Spw-cr605gx56Spw-cr605gxn56Spw-cr365gxn8Spw-cr485g xn8Spw-cr605gxn8](#) ... [Show all](#)

[Save PDF](#)