

Examples Of Wiring Diagrams - Sanyo 26 series Installation Instructions Manual

Split system heat pump air conditioner

1

2

3

4

5

Table Of Contents

6

7

8

9

10

11

12

13

14


15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110



•

[Table of Contents](#)

•

Bookmarks



11-8. Examples of Wiring Diagrams

11-8-1. Basic wiring diagram 1

Single-type system

G

Be careful to avoid miswiring when connecting the wires. (Miswiring will damage the units.)

Power supply

Single-phase

230 / 208 V

System address rotary switch

(Set to "0" at the time of shipment.)

Outdoor unit


L1

L2

1

2

Ground



1
2
Indoor
unit

U1

U2

RC

BLK

WHT

1 2

(Optional)

Wired remote
controller

Fig. 11-5

107

Power supply


Single-phase

230 / 208 V

Ground

Remote controller wiring

(Field supply)



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

106

107

108

109

Quick Links:

[Indoor Unit](#)

[Outdoor Unit](#)

[Trouble Diagnostics](#)

Related Manuals for Sanyo 26 series

[Air Conditioner Sanyo Big PACi 18 Series Technical Data & Service Manual](#)

Big pack i dc inverter (275 pages)

[Air Conditioner Sanyo C4272R Service Manual](#)

Sanyo split system air conditioner service manual (181 pages)

[Air Conditioner Sanyo C4272R S/C Installation Instructions Manual](#)

Sanyo split system heat pump air conditioner installation instructions (111 pages)

[Air Conditioner Sanyo C3072R Parts List](#)

Outdoor unit (4 pages)

[Air Conditioner Sanyo CH3672R Parts List](#)

Outdoor unit (4 pages)

[Air Conditioner Sanyo 000-31 Specifications](#)

Concealed duct air conditioner & heat pump 24,000-31,200 btu/h 13.9-14.9 seer
(2 pages)

[Air Conditioner Sanyo 26KS72R Specifications](#)

Wall mounted air conditioner (2 pages)

[Heat Pump Sanyo 26THW72R Specifications](#)

Ceiling suspended heat pump (2 pages)

[Air Conditioner Sanyo 26UW72R Specifications](#)

Concealed duct air conditioner (2 pages)

[Air Conditioner Sanyo 26KHS72R Submittal Data](#)

Wall mounted heat pump (2 pages)

[Air Conditioner Sanyo 36UW72R Specifications](#)

Concealed duct air conditioner (2 pages)

[Air Conditioner Sanyo KHHS2672R Specifications](#)

Wall mounted heat pump with heater (2 pages)

[Air Conditioner Sanyo KHS3072R Specifications](#)

Wall mounted air conditioner (2 pages)

[Air Conditioner Sanyo KHS3672R Datasheet](#)

Wall mounted air conditioner (2 pages)

[Air Conditioner Sanyo THW3672R Specifications](#)

Ceiling suspended air conditioner (2 pages)

[Air Conditioner Sanyo XHW2672R Specifications](#)

Ceiling recessed air conditioner (2 pages)

Related Content for Sanyo 26 series

[STW-2 Series Electrical Wiring Diagrams](#)

Sanyo STW-2 Series

[C2432A Examples Of Incorrect Wiring](#)

Sanyo C2432A

[SAP-CMR2428E Electric Wiring Diagrams](#)

Sanyo SAP-CMR2428E

[SAP-K91AA Electric Wiring Diagrams](#)

Sanyo SAP-K91AA

[SAP-K92A Electric Wiring Diagrams](#)

Sanyo SAP-K92A

[SAP-K91AA-S Electric Wiring Diagrams](#)

Sanyo SAP-K91AA-S

[SAP-CMRV1426EH Electric Wiring Diagrams](#)

Sanyo SAP-CMRV1426EH

[C4272R Examples Of Wiring Diagrams](#)

Sanyo C4272R

This manual is also suitable for:

[30 series](#)[36 series](#)[Split system](#)[heat pump](#)[air conditioner](#)[Ch2672r](#)[Ch3072r](#)[Ch3672r](#) ... [Show all](#)