



# Table Of Contents - Sanyo SPW-X483GH56 Installation Instruction

Eco multi system air conditioner



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68

69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91

|  |
|--|
|  |
|--|

•

[Table of Contents](#)


•

Bookmarks

|  |
|--|
|  |
|--|







IMPORTANT

Please Read Before Starting  
Check of Density Limit

|                         |       |   |
|-------------------------|-------|---|
| 1.                      |       |   |
| <a href="#">GENERAL</a> | ..... | 4 |

|  |  |  |
|--|--|--|
| 1-1.   |  |  |
| <a href="#">Tools Required for Installation (Not Supplied)</a> |  |  |

|  |  |  |
|--|--|--|
| 1-2.   |  |  |
| <a href="#">Accessories Supplied with Unit</a> |  |  |

|   |  |  |
|---|--|--|
| 1-3.  |  |  |
| <a href="#">Type of Copper Tube and Insulation Material</a> |  |  |

|  |  |  |
|--|--|--|
| 1-4.   |  |  |
| <a href="#">Additional Materials Required for Installation</a> |  |  |

|                               |  |  |
|-------------------------------|--|--|
| 1-5.                          |  |  |
| <a href="#">Tubing Length</a> |  |  |

|   |    |   |
|---|----|---|
| 1-6.  |    |   |
| <a href="#">Tubing Size</a>   |    |   |
| 1-7.  |    |   |
| <a href="#">Straight Equivalent Length of Joints</a>  |    |   |
| 1-8.  |    | ■ |
| <a href="#">Additional Refrigerant Charge</a>   |    |   |
| 1-9.  |    |   |
| <a href="#">Installing the Distribution Joint</a>   |    |   |
| <a href="#">1-10. Optional Distribution Joint Kits</a>  |    |   |
| <a href="#">1-11. Selecting Refrigerant Tubing Size and Calculating the Amount of Additional Charge</a> |    |   |
| 2.  |    |   |
| <a href="#">SELECTING THE INSTALLATION SITE</a> .....   | 13 |   |
| <a href="#">Indoor Unit</a>   |    | ■ |
| <a href="#">Outdoor Unit</a>  |    |   |
| <a href="#">48 Type</a>   |    |   |
| 2-1.  |    |   |
| <a href="#">Air-Discharge Chamber for Top Discharge</a>   |    |   |
| 2-2.  |    |   |
| <a href="#">Installing the Unit in Heavy Snow Areas</a>   |    |   |
| 2-3.  |    |   |
| <a href="#">Precautions When Installing in Heavy Snow Areas</a>   |    |   |
| 2-4.  |    |   |
| <a href="#">Dimensions of Snow/Wind-Proof Ducting and Refrigerant Tubing Space for Installation</a>     |    | ■ |
| 2-5.  |    |   |
| <a href="#">Dimensions of Snow / Wind Ducting (48 Type)</a>   |    |   |
| <a href="#">70, 90 Type</a>   |    |   |
| 2-6.  |    |   |
| <a href="#">Shield for Horizontal Exhaust Discharge</a>   |    |   |
| 2-7.  |    | ■ |
| <a href="#">Installing the Outdoor Unit in Heavy Snow Areas</a>   |    |   |
| 2-8.  |    |   |
| <a href="#">Precautions When Installing in Heavy Snow Areas</a>   |    |   |
| 2-9.  |    |   |
| <a href="#">Dimensions of Snow / Wind Ducting (70, 90 Type)</a>   |    |   |
| 3.  |    |   |
| <a href="#">HOW TO INSTALL THE INDOOR UNIT</a> .....  | 21 |   |
| <a href="#">1-Way Air Discharge Semi-Concealed Type (AS Type)</a> .....                                 | 21 | ■ |
| 3-1.  |    |   |
| <a href="#">Suspending the Indoor Unit</a>  |    |   |
| 3-2.  |    |   |
| <a href="#">Placing the Unit Inside the Ceiling</a>   |    |   |
| 3-3.  |    |   |
| <a href="#">Installing the Drain Piping</a>   |    |   |
| 3-4.  |    |   |
| <a href="#">Checking the Drainage</a>   |    |   |
| <a href="#">2-Way Air Discharge Semi-Concealed Type (S Type)</a> .....                                  | 26 | ■ |

3-5.

[Suspending the Indoor Unit](#)

3-6.

[Placing the Unit Inside the Ceiling](#)

3-7.

[Installing the Drain Piping](#)

3-8.

[Checking the Drainage](#)

## CONTENTS

Page

[4-Way Air Discharge Semi-Concealed Type](#)

[\(X Type\)](#) ..... 30

3-9.

[Suspending the Indoor Unit](#)

[3-10. Preparation for Suspending](#)

[3-11. Placing the Unit Inside the Ceiling](#)

[3-12. Installing the Drain Piping](#)

[3-13. Checking the Drainage](#)

[Wall-Mounted Type \(K Type\)](#) ..... 34

[3-14. Removing the Rear Panel from the Unit](#)

[3-15. Selecting and Making a Hole](#)

[3-16. Installing the Rear Panel onto the Wall](#)

[3-17. Removing the Grille to Install the Indoor Unit](#)

[3-18. Preparing the Tubing](#)

[3-19. Shaping the Tubing](#)

[3-20. Installing the Drain Hose](#)

[Ceiling-Mounted Type \(T Type\)](#) ..... 38

[3-21. Suspending the Indoor Unit](#)

[3-22. Partial Flush Mounting](#)

[3-23. When Suspending Away from the Ceiling](#)

[3-24. Installing the Drain Piping](#)

[Concealed-Duct Type \(U Type\)](#) ..... 42

[3-25. Required Minimum Space for Installation and](#)

Service

[3-26. Suspending the Indoor Unit](#)

[3-27. Installing the Drain Piping](#)

[3-28. Checking the Drainage](#)

[3-29. Increasing the Fan Speed](#)

[Concealed-Duct High Static Pressure Type](#)

[\(D Type\)](#) ..... 47

[3-30. Required Minimum Space for Installation and](#)

Service

[3-31. Suspending the Indoor Unit](#)

[3-32. Installing the Drain Piping](#)

[3-33. Caution for Ducting Work](#)

[Floor-Standing Type \(F Type\),](#)

[Concealed Floor-Standing Type \(FM Type\)](#) ..... 51

[3-34. Required Minimum Space for Installation and](#)

Service

3-35. Dimensions and Part Names

3-36. Removing and Attaching the Front Panel  
(Floor-Standing Type)

3-37. Installing the Refrigerant Tubing

3-38. Installing the Drain Piping

3-39. Installing the Remote Controller

Page

Previous Page

Next Page

1  
2  
3  
4  
5  
6  
7  
8

Quick Links:

[Please Read before Starting](#)

[Indoor Unit](#)

[Outdoor Unit](#)

## Chapters

[Table of Contents](#) 4

[Concealed-Duct Type \( U Type\) 3-25. Required Minimum Space for Installation and Service](#) 44

## Related Manuals for Sanyo SPW-X483GH56

[Air Conditioner Sanyo SPW-U253GH56 Service Manual](#)

Split system air conditioner (108 pages)



[Air Conditioner Sanyo SPW-D253GH56 Service Manual](#)

Split system (108 pages)

[Air Conditioner Sanyo SPW-T253GH56 Service Manual](#)

Split system (106 pages)

[Air Conditioner Sanyo SPW-X253GH56 Service Manual](#)

Split system (105 pages)

[Air Conditioner Sanyo 2-WAY ECO-i SPW-C0705DXHN8 Service Manual](#)

Multi system (143 pages)

[Air Conditioner Sanyo SPW-C1155DXHN8 Technical Data & Service Manual](#)

2-way eco-i multi system (242 pages)

[Air Conditioner Sanyo ECOi C0705DXHN8 Brochure & Specs](#)

2 and 3 pipe electric vrf systems (10 pages)

[Air Conditioner Sanyo MINI ECO-i SPW-CR365GXH56B Service Manual](#)

(252 pages)

[Air Conditioner Sanyo SPW-D253G56 Service Manual](#)

Split system air conditioner (66 pages)

[Air Conditioner Sanyo SPW-CR365GXH56 Technical Data Manual](#)

Mini eco-i system (346 pages)

[Air Conditioner Sanyo SPW-C483GYH8 Service Manual](#)

Eco multi system (235 pages)

[Air Conditioner Sanyo SPW-C256VH Technical Data & Service Manual](#)

4-way air discharge semi-concealed wall-mounted ceiling-mounted concealed-duct (517 pages)

[Air Conditioner Sanyo Big PACi 18 Series Technical Data & Service Manual](#)

Big pack i dc inverter (275 pages)

[Air Conditioner Sanyo SPW-CR1503GDYH8 Technical Data & Service Manual](#)

W-eco multi system series (377 pages)

[Air Conditioner Sanyo SPW-XR253GH56 Technical Data & Service Manual](#)

(223 pages)

[Air Conditioner Sanyo SPW-XR254EH56 Installation And Operation Manual](#)

Dc inverter air conditioner (40 pages)

## Related Content for Sanyo SPW-X483GH56

[CM1812 / KMS0912 \(x2\) Table Of Contents](#)

[Sanyo CM1812 / KMS0912 \(x2\)](#)

[XS3632 / C3632 Table Of Contents](#)

[Sanyo XS3632 / C3632](#)

[XS2422 Table Of Contents](#)

[Sanyo XS2422](#)

[SAP91KC Table Of Contents](#)

Sanyo SAP91KC

[KS2432A Table Of Contents](#)

Sanyo KS2432A

[PO811 Table Of Contents](#)

Sanyo PO811

[KMS1212 Table Of Contents](#)

Sanyo KMS1212

[C4272R Table Of Contents](#)

Sanyo C4272R

This manual is also suitable for:

Spw-d483gh56Spw-x363gh56Spw-t363gh56Spw-u363gh56Spw-d363gh56Spw-t483gh56 ... [Show all](#)