



# 2-Way Air Discharge Semi-Concealed Type (S Type); Before Installing The Ceiling Panel - Sanyo SPW-X483GH56 Installation Instruction


Eco multi system air conditioner



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68

69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91



•


[Table of Contents](#)

•

## Bookmarks







Enlarged version

## 2-Way Air Discharge Semi-Concealed Type

(S Type)

10-3.

### ■ 2-Way Air Discharge Semi-Concealed Type

Before Installing the Ceiling Panel

(1) Adjust the distance between the unit and the surface of the ceiling (60 mm) using the 2 hex-

agonal nuts as shown in Fig. 10-2 while following the installation gauge.

(2) Remove the air-intake panel and the air filter from the ceiling panel as shown in Figs. 10-3 and 10-4.

Never touch or attempt to move the air-direction louver

CAUTION

by hand or you may damage

Never touch or attempt to




Fig.

the unit. Instead, use the remote controller if you want to change the direction of air flow.

■ **2-Way Air Discharge Semi-Concealed Type (S Type)**

How to remove the air-intake panel (from either side). (Fig.10-4)

- 1 Push in.
- 2 Slide.
- 4 Remove.

Air-intake panel  
Fig. 10-4

- 3 Pull.
- 2
- 1
- 3

0809\_S\_1  
79  
79

Indoor unit  
Ceiling  
Fig. 10-2  
Ceiling panel  
Fig. 10-3

S4179544  
S4179544  
11111  
AS  
22222  
0143\_S\_1

S  
33333  
Air-intake panel  
X

Air filter  
0810\_S\_1  
00000  
C

**10-3. Before Installing the Ceiling Panel**

- (1) Adjust the distance between the unit and the surface of the ceiling (60 mm) using the 2 hexagonal nuts as shown in Fig. 10-2 while following the installation gauge.
- (2) Remove the air-intake panel and the air filter from the ceiling panel as shown in Figs. 10-3 and 10-4.




**CAUTION**


**Never touch or attempt to move the air-direction louver by hand or you may damage the unit. Instead, use the remote controller if you want to change the direction of air flow.**

**How to remove the air-intake panel (from either side). (Fig.10-4)**

- ① Push in. → ② Slide. → ③ Pull.
- ④ Remove.



**Fig.**



**Fig.**

[Previous Page](#)  
[Next Page](#)

1  
...  
78  
79  
80  
**81**  
82  
83  
84  
85

Quick Links:

[Please Read before Starting](#)

[Indoor Unit](#)

[Outdoor Unit](#)

## Chapters

[Table of Contents](#) 4

[Concealed-Duct Type \( U Type\) 3-25. Required Minimum Space for Installation and Service](#) 44

## Related Manuals for Sanyo SPW-X483GH56

[Air Conditioner Sanyo SPW-U253GH56 Service Manual](#)

Split system air conditioner (108 pages)

[Air Conditioner Sanyo SPW-D253GH56 Service Manual](#)

Split system (108 pages)

[Air Conditioner Sanyo SPW-T253GH56 Service Manual](#)

Split system (106 pages)

[Air Conditioner Sanyo SPW-X253GH56 Service Manual](#)

Split system (105 pages)

[Air Conditioner Sanyo 2-WAY ECO-i SPW-C0705DXHN8 Service Manual](#)

Multi system (143 pages)

[Air Conditioner Sanyo SPW-C1155DXHN8 Technical Data & Service Manual](#)

2-way eco-i multi system (242 pages)

[Air Conditioner Sanyo ECOi C0705DXHN8 Brochure & Specs](#)

2 and 3 pipe electric vrf systems (10 pages)

[Air Conditioner Sanyo MINI ECO-i SPW-CR365GXH56B Service Manual](#)

(252 pages)

[Air Conditioner Sanyo SPW-D253G56 Service Manual](#)

Split system air conditioner (66 pages)

[Air Conditioner Sanyo SPW-CR365GXH56 Technical Data Manual](#)

Mini eco-i system (346 pages)

[Air Conditioner Sanyo SPW-C483GYH8 Service Manual](#)

Eco multi system (235 pages)

[Air Conditioner Sanyo SPW-C256VH Technical Data & Service Manual](#)

4-way air discharge semi-concealed wall-mounted ceiling-mounted concealed-duct (517 pages)

[Air Conditioner Sanyo Big PACi 18 Series Technical Data & Service Manual](#)

Big pack i dc inverter (275 pages)

[Air Conditioner Sanyo SPW-CR1503GDYH8 Technical Data & Service Manual](#)

W-eco multi system series (377 pages)

[Air Conditioner Sanyo SPW-XR253GH56 Technical Data & Service Manual](#)

(223 pages)

[Air Conditioner Sanyo SPW-XR254EH56 Installation And Operation Manual](#)

Dc inverter air conditioner (40 pages)

## Related Content for Sanyo SPW-X483GH56

[SPW-CR365GXH56 Way Air-Discharge Semi-Concealed Type \(X Type\)](#)

Sanyo SPW-CR365GXH56

[KH2442 / CH2442 Way Air Discharge Semi-Concealed Type](#)

Sanyo KH2442 / CH2442

[CH2442 4-Way Air Discharge Semi-Concealed Type \(Xh Type\)](#)

Sanyo CH2442

[W-3WAY ECO-i 85464369098000 4-Way Air Discharge Semi-Concealed](#)



[Type \(X Type\)](#)

Sanyo W-3WAY ECO-i 85464369098000

[Mini ECO-i 85464359981002 I 4-Way Air Discharge Semi-Concealed](#)

[Type \(X Type\)](#)

Sanyo Mini ECO-i 85464359981002

[C4272R S/C 4-Way Air Discharge Semi-Concealed Type](#)

Sanyo C4272R S/C

[85464359982001 I 4-Way Air Discharge Semi-Concealed Type \(X](#)

[Type\)](#)

Sanyo 85464359982001

[ECO-i AHX0752 Way Air Discharge Semi-Concealed Type \(X, Xm Type\)](#)

Sanyo ECO-i AHX0752

This manual is also suitable for:

[Spw-d483gh56Spw-x363gh56Spw-t363gh56Spw-u363gh56Spw-d363gh56Spw-t483gh56](#) ... [Show all](#)