



Table of Contents





Download this manual	Quick Links	









## Related Manuals for Whirlpool VB-100

Vacuum Cleaner Whirlpool VS1809 Use & Care Manual

(30 pages)

Vacuum Cleaner Whirlpool VS1405 User Manual

(28 pages)

Vacuum Cleaner Whirlpool VH1806 User Manual

(11 pages)

Vacuum Cleaner Whirlpool VL1407 User Manual

(11 pages)

Vacuum Cleaner Whirlpool VL1602 User Manual

(21 pages)

Vacuum Cleaner Whirlpool VS2511 Use And Care Manual

(44 pages)

# Summary of Contents for Whirlpool VB-100

### Page 1: Instruction Manual

INSTRUCTION MANUAL Vacuum Cleaner Model No.: VB-100 Please read carefully before using this cleaner. Always fully extend the mains cable before use. Retain for future reference.

<u>Page 2</u> 1. Parts and components overview Note: Illustations may differ from actual product. Hose inlet 9. Dirt container Lid release button 10. Dusting brush Carry handle 11. Telescopic extension tube Auto cord rewind button 12. Accessories holder Floor tool parking slot 13.

#### Page 3: Safety Information

Whirlpool Authorised Service container, or before connecting/disconnecting Agent or suitably qualified person for the attachments.

#### Page 4: How To Assemble

3. How to Assemble IMPORTANT: Always unplug the vacuum cleaner from the electrical outlet before assembling or removing the accessories. 1. Insert the flexible hose connector into the 3. The telescopic extension tube can be inlet on the main body of the vacuum lengthened or shortened by pushing the cleaner until it clicks into place.

<u>Page 5</u> 5. Accessories: The accessories can be attached directly to the handle by removing the telescopic tube and pushing in the desired accessory. The accessories can also be attached to the telescopic tube for extra reach. Remove the combination floor head and push on the desired accessory. Crevice tool: for crevices, corners and cracks, etc.

<u>Page 6</u> When all the dirt has fallen close the dirt container base, and return the dirt container to the vacuum cleaner. Cleaning the Filters: NOTE: NOTE: Do not use any detergents or boiling water to wash the filters. Whirlpool recommends checking the filters every time the dirt container is emptied and cleaning as instructed below.

<u>Page 7</u> Post-motor filter: NOTE: This is located on the back of the vacuum cleaner. Release the post-motor cover by pressing down on the catch at the top of the cover. Remove the filter and case by pulling away from the casing then separate the filter from the case. The post-motor filter can be rinsed in warm water (max 40 C).

## Page 8: Troubleshooting

1.6 Litres approx Cord length: 5M approx Subject to technical change without notice. 11. Service & Help Please contact Whirlpool Service Centre: Address: 14/F Wilson Logistics Centre, 24-28 Kung Yip Street, Kwai Chung, Hong Kong Star Hotline: 852-2406 9138...