



Toshiba RAS-10~16 SKV(R) Series Owner's Manual

Split type

1
2
3
4

--




•

Bookmarks

[Download this manual](#)

Quick Links



OWNER'S MANUAL

AIR CONDITIONERS (SPLIT TYPE)
TOSHIBA
For general public use

Indoor unit

RAS-10~16 SKV(R) Series

RAS-M10~16 SK(C)V Series

Outdoor unit

RAS-10~16 SAV(R) Series

TOSHIBA



TÜRKÇE
NEDERLANDS
ΕΛΛΗΝΙΚΑ
SVENSKA
SUOMI
NORSK
DANSK
ROMÂNĂ
EESTI
LATVISKI
SLOVENČINA
SLOVENŠČINA

ManualsLib.com

[Next Page](#)

1
2
3
4

Related Manuals for Toshiba RAS-10~16 SKV(R) Series

[All in One Printer Toshiba e-STUDIO6540C Management Manual](#)

Multifunctional digital color systems / multifunctional digital systems (192 pages)

[Air Conditioner Toshiba RAS-M10 Series Installation Manual](#)

(148 pages)

[LCD TV Toshiba DIGITAL Series User Manual](#)

(57 pages)

[Air Conditioner Toshiba RAS-16SKV Series Owner's Manual](#)

(52 pages)

[Flat Panel TV Toshiba 40BL702B Owner's Manual](#)

Digital series (50 pages)

[TV Toshiba 32BV501B User Manual](#)

Digital series (49 pages)

[TV Toshiba 22BL704B Owner's Manual](#)

Digital series (48 pages)

[Monitor Toshiba LED TV Series Owner's Manual](#)

(22 pages)

[Air Conditioner Toshiba RAS-10 Owner's Manual](#)

18ufv series, 18sav series (19 pages)

[Split air conditioner Toshiba RAS-05 Installation Manual](#)

(16 pages)

[Air Conditioner Toshiba RAS-M14GAV-E Installation Manual](#)

Split type (12 pages)

[Air Conditioner Toshiba RAS-10\(7\)~16\(7\)SKV Series Installation Manual](#)

Air conditioner (split type) (11 pages)

[Air Conditioner Toshiba RAS-10 SKV Series Owner's Manual](#)

(8 pages)

[Air Conditioner Toshiba RAS-M14GAV-E Owner's Manual](#)

Split type (7 pages)

[Air Conditioner Toshiba RAS-10 Series Owner's Manual](#)

Indoor and outdoor unit (5 pages)

[Air Conditioner Toshiba RAS-10 SKV Series Owner's Manual](#)

Air conditioner (split type) (4 pages)

Summary of Contents for Toshiba RAS-10~16 SKV(R) Series

[Page 1](#) ITALIANO DEUTSCH PORTUGUÊS POLSKI ČESKY HRVATSKI MAGYAR TÜRKÇE NEDERLANDS EΛΛΗΝΙΚΑ SVENSKA SUOMI NORSK DANSK ROMÂNĂ AIR CONDITIONER (SPLIT TYPE) For general public use EESTI Indoor unit LATVISKI RAS-10~16 SKV(R) Series RAS-M10~16 SK(C)V Series SLOVENČINA Outdoor unit SLOVENŠČINA RAS-10~16 SAV(R) Series...

[Page 2: Precautions For Safety](#)

“ONE-TOUCH” of the button. If you prefer other settings you can select from the many other operating functions of your Models: RAS-10, 13, 16SKV(R) Series, RAS-M10, 13, 16SK(C)V Series, 1 Hi POWER (Green) Toshiba unit. 2 FILTER (Orange) ONE-TOUCH 3 PURE (Blue) (10, 13,

16SKVR-E Series) Press : Start the operation.

[Page 3: Temporary Operation](#)

Cleaning the plasma air purifier unit (About 1000 hours performed) TEMPORARY OPERATION (RAS-10, 13, 16SKVR-E Only) 1. Turn off air conditioner using remote control and power supply. In case of the misplaced or discharged remote control 2. Take out the air inlet grille (See detail in installation manual). •...

[Page 4](#) 1110250125...

This manual is also suitable for:

[Ras-m10~16 sk\(c\)vSeries](#) [Ras-10skv series](#) [Ras-13skv series](#) [Ras-10sav series](#) [Ras-13sav series](#) ... [Show all](#)