




Toshiba RAS-107SKV Owner's Manual

Split type

1
2
3
4

--

•

Bookmarks

--

Quick Links

[Download this manual](#) See also: [Installation Manual](#)



OWNER'S MANUAL

AIR CONDITIONER (SPLIT TYPE)

For general purpose use

Indoor unit

RAS-107, 137, 167SKV Series

Outdoor unit

RAS-107, 137, 167SAV Series

TOSHIBA



TOSHIBA



ΕΛΛΗΝΙΚΑ

SVENSKA

SUOMI

NORSK

DANSK

ROMÂNĂ

БЪЛГАРСКИ

EESTI

LATVISKI

SLOVENČINA

SLOVENŠČINA

ManualsLib.com

1110250170

[Next Page](#)

1
2
3
4

Related Manuals for Toshiba RAS-107SKV

[Air Conditioner Toshiba RAS-137SKV Series Installation Manual](#)

(160 pages)

[Air Conditioner Toshiba RAS-107SKV series Installation Manual](#)

(55 pages)

[Air Conditioner Toshiba RAS SKV Series Installation Manual](#)

Split type air conditioner (31 pages)

[Air Conditioner Toshiba RAS-107 Owner's Manual](#)

Air conditioner (18 pages)

[Air Conditioner Toshiba RAS-10\(7\)~16\(7\)SKV Series Installation Manual](#)

Air conditioner (split type) (11 pages)

[Air Conditioner Toshiba RAS-077SKV Owner's Manual](#)

(4 pages)

[Air Conditioner Toshiba RAS-107SKV Series Owner's Manual](#)

Toshiba split type air conditioners indoor/outdoor unit (3 pages)

[Split type air conditioners Toshiba RAS-167SKV Series Installation Manual](#)

Indoor/outdoor unit (160 pages)

[Air Conditioner Toshiba RAS-077 Series Owner's Manual](#)

(45 pages)

[Air Conditioner Toshiba RAS-077KV Series Owner's Manual](#)

Air conditioner (split type) (21 pages)

[Air Conditioner Toshiba RAS-077 Owner's Manual](#)

Air conditioner (split type) indoor unit and outdoor unit (4 pages)

[Air Conditioner Toshiba RAS-107 Owner's Manual](#)

(51 pages)

[Air Conditioner Toshiba RAS-077SKV-E6 Service Manual](#)

Split type air conditioner (104 pages)

[Air Conditioner Toshiba RAS-107SKV-E5 Technical Handbook](#)

(78 pages)

[Air Conditioner Toshiba RAS-167SKV-E7 Installation Manual](#)

(10 pages)

[Air Conditioner Toshiba RAS-107SKV-E3 Service Manual](#)

Split type (86 pages)

Summary of Contents for Toshiba RAS-107SKV

[Page 1](#) OWNER'S MANUAL ENGLISH ESPAÑOL FRANÇAIS ITALIANO DEUTSCH PORTUGUÊS POLSKI ČESKY HRVATSKI MAGYAR NEDERLANDS ΕΛΛΗΝΙΚΑ SVENSKA SUOMI NORSK DANSK ROMÂNĂ БЪЛГ АРСКИ EESTI LATVISKI AIR CONDITIONER (SPLIT TYPE) SLOVENČINA For general public use SLOVENŠČINA Indoor unit RAS-107, 137, 167SKV Series Outdoor unit RAS-107, 137, 167SAV Series 1110250170...

[Page 2](#) TOUCH" of the button. If you prefer other settings you can select from the 2 FILTER (Orange) Hi POWER FILTER PRE. DEF TIMER OPERATION many other operating functions of your

Toshiba unit. 3 PRE. DEF (DE-FROST) (Orange) ONE-TOUCH 4 TIMER (Yellow) Press : Start the operation. 5 OPERATION (Green)

[Page 3](#) TEMPORARY OPERATION MAINTENANCE In case of the misplaced or discharged remote control Firstly, turn off the circuit breaker. • Pressing the RESET button, the unit can start or stop without Filter Reset (Some models only) using the remote control. FILTER lamp lights on; the fi lter must be cleaned. •...

[Page 4](#) Information according to EMC Directive 2004/108/EC (Name of the manufacturer) TOSHIBA CARRIER (THAILAND) CO., LTD. (Address, city, country) 144/9 MOO 5, BANGKADI INDUSTRIAL PARK, TIVANON ROAD, TAMBOL BANGKADI, AMPHUR MUANG, PATHUMTHANI 12000, THAILAND. (Name of the Importer/Distributor in EU) TOSHIBA CARRIER UK LTD.

This manual is also suitable for:

Ras-167skvRas-137skvRas-107savRas-137savRas-167savRas-137 ... [Show all](#)