





Sanyo DVD-HP62 Service Manual



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19

20

• PAGE

1

OF 20 GO

•

[Table of Contents](#)

•

## Bookmarks

[Download this manual](#)

## Quick Links





# Service Manual

## CONTENTS

<a href="#">Laser beam safety precaution</a> .....	1
<a href="#">Exploded View (Packing &amp; Accessories)</a> .....	2
<a href="#">Exploded View (Cabinet &amp; Chassis)</a> .....	3
<a href="#">Parts List</a> .....	4
<a href="#">Schematic Diagram</a> .....	6
<a href="#">Wiring Diagram</a> .....	22
<a href="#">Wiring Connection</a> .....	30

## Portable DVD Player

FILE NO.

# DVD-HP62



**(XE)**

**PRODUCT CODE No.**

**137 130 02**

**SM**

**REFERENCE No.**

**5810758**

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Sanyo DVD-HP62

[Portable DVD Player Sanyo DVD-HP62 Service Manual](#)

(20 pages)

[Portable DVD Player Sanyo DVD-L77 Instruction Manual](#)

Dvd/video cd/cd player with stereo radio and 6.2" widescreen lcd dvd boomer (15 pages)

[Portable DVD Player Sanyo DVD-L77 Instruction Manual](#)

Dvd boomer dvd/video cd/cd player with stereo radio and 6.2" widescreen lcd (15 pages)

[Portable DVD Player Sanyo DVD-L70 Instruction Manual](#)

Portable lcd tv/dvd player (56 pages)

[Portable DVD Player Sanyo DVD-HP42 Service Manual](#)

(19 pages)

[Portable DVD Player Sanyo DVD-HP42 Service Manual](#)

(19 pages)

[Portable DVD Player Sanyo DVD-HP42 Service Manual](#)

(19 pages)

[Portable DVD Player Sanyo MCD-DV595M/XE Service Manual](#)

Dvd portable radio cassette recorder (22 pages)

## Summary of Contents for Sanyo DVD-HP62

### [Page 1: Table Of Contents](#)

FILE NO. DVD-HP62 Service Manual Portable DVD Player (XE) CONTENTS Laser beam safety precaution ..... 1 PRODUCT CODE No. 137 130 02 Exploded View (Packing & Accessories) .....2 Exploded View (Cabinet & Chassis) ..... 3 Parts List .....4 Schematic Diagram .....

### [Page 2: Laser Beam Safety Precaution](#)

LASER BEAM SAFETY PRECAUTION • Pickup that emits a laser beam is used on this CD section. CAUTION : USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE. LASER OUTPUT ....0.6 mW Max. (CW) WAVE LENGTH ....

### [Page 3: Exploded View \(Packing & Accessories\)](#)

EXPLODED VIEW (PACKING & ACCESSORIES) - 2 -...

### [Page 4: Exploded View\(Cabinet & Chassis\)](#)

EXPLODED VIEW(CABINET & CHASSIS) - 3 -...

### [Page 5: Parts List](#)

PARTS LIST PRODUCT SAFETY NOTICE EACH PRECAUTION IN THIS MANUAL SHOULD BE FOLLOWED DURING SERVICING. COMPONENTS IDENTIFIED WITH THE IEC SYMBOL IN THE PARTS LIST AND THE SCHEMATIC DIAGRAM DESIGNATE COMPONENTS IN WHICH SAFETY ! ! ! CAN OF SPECIAL SIGNIFICANCE. WHEN REPLACING A COMPONENT IDENTIFIED , USE ONLY THE REPLACEMENT PARTS DESIGNATED, OR PARTS WITH THE SAME RATINGS OF RESISTANCE, WATTAGE OR VOLTAGE THAT ARE DESIGNATED IN THE PARTS LIST IN THIS MANUAL.

### [Page 6](#) REF.NO. PART NO. DESCRIPTION REF.NO. PART NO. DESCRIPTION D0004 645 081

8813 DIODE SK34 LED01 645 068 5163 LED F0001 645 081 9063 FUSE Q0002 645 068 5125  
TRANSISTOR 3906 IC004 645 081 8806 TRANSISTOR SI9435A Q0003 645 075 8461  
TRANSISTOR AO3407 IC005 645 081 8806 TRANSISTOR SI9435A Q0004...

### [Page 7: Schematic Diagram](#)

SCHEMATIC DIAGRAM (MAIN-1) This is a basic schematic diagram. - 6 - - 7 -...

[Page 8](#) SCHEMATIC DIAGRAM (MAIN-2) This is a basic schematic diagram. - 8 - - 9 -...

[Page 9](#) SCHEMATIC DIAGRAM (MAIN-3) This is a basic schematic diagram. - 10 - - 11 -...

[Page 10](#) SCHEMATIC DIAGRAM (MAIN-4) This is a basic schematic diagram. - 12 - - 13 -...

[Page 11](#) SCHEMATIC DIAGRAM (MAIN-5) This is a basic schematic diagram. - 14 - - 15 -...

[Page 12](#) SCHEMATIC DIAGRAM (MAIN-6) This is a basic schematic diagram. - 16 - - 17 -...

[Page 13](#) SCHEMATIC DIAGRAM (DVD KEY) SCHEMATIC DIAGRAM (BATTERY CHARGE) - 18 - - 19 -...

[Page 14](#) SCHEMATIC DIAGRAM (MONITOR MAIN) 0.1uF R272 R250 560 R236 680K 380PF  
R238 330K 0.1uF R240 R231 C254 C215 0.1uF R242 C234 C217 C203 C232 0.82uH 0.01uF  
1000P 18uH C219 1000 0.1uF 100PF R233 NJM2107F C216 0.1uF IC-1C C233 C218 0.01uF OPEN  
R224 C201...

### [Page 15: Wiring Diagram](#)

WIRING DIAGRAM (DVD MAIN A SIDE) - 22 - - 23 -...

[Page 16](#) WIRING DIAGRAM (DVD MAIN B SIDE) - 24 - - 25 -...

[Page 17](#) WIRING DIAGRAM (BATTERY CHARGE) WIRING DIAGRAM (DVD KEY) - 26 - - 27 -...

[Page 18](#) WIRING DIAGRAM (MONITOR MAIN) - 28 - - 29 -...

### [Page 19: Wiring Connection](#)

WIRING CONNECTION - 30 -...

[Page 20](#) SANYO Electric Co., Ltd. Osaka, Japan Jun / '05 Printed in Japan...