



Sanyo DC-C30 Service Manual

Mini component system

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37

•

[Table of Contents](#)

•


Bookmarks

Quick Links

[1 Specifications](#)

[Download this manual](#)

See also: [Instruction Manual](#)



L
L

Service Manual

Contents

I FILE NO.

I

Mini Component System

DC-C30

(AU)

[Specifications](#)

..... 1

[What to do if](#) 1

Laser beam safety precaution 2

[CD pick-up maintenance](#)

Service Manual


Mini Component System



.....	2
Service mode	2
CD player adjustments	3
Tape adjustments	4
Tuner adjustments	6
Exploded view	7
(Cabinet & Chassis)	7
(Tape mechanism)	15
(CD changer mechanism)	16
(CD base mechanism)	17
Parts list	8
(Cabinet & Chassis)	14
(Tape mechanism)	17
(CD mechanism)	17
PRODUCT CODE No. 12955605	
IC block diagram & description	18
FL display description	23
IC & Transistor voltages	24
Wiring connection	25
Schematic diagram	26
(TUNER)	28
(AMPLIFIER)	32
(FRONT)	36
(CD)	40
(DECK)	30
Wiring diagram (TUNER & AMPLIFIER)	34
(FRONT)	38
(CD)	39
(DECK)	42
(POWER TRANSFORMER)	43
(POWER SWITCH, DISC SWITCH)	43

Service Manual

Mini Component System



Contents

Specifications	1
What to do if	1
Laser beam safety precaution	2
CD pick-up maintenance	2
Service mode	2
CD player adjustments	3
Tape adjustments	4
Tuner adjustments	6
Exploded view	7
(Cabinet & Chassis)	7
(Tape mechanism)	15
(CD changer mechanism)	16
(CD base mechanism)	17
Parts list	

IC block diagram & description	
FL display description	
IC & Transistor voltages	
Wiring connection	
Schematic diagram	
(TUNER)	
(AMPLIFIER)	
(FRONT)	
(CD)	
(DECK)	
Wiring diagram	
(TUNER & AMPLIFIER)	
(FRONT)	
(CD)	

This service manual is for model
(Main unit: 12955605),
05),

ManualsLib.com

RB-C30'

(Remote control) and "SX-C30' (Speaker system:
133 68402)ti

REFERENCE

No. SM5810047

Service Manual

Mini Component System

[Next Page](#)

1
2
3
4
5

Related Manuals for Sanyo DC-C30

[Stereo System Sanyo DC-C30 Instruction Manual](#)

(13 pages)

[Micro Music System Sanyo DC-DA2000 Service Manual](#)

Micro component system (12 pages)

[Micro Music System Sanyo DC-D9 Service Manual](#)

Mini component system (76 pages)

[Micro Music System Sanyo DC-DA70 Service Manual](#)

Micro component system (33 pages)

Related Products for Sanyo DC-C30

[Sanyo DC-DA70](#)

[Sanyo DC-C70](#)

[Sanyo DC-C300](#)

[Sanyo DC-C200](#)

[Sanyo DC-C10](#)

[Sanyo DC-AVD8501](#)

[Sanyo DC-DA1100 \(XE\)](#)

[Sanyo DC-X8CT](#)

[Sanyo DC-DA170](#)

[Sanyo DC-BM300XE](#)

[Sanyo DC-D27](#)

[Sanyo DC-M3](#)

[Sanyo DC-MCR60XE](#)

[Sanyo DC-D7](#)

[Sanyo DC D60](#)

[Sanyo DC-X801](#)